CHEBIO CVC V16PRO

CHEBIO V16PRO Cordless Vacuum Cleaner User Manual

Model: CVC V16PRO | Brand: CHEBIO

1. Introduction

Thank you for choosing the CHEBIO V16PRO Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Always disconnect the vacuum cleaner from the charger before cleaning or performing maintenance.
- Do not use the vacuum cleaner to pick up water or wet substances, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner if it has been dropped, damaged, left outdoors, or dropped into water.
- Use only manufacturer-recommended attachments.
- Store the vacuum cleaner indoors in a dry place.

2. Package Contents

Please check the package contents to ensure all items are present:

- Main Vacuum Unit (with dustbin and motor)
- Extension Wand
- Motorized Floor Brush
- Long Crevice Nozzle
- 2-in-1 Dust Brush
- Wall Mount Bracket
- Power Adapter/Charger

- User Manual



An overview of the CHEBIO V16PRO cordless vacuum cleaner, highlighting its versatile design, main unit, extension wand, floor brush, and included attachments. The image also displays the digital power indicator.

3. Product Overview

Familiarize yourself with the main components of your CHEBIO V16PRO vacuum cleaner:

Main Unit and Display



The intuitive LED display provides real-time information including battery level, current suction mode (Min, Mid, Max), and alerts for a tangled brush roller or a clogged air duct, ensuring optimal performance.

- **Power Button:** Turns the vacuum on/off.
- **Mode Button:** Cycles through suction modes (Min, Mid, Max).
- **LED Display:** Shows battery indicator, suction mode, brush roller tangled warning, and air duct clogged warning.
- **Dustbin Release Button:** For emptying the dustbin.

Attachments



The vacuum easily converts into a handheld unit, perfect for cleaning furniture, car interiors, or high-up areas. It comes with a long crevice nozzle for tight spaces and a 2-in-1 dust brush for versatile cleaning.

- **Motorized Floor Brush:** Ideal for carpets and hard floors. Features an anti-tangle V-roller.
- **Long Crevice Nozzle:** For narrow gaps, corners, and hard-to-reach areas.
- **2-in-1 Dust Brush:** Can be used as a soft brush for delicate surfaces or as a wide nozzle for general dusting.

4. Setup

Assembly

1. Insert the extension wand into the main vacuum unit until it clicks securely.
2. Attach the motorized floor brush to the other end of the extension wand until it clicks.
3. Alternatively, attach any desired accessory (crevice tool, 2-in-1 brush) directly to the main unit for handheld

use.

Charging the Battery

Before first use, fully charge the battery. The battery can be charged while attached to the main unit or separately.



Detail of the vacuum's removable battery, which provides up to 60 minutes of runtime in Min-Mode, 40 minutes in Mid-Mode, and 20 minutes in Max-Mode. The battery can be charged separately.

1. Connect the power adapter to the charging port on the battery or the main unit.
2. Plug the adapter into a wall outlet.
3. The LED display will indicate charging status. A full charge typically takes several hours.

5. Operating Instructions

Powering On/Off and Suction Modes

- Press the Power Button to turn the vacuum cleaner on. It will start in the default suction mode.
- Press the Mode Button repeatedly to cycle through Min, Mid, and Max suction modes.
- Press the Power Button again to turn the vacuum cleaner off.



This image illustrates the CHEBIO V16PRO in action, showcasing its powerful 500W motor and 40KPa suction capability, effectively cleaning debris from hard floor surfaces.

Using the Self-Standing Feature



The vacuum cleaner features a convenient self-standing design, allowing it to remain upright on its own for easy storage and quick pauses during cleaning.

The CHEBIO V16PRO is designed to stand upright on its own. Simply release the vacuum from your hand, and it will remain standing, allowing for convenient pauses during cleaning or for temporary storage.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dustbin

1. Ensure the vacuum is turned off.
2. Press the dustbin release button to detach the dustbin from the main unit.
3. Hold the dustbin over a trash can and press the dustbin bottom release button to empty contents.

4. Close the dustbin flap and reattach the dustbin to the main unit until it clicks.

Cleaning the Filters



An illustration of the advanced 5-layer cone fine filtration system, which effectively captures 99.99% of allergens and dirt particles, ensuring cleaner air and preventing secondary pollution.

The CHEBIO V16PRO features a 5-layer cone fine filtration system, including a HEPA filter. Filters should be cleaned regularly (e.g., monthly, depending on usage) and replaced every 3-6 months.

1. Remove the dustbin and then carefully remove the filter components.
2. Tap the filters to remove loose dust. For thorough cleaning, rinse the filters under cold running water.
3. Allow all filter components to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.

Cleaning the Brush Roll



The anti-tangle V-roller floor brush is designed to reduce hair knotting by 99%, making it ideal for homes with pets. Its unique V-shape channels hair directly into the dustbin, preventing tangles.

1. Turn off the vacuum and detach the floor brush.
2. Locate the brush roll release mechanism (usually a latch or screw on the side of the brush head).
3. Remove the brush roll. Use scissors to cut away any tangled hair or debris.
4. Clean the brush roll and the brush housing. Reinsert the brush roll and secure it.

7. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or improperly installed.	Charge the battery fully. Ensure the battery is securely clicked into place.
Weak suction.	Dustbin is full. Filters are clogged. Air duct is blocked.	Empty the dustbin. Clean or replace filters. Check for blockages in the extension wand or floor brush.
Brush roll not spinning.	Brush roll is tangled with hair/debris. Obstruction in the brush head.	Clean the brush roll. Remove any obstructions from the brush head.
Unusual noise.	Obstruction in the air duct or brush roll.	Check for and remove any blockages in the vacuum path or brush roll.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	CHEBIO
Model Number	CVC V16PRO
Color	Lemon Yellow
Product Dimensions (L x W x H)	2.54 x 2.54 x 2.54 cm (approx. 1 x 1 x 1 inch); 3.73 kilograms
Power	500W
Noise Level	62 dB
Runtime	Up to 1 hour (60 minutes)
Special Feature	HEPA Filtration
Filter Type	Cyclonic Filter
Surface Recommendation	Carpet, Hard Floor, Tile, Hardwood
Power Source	Cordless Battery
Components Included	Accessory Kit
Battery	1 Lithium-ion (included)

9. Warranty and Support

The CHEBIO V16PRO Cordless Vacuum Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, spare parts, or any inquiries not covered in this manual, please contact CHEBIO customer service through the retailer where you purchased the product or visit the official CHEBIO website for contact information.

© 2024 CHEBIO. All rights reserved.