Fagor FGAF8L

FAGOR Air Fryer 8L User Manual

Model: FGAF8L

1. Introduction

Thank you for choosing the FAGOR Air Fryer 8L. This appliance is designed to provide a healthier way to cook your favorite foods, using hot air circulation to achieve crispy results with little to no oil. With its large 8-liter capacity, 1800W power, LED screen, and 7 pre-set programs, it offers convenience and versatility for your kitchen.
Please read this manual thoroughly before operating the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and extend the life of your air fryer.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation.

- Do not block any ventilation openings.

3. Product Components

Familiarize yourself with the parts of your FAGOR Air Fryer 8L:



Figure 3.1: Front view of the FAGOR Air Fryer 8L, showing the main unit, LED digital display, and the basket handle.



Figure 3.2: The FAGOR Air Fryer 8L with its cooking basket fully pulled out, revealing the spacious interior for food preparation.



Figure 3.3: The FAGOR Air Fryer 8L positioned on a kitchen counter, demonstrating its compact size and how it fits into a typical kitchen environment, with prepared food nearby.

- **Main Unit:** Houses the heating element and fan.
- **Cooking Basket:** Removable basket for holding food.
- **LED Digital Display:** Shows temperature, time, and selected programs.
- **Control Panel:** Sensitive touch controls for operation.
- **Handle:** For safely pulling out and inserting the cooking basket.
- **Air Inlet/Outlet:** For proper air circulation during cooking.

4. Setup

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, clean the cooking basket and any removable parts with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance to allow for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. Operating Instructions

5.1 Control Panel Overview

The FAGOR Air Fryer features an intuitive LED digital display and sensitive touch controls:

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature (80°C - 200°C).
- **Time Control:** Adjusts cooking time (up to 60 minutes).
- **Pre-set Programs:** Select from 7 pre-recorded cooking programs for common dishes.
- **Start/Pause Button:** Initiates or pauses the cooking cycle.

5.2 Basic Operation

1. **Prepare Food:** Place your ingredients into the cooking basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the cooking basket back into the main unit until it clicks into place.
3. **Power On:** Press the Power Button to turn on the air fryer. The LED display will illuminate.

4. **Set Time and Temperature:**
    - Manually adjust the temperature and time using the respective control buttons.
    - Alternatively, select one of the 7 pre-set programs. The air fryer will automatically set the recommended time and temperature for that program.
5. **Start Cooking:** Press the Start/Pause Button to begin the cooking process. The fan and heating element will activate.
6. **Shake/Turn Food (Optional):** For some recipes, it is recommended to shake or turn the food halfway through the cooking time to ensure even browning. Pull out the basket, shake or turn the food, and then reinsert the basket. The air fryer will automatically resume cooking.
7. **Cooking Completion:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and check if the food is cooked to your preference.
8. **Serve:** Carefully remove the cooked food from the basket. Use non-scratch utensils.
9. **Power Off:** Press the Power Button to turn off the appliance after use. Unplug from the wall outlet.

6. Maintenance and Cleaning

Regular cleaning and maintenance will help prolong the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Cooking Basket:** The cooking basket is non-stick. Clean it with warm water, a mild dishwashing detergent, and a non-abrasive sponge. For stubborn residue, soak the basket in warm soapy water for about 10 minutes before cleaning. The basket may also be dishwasher safe (check product specific instructions if available, otherwise hand wash is recommended).
3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. Do not use abrasive cleaners or steel wool.
4. **Clean Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer. Store it in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your FAGOR Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Power outlet not working; Basket not inserted correctly.	Ensure the power cord is securely plugged into a working outlet. Check if the basket is fully inserted and clicked into place.
Food is not cooked evenly.	Basket is overfilled; Food pieces are too large; Food not shaken/turned.	Do not overfill the basket. Cut food into smaller, more uniform pieces. Shake or turn food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; Fatty ingredients cooking.	Clean the basket and interior thoroughly after each use. For fatty foods, ensure excess oil is drained. This is usually harmless.

Problem	Possible Cause	Solution
Appliance smells during first use.	Protective coating burning off.	This is normal for first use and will dissipate. Ensure good ventilation.

8. Specifications

Feature	Detail
Brand	Fagor
Model Number	FGAF8L
Capacity	8 Liters
Power	1800 Watts
Voltage	230 Volts
Material	Metal
Features	Large 8-liter capacity, LED screen, Sensitive touch controls, 7 pre-set programs, 60-minute timer, 80-200°C temperature range
Item Weight	6.6 Kilograms

9. Warranty and Support

This FAGOR Air Fryer 8L comes with a manufacturer's warranty. Please refer to the warranty card or documentation included with your purchase for specific terms, conditions, and duration of the warranty.
For technical support, service, or inquiries regarding spare parts, please contact FAGOR customer service. Contact information can typically be found on the FAGOR official website or on the product packaging.
Please note that information regarding the availability of spare parts was not provided at the time of this manual's creation.

© 2024 FAGOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question