ceamorfco 25BD

User Manual for Portable Washing Machine

Brand: ceamorfco | Model: 25BD

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your new ceamorfco Portable Washing Machine. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image: The ceamorfco Portable Washing Machine, a compact twin-tub design in blue and white, with water effects indicating its washing function.

Product Features

- **Twin Tub Design:** Features an 8lbs washing tub and a 5lbs spin-dry tub for separate washing and spinning cycles.
- **Multiple Cleaning Modes:** Offers three washing modes: Soft, Normal, and Drain, to suit various fabric types and cleaning needs.
- **Powerful Motor:** Equipped with a 1300RPM motor (60HZ max frequency) for efficient and quick laundry cycles.
- **Compact and Portable:** Measuring 21.6" x 14.1" x 20.4", ideal for small living spaces such as dorms, RVs, apartments, and college rooms.
- **User-Friendly Controls:** Simple control panel with wash and spin timer options for easy operation.
- **Semi-Transparent Lid:** Allows clear visibility of the washing process.
- **Durable Construction:** Crafted with a premium metal bucket and sturdy plastic material, weighing 24 pounds, ensuring longevity.

- **Integrated Drain Pump and Hose:** Facilitates convenient water disposal.



Image: Comparison showing the compact portable washing machine next to a full-size washing machine, highlighting energy savings of over 60%.




Image: Visual representation of the washing machine's dimensions (21.6" x 14.1" x 22.4") and loading capacity for various clothing items like underwear, socks, t-shirts, baby clothes, and jeans.

What's in the Box

Upon unpacking, please ensure all the following components are present and undamaged:

- 1 x Portable Washing Machine Unit
- 1 x Inlet Hose (5 FT)
- 1 x Drain Hose
- 1 x Spin Cap



Image: Detailed view of key components including the pulsator, hose clamp, water inlet, wash tab, spin cap, and drain hose.

Setup Instructions

1. **Unpacking:** Carefully remove the washing machine from its packaging. Retain packaging materials for future transport or storage.
2. **Placement:** Place the washing machine on a firm, level surface near a water source and a drain. Ensure there is adequate space around the unit for ventilation and operation. The machine is designed for use in various compact environments such as RVs, dormitories, bathrooms, and apartments.
3. **Connect Inlet Hose:** Attach the 5 FT inlet hose to the water inlet on the washing machine and to a suitable water faucet. Ensure connections are secure to prevent leaks.
4. **Position Drain Hose:** Place the drain hose into a sink, bucket, or floor drain. Ensure the hose is not kinked or obstructed to allow for proper drainage. The machine includes a drain pump for convenient water disposal.
5. **Power Connection:** Plug the power cord into a grounded 110V electrical outlet.



Image: Depicts various application scenarios for the portable washing machine, including RVs, dormitories, bathrooms, and apartments, emphasizing its versatility in limited spaces.

Operating Instructions

Washing Cycle

1. **Load Laundry:** Open the lid of the washing tub and place clothes inside. Do not overload the tub; the washing tub has an 8lbs capacity.
2. **Add Detergent:** Add appropriate amount of laundry detergent directly into the washing tub.
3. **Fill with Water:** Turn on the water faucet connected to the inlet hose to fill the washing tub with water to the desired level.
4. **Select Wash Mode:** Use the "Wash Selector" knob to choose one of the three washing modes:
   - **Soft:** For delicate items.
   - **Normal:** For everyday laundry.
   - **Drain:** To drain water from the wash tub.
5. **Set Wash Timer:** Turn the "Wash Timer" knob to set the desired washing time, up to 15 minutes. The machine will start automatically.
6. **Monitor Progress:** The semi-transparent lid allows you to observe the washing process.
7. **Drain Water:** Once the wash cycle is complete, set the "Wash Selector" knob to "Drain" to empty the water from the washing tub.

Spin Drying Cycle

1. **Transfer Laundry:** Carefully transfer the washed clothes from the washing tub to the spin-dry tub. The spin-dry tub has a 5lbs capacity. Ensure clothes are evenly distributed.
2. **Place Spin Cap:** Place the spin cap firmly on top of the clothes in the spin-dry tub to prevent items from flying out during spinning.
3. **Set Spin Timer:** Turn the "Spin Timer" knob to set the desired spin drying time, up to 5 minutes. The spin cycle will begin.
4. **Remove Clothes:** Once the spin cycle is complete, remove the spin cap and take out the spun-dry clothes. They will be significantly drier than after a wash cycle, reducing drying time.



Image: Close-up of the control panel showing the Wash Timer (0-15 min), Wash Selector (3 MODS: Soft/Normal/Drain), and Spin Timer (0-5 min) knobs, along with the water inlet.

Maintenance

- **Cleaning the Exterior:** Wipe the exterior of the machine with a soft, damp cloth after each use. Avoid abrasive cleaners or solvents.
- **Cleaning the Tubs:** Periodically clean the inside of the washing and spin tubs to prevent residue buildup. A mild detergent and water can be used. Rinse thoroughly.
- **Drain Hose Maintenance:** Ensure the drain hose is clear of blockages. If water flow is slow, check for kinks or debris.
- **Storage:** If storing the machine for an extended period, ensure both tubs are completely dry. Disconnect hoses and store them properly. Store the machine in a dry, cool place.
- **Filter Cleaning:** Check and clean any lint filters regularly to maintain optimal performance. (Note: Specific filter location not detailed in product info, general advice).

Troubleshooting

Problem	Possible Cause	Solution
Machine does not start.	Not plugged in; power outage; timer not set.	Ensure power cord is securely plugged into a live outlet. Check circuit breaker. Set the wash or spin timer.
Water does not drain.	Drain hose kinked or blocked; drain selector not set to "Drain".	Straighten the drain hose and check for obstructions. Ensure the "Wash Selector" knob is set to "Drain".
Excessive vibration or noise during spin.	Uneven load in spin tub; machine not on a level surface.	Redistribute clothes evenly in the spin tub. Ensure the machine is placed on a stable, level surface.

Problem	Possible Cause	Solution
Water leaks from machine.	Hoses not securely connected; tub overloaded; crack in tub (less common).	Check and tighten all hose connections. Do not exceed maximum load capacity. Inspect the tub for visible damage.
Clothes not clean.	Too much laundry; insufficient detergent; incorrect wash mode.	Reduce load size. Use recommended amount of detergent. Select appropriate wash mode (Normal for most items).

Specifications

Feature	Detail
Brand	ceamorfco
Model Number	25BD
Product Dimensions	21.6"D x 14.1"W x 22.4"H (54.86 x 35.81 x 56.9 cm)
Item Weight	24 Pounds (10.89 kg)
Washing Capacity	8 lbs
Spin Drying Capacity	5 lbs
Total Capacity	13 lbs
Max Spin Speed	1300 RPM
Voltage	110 Volts
Control Console	Push Button / Rotary Knobs
Access Location	Top Load
Material	Plastic (with metal bucket)
Color	Blue
Special Features	Child Lock, Easy to Install, High Efficiency, Portable, Vertical Cleansing

Warranty and Support

Specific warranty details for the ceamorfco Portable Washing Machine (Model 25BD) are not provided in the available product information. For warranty claims, technical support, or service inquiries, please contact ceamorfco customer service directly through their official channels or the retailer from whom the product was purchased. Please have your model number (25BD) and purchase date available when contacting support.

© 2024 ceamorfco. All rights reserved.