Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JTOSMFNA WDA-100

JTOSMFNA Wooden Decorative Sign (Model WDA-100, Variant WD011) User Manual

Comprehensive instructions for your decorative wall sign.

1. Product Overview

The JTOSMFNA Wooden Decorative Sign, Model WDA-100 (Variant WD011), is a wall-hanging accessory designed to enhance your living space. Crafted from solid MDF wood fiberboard, this sign features a durable construction and comes with pre-attached twine for easy hanging. It measures approximately 12 inches by 6 inches.



Image 1.1: Front view of the JTOSMFNA Wooden Decorative Sign, Model WD011.

Key Features:

- **Material:** Solid MDF wood fiberboard, 1/4 inch thickness.
- **Dimensions:** Approximately 12 inches (30.5 cm) in length by 6 inches (15.2 cm) in width.
- **Hanging Mechanism:** Securely stapled twine on the back for easy installation.
- **Durability:** Designed for indoor use, can be used outdoors if not exposed to moisture.

2. Setup and Installation

Follow these steps to properly install your decorative sign:

1. **Choose Location:** Select a suitable indoor location for display. If placing outdoors, ensure it is in a sheltered area protected from direct rain and moisture.
2. **Prepare Mounting Point:** Use a nail, screw, or adhesive hook appropriate for your wall type and the sign's weight (approximately 91g). Ensure the mounting point is secure.
3. **Hang the Sign:** Carefully hang the sign using the pre-attached twine loop on the back. Ensure the sign is level and stable.

3. Operation

The JTOSMFNA Wooden Decorative Sign is designed for passive display. Once installed, no further operation is required. Enjoy its aesthetic contribution to your chosen space.

4. Maintenance and Care

To ensure the longevity and appearance of your decorative sign, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the sign with a soft, dry cloth to remove dust. Avoid using abrasive cleaners or excessive moisture, which can damage the wood finish.
- **Moisture Protection:** As the sign is made of MDF, prolonged exposure to high humidity or direct water can cause warping or damage. If used outdoors, ensure it is in a well-protected area.
- **Sunlight Exposure:** Direct and prolonged sunlight may cause the colors to fade over time. Consider placement to minimize direct sun exposure.

5. Troubleshooting

Here are solutions to common issues you might encounter:

- **Sign is not hanging straight:** Adjust the twine on the mounting point or reposition the mounting point slightly until the sign is level.
- **Sign falls from wall:** Ensure the mounting point (nail, screw, hook) is securely fixed into the wall and can support the sign's weight. Check the integrity of the twine.
- **Sign appears dull or dusty:** Refer to the 'Maintenance and Care' section for proper cleaning instructions.

6. Specifications

Attribute	Detail
Brand	JTOSMFNA
Model Number	WDA-100
Variant Color	WD011
Product Dimensions (L x W)	30.5 cm x 15.2 cm (12 inches x 6 inches)
Item Weight	91 g
Material	Solid MDF Wood Fiberboard
UPC	763102409668
Country of Origin	India

7. Warranty Information

Specific warranty details for the JTOSMFNA Wooden Decorative Sign are not provided in this manual. Please refer to your purchase documentation or contact the retailer for information regarding applicable warranties.

8. Customer Support

For further assistance, questions, or concerns regarding your JTOSMFNA Wooden Decorative Sign, please contact the retailer or manufacturer through their official support channels. Contact information can typically be found on the product packaging or the retailer's website.

© 2026 JTOSMFNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D262CHCY

More documents and user manuals: **https://manuals.plus/**