ChooChoo CT2304-1TWL

ChooChoo Farmhouse Lift-Top Coffee Table Instruction Manual

Model: CT2304-1TWL

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo Farmhouse Lift-Top Coffee Table. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The ChooChoo Farmhouse Coffee Table features a lift-top mechanism and a flip drawer, offering versatile functionality and ample storage. Its design incorporates classic wood grain and antique elements, suitable for various living room decors.

Safety Information

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 39.92 kg (88 lbs) on the tabletop.
- Keep hands and fingers clear of the lift-top mechanism when opening or closing to prevent pinching.
- This product is designed for indoor use only.
- Keep small parts away from children during assembly.

Parts List

Before assembly, verify that all components are present and undamaged. Refer to the included assembly instructions for a complete list of parts and hardware. Each piece is numbered for easy identification.



Figure 1: Exploded view of the ChooChoo Farmhouse Lift-Top Coffee Table, showing individual components and overall dimensions (31.5" L x 31.5" W x 18.1" H, lifting to 22.6" H).

Setup and Assembly

Assembly is required for this coffee table. It is recommended that at least one person performs the assembly. A screwdriver is the only tool recommended for assembly. Detailed instructions with numbered parts are included in the product packaging.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Match each part to the corresponding number in the assembly guide.
3. **Follow Step-by-Step Instructions:** Adhere strictly to the provided assembly manual. Do not skip steps.
4. **Secure Fasteners:** Ensure all screws, bolts, and connectors are tightened firmly. Avoid over-tightening to prevent stripping.
5. **Lift-Top Mechanism:** Pay close attention to the installation of the hydraulic cushion lifter for smooth operation.



Figure 2: Detail of the hydraulic cushion lifter mechanism, which allows the tabletop to smoothly raise and lower.

Operating Instructions

Lift-Top Function

The coffee table features a hydraulic lift-top mechanism, allowing the tabletop to be raised to a height of 22.6 inches, suitable for use as a workspace or dining surface.

- **To Raise:** Gently lift the front section of the tabletop upwards. The hydraulic mechanism will assist in a smooth, controlled ascent.
- **To Lower:** Apply gentle downward pressure to the raised tabletop. The hydraulic mechanism will ensure a slow and controlled descent back to the original coffee table height (18.1 inches).
- **Caution:** Ensure no objects or body parts are in the path of the lift-top when raising or lowering.



Figure 3: The ChooChoo coffee table transitioning between its standard coffee table mode and raised office table mode, highlighting its dual functionality.

Hidden Storage and Flip Drawer

The table provides ample hidden storage space beneath the lift-top and a convenient flip drawer for easy access.

- **Hidden Storage:** When the lift-top is raised, the large compartment beneath becomes accessible for storing blankets, books, or other items.
- **Flip Drawer:** The additional flip drawer allows for easy storage and retrieval of items without needing to move the main desktop. Simply pull the handle to open the drawer.



Figure 4: The coffee table with its lift-top raised, revealing the spacious hidden storage compartment and the accessible flip drawer, ideal for organizing living room essentials.

Maintenance

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the engineered wood top.
- **Hardware Check:** Periodically inspect all screws, bolts, and hinges for tightness. Re-tighten as needed to ensure stability and safe operation of the lift-top mechanism.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or damage to the wood finish.
- **Protect Surfaces:** Use coasters under drinks and placemats under hot items to protect the tabletop.

Troubleshooting

Problem	Possible Cause	Solution
Lift-top mechanism is stiff or uneven.	Loose or improperly installed hydraulic lifter. Obstruction in the mechanism.	Check all connections of the hydraulic lifter and ensure they are securely fastened according to assembly instructions. Inspect for any foreign objects obstructing the movement and remove them.
Table feels wobbly after assembly.	Loose screws or connections. Uneven floor surface.	Re-tighten all assembly screws and bolts. Place shims under the legs if the floor is uneven.
Flip drawer does not open/close smoothly.	Misaligned hinges. Obstruction in the drawer path.	Check and adjust the hinges for proper alignment. Ensure nothing is blocking the drawer's movement.

Specifications

Brand	ChooChoo
Model Number	CT2304-1TWL
Product Dimensions (L x W x H)	80D x 80W x 46H Centimetres (31.5 x 31.5 x 18.1 Inches)
Maximum Lifting Height	22.6 Inches
Item Weight	25 kg (55.1 lbs)
Maximum Weight Recommendation	39.92 kg (88 lbs)
Frame Material	Oak Wood
Top Material Type	Engineered Wood
Color (This Variant)	Antique White & Brown
Number of Drawers	1 (Flip Drawer)
Special Features	Lift-top, Hidden Storage
Assembly Required	Yes
Recommended Assembly Persons	1
Recommended Tools	Screwdriver

Warranty and Support

While specific warranty details are not provided in this manual, ChooChoo is committed to customer satisfaction. If you

encounter any issues with your coffee table, have questions regarding assembly, or require assistance, please contact our customer service team.
Please refer to your purchase documentation or the retailer's website for contact information and any applicable warranty terms.

© 2024 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question