Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo CT2304-BK

ChooChoo Farmhouse Coffee Table with Hidden Storage

Model: CT2304-BK

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo Farmhouse Coffee Table with Hidden Storage. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The ChooChoo Farmhouse Coffee Table in its closed position, showcasing its rustic design and black finish.

Safety Information

Caution: This table features a lifting top mechanism. Exercise care during operation to avoid pinch points. Ensure the table is placed on a stable, level surface. For optimal stability, avoid placing excessive weight on the lifted tabletop. Adhere to the maximum weight recommendation of 39.92 kg. Be aware of the iron sheet details around the table, which may have sharp edges. Always lift and lower the tabletop smoothly and with control.

Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Tabletop Panels (Lift-top and Fixed)
- Side Panels (4)

- Base Frame Components
- Flip Drawer Panel
- Hydraulic Lift Mechanism Components
- Hardware Pack (screws, dowels, hinges, handles)
- Assembly Guide (this document)

Tools Recommended for Assembly: Screwdriver (not included).

Setup and Assembly Instructions

Assembly typically requires two people and approximately 2-3 hours. Follow the numbered steps in the included assembly guide for best results. Ensure you have adequate space for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in your separate assembly guide to identify each piece.
2. **Assemble the Base Frame:** Connect the base frame components using the provided screws and dowels. Ensure all connections are secure.
3. **Attach Side Panels:** Securely attach the four side panels to the assembled base frame. Pay attention to the orientation of each panel, especially those designed for the flip drawer.
4. **Install Flip Drawer Mechanism:** Assemble and install the flip drawer mechanism according to the specific instructions in your guide. This allows for easy access to storage without moving the desktop.
5. **Install Hydraulic Lift Mechanism:** Attach the hydraulic cushion lifter components to the designated areas on the table frame and the lift-top panel. Ensure the mechanism is correctly aligned for smooth operation.



Image: Close-up view of the hydraulic lift mechanism, illustrating its structure for smooth tabletop elevation.

6. **Attach Tabletop Panels:** Carefully attach the fixed tabletop panel and the lift-top panel. Ensure the lift-top panel is correctly aligned with the hydraulic mechanism.
7. **Install Handles and Hardware:** Secure any remaining handles or decorative hardware, such as the classic antique handle, to complete the assembly.



Image: The coffee table with its lift-top raised, revealing the spacious hidden storage compartment and the functional flip drawer.

Operating Instructions

Using the Lift-Top Feature:

- To raise the tabletop, gently lift the front edge of the designated lift-top section. The hydraulic cushion lifter will assist in a smooth, controlled ascent.
- The tabletop can be raised to a maximum height of 22.6 inches, providing a comfortable surface for working, dining, or other activities while seated on a sofa.
- To lower the tabletop, gently push down on the front edge of the lift-top section. Guide it slowly back into its closed position, ensuring fingers are clear of pinch points.

Accessing the Flip Drawer:

- The additional flip drawer is located on the side of the table. To open, gently pull the handle or edge of the drawer panel outwards and downwards.

- This design allows for easy storage access without needing to move items from the main tabletop.
- To close, push the drawer panel upwards and inwards until it is flush with the table's side.



Image: The coffee table with its innovative flip drawer open, demonstrating convenient side access to stored items.

Maintenance

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the wooden grain finish.
- **Dusting:** Regularly dust the table with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining, especially on the wooden grain finish.
- **Weight Distribution:** Distribute weight evenly across the tabletop, especially when the lift-top is extended, to maintain stability and prevent stress on the mechanism.
- **Mechanism Care:** The hydraulic lift mechanism is designed for durability. Avoid forcing it or applying excessive sideways pressure. If the mechanism becomes stiff, ensure no debris is obstructing its movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or damage to the finish.

Troubleshooting

Problem	Possible Cause	Solution
Table is wobbly/unstable	Loose screws; uneven floor	Tighten all assembly screws. Ensure the table is on a level surface.
Lift-top mechanism is stiff or not smooth	Obstruction; mechanism not properly aligned during assembly	Check for any objects obstructing the mechanism. Review assembly steps for the hydraulic lifter to ensure correct installation. Do not force the mechanism.
Flip drawer does not open/close smoothly	Obstruction; panel misalignment	Check for items blocking the drawer's path. Ensure the drawer panel is correctly seated in its tracks.

Problem	Possible Cause	Solution
Missing parts or damaged components	Packaging error; shipping damage	Do not proceed with assembly. Contact ChooChoo customer support immediately for replacement parts.

Specifications

Feature	Detail
Model Number	CT2304-BK
Product Dimensions (L x W x H)	80D x 80W x 46H Centimetres (31.5L x 31.5W x 18.1H inches)
Maximum Lifting Height	22.6 Inches
Item Weight	25 kg
Maximum Weight Recommendation	39.92 kg
Frame Material	Engineered Wood
Top Material Type	Engineered Wood
Color	Black
Number of Drawers	1 (Flip Drawer)
Style	Farmhouse
Assembly Required	Yes



Image: Diagram showing the key dimensions of the ChooChoo Farmhouse Coffee Table, including length, width, and height.

Warranty and Support

ChooChoo products are designed for quality and durability. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims. For assistance with assembly, missing parts, or any product-related inquiries, please contact ChooChoo customer service through the retailer where the product was purchased.

Our service team is ready to help you with any questions about your coffee table or its assembly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2921C5S

More documents and user manuals: **https://manuals.plus/**