Complete Cuisine CC-TOV4400

Complete Cuisine 4-Slice Toaster Oven (9L) Instruction Manual

Model: CC-TOV4400

Introduction Safeguards Parts Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

Thank you for purchasing the Complete Cuisine 4-Slice Toaster Oven. This appliance is designed for quickly toasting and baking various meals and snacks. With a 9-liter capacity, it can accommodate up to four slices of bread or a 9-inch pizza. Please read this manual thoroughly before use to ensure safe and efficient operation.



Image: The Complete Cuisine 4-Slice Toaster Oven, a compact appliance suitable for various kitchen tasks.



Image: This illustration highlights the toaster oven's capacity to fit 4 slices of toast or a 9-inch pizza, with approximate dimensions of 16" x 12" x 9".

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the toaster oven.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, or anything similar.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not place cooking utensils or baking dishes on the glass door.
- Always ensure the crumb tray is properly inserted before use.

3. Parts and Features

Familiarize yourself with the components of your Complete Cuisine Toaster Oven:

1. **Temperature Control Dial:** Used to select the desired cooking temperature from 200°F to 465°F.
2. **Function Selector Dial:** Allows selection of Toast, Bake, or Broil modes.
3. **Timer Dial:** Sets cooking time up to 60 minutes with an audible bell. Includes a 'Stay-On' setting for longer cooking.
4. **Power Indicator Light:** Illuminates when the oven is operating.
5. **Glass Door:** Dropdown door for easy access to food.
6. **Cool-Touch Handle:** Designed for safe opening and closing of the oven door.
7. **Baking Pan:** Aluminized pan for baking.
8. **Chrome Toasting Rack:** For toasting bread and other items.
9. **Removable Crumb Tray:** Collects crumbs for easy cleaning.

Complete Cuisine

3 Cooking Modes

Toast, Bake & Broil



The toaster oven allows you to toast, bake, or broil a variety of meals. It includes different mode selections so you can use the upper grill, lower grill, or both. It also features an adjustable temperature range of 200°-465° for a customized cooking experience.

Material

Stainless Steel

Image: A close-up view of the toaster oven's control panel, showing the temperature dial, function selector, and timer dial. The three cooking modes (Toast, Bake, Broil) are indicated.



Image: This image highlights key design features including the cool-touch stainless-steel door handle, the 60-minute timer with auto-end bell and stay-on setting, and the included baking pan, rack, and crumb tray for easy cleaning.

4. Before First Use and Setup

Before using your toaster oven for the first time, please follow these steps:

- **Unpack:** Carefully remove the toaster oven and all accessories from its packaging. Remove any packing materials, stickers, or labels.
- **Clean:** Wash the baking pan, toasting rack, and crumb tray in warm, soapy water. Rinse and dry thoroughly. Wipe the interior and exterior of the oven with a damp cloth. Do not immerse the main unit in water.
- **Placement:** Place the toaster oven on a flat, stable, heat-resistant surface. Ensure there is at least 4 inches (10 cm) of clearance on all sides of the oven for proper ventilation. Do not place it directly under cabinets or near flammable materials.
- **Initial Burn-Off:** It is recommended to run the oven empty for about 10-15 minutes at the highest temperature setting (465°F) in the 'Bake' mode. This will help burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.
- **Insert Crumb Tray:** Always ensure the removable crumb tray is properly inserted at the bottom of the oven before use.

5. Operating Your Toaster Oven

This toaster oven offers three cooking functions: Toast, Bake, and Broil.

General Operation Steps:

1. Place the food on the baking pan or toasting rack.
2. Slide the baking pan or rack into the desired rack position inside the oven.
3. Close the glass door securely.
4. Turn the **Function Selector Dial** to the desired cooking mode (Toast, Bake, or Broil).
5. Turn the **Temperature Control Dial** to the desired temperature.
6. Turn the **Timer Dial** to the desired cooking time. The power indicator light will illuminate.
7. When the cooking time is complete, the timer will ring, and the oven will automatically turn off. If using the 'Stay-On' setting, you must manually turn the timer dial to 'OFF' to stop cooking.
8. Carefully remove the cooked food using oven mitts.

Specific Cooking Functions:

5.1. Toasting

- Place bread slices directly on the toasting rack. This oven can toast up to 4 slices.
- Set the **Function Selector Dial** to 'Toast'.
- Set the **Temperature Control Dial** to the 'Toast' setting (usually indicated on the dial).
- Turn the **Timer Dial** to the desired toast shade. For lighter toast, select a shorter time; for darker toast, select a longer time.
- The oven will turn off automatically when the timer rings.

5.2. Baking

- Place food (e.g., a 9-inch pizza, casseroles, cookies) on the baking pan.
- Set the **Function Selector Dial** to 'Bake'.
- Set the **Temperature Control Dial** to the desired baking temperature (range 200°F - 465°F).
- Turn the **Timer Dial** to the recommended baking time. For longer baking times, you can use the 'Stay-On' setting and monitor manually.
- The oven will turn off automatically when the timer rings.

5.3. Broiling

- Place food on the baking pan, ensuring it is positioned to allow for proper broiling.
- Set the **Function Selector Dial** to 'Broil'.
- Set the **Temperature Control Dial** to 'Broil' (usually the highest temperature setting).
- Turn the **Timer Dial** to the desired broiling time. Broiling often requires shorter times and close monitoring to prevent burning.
- The oven will turn off automatically when the timer rings.

Using the Timer:

The 60-minute timer features an audible bell to indicate the end of the cooking cycle. For continuous operation, turn the timer past the 60-minute mark to the 'Stay-On' position. When using 'Stay-On', you must manually turn the timer dial to 'OFF' to stop the heating elements.

6. Cleaning and Maintenance

Regular cleaning will help maintain the performance and longevity of your toaster oven.

- **Always unplug the oven** from the electrical outlet and allow it to cool completely before cleaning.

- **Crumb Tray:** Slide out the removable crumb tray from the bottom of the oven. Discard crumbs and wash the tray in warm, soapy water. Rinse and dry thoroughly before reinserting.
- **Baking Pan and Toasting Rack:** These accessories can be washed in warm, soapy water. For stubborn food residues, soak them before washing. Rinse and dry completely.
- **Interior:** Wipe the interior walls with a damp cloth and a mild liquid soap solution. Do not use abrasive cleaners or scouring pads, as they can damage the non-stick surfaces. Ensure the interior is dry before next use.
- **Exterior:** Wipe the exterior surface with a damp cloth. Do not use abrasive cleaners.
- **Glass Door:** Clean the glass door with a damp cloth and a non-abrasive cleaner.
- **Do not immerse the main unit** of the toaster oven in water or any other liquid.

7. Troubleshooting

If you encounter issues with your toaster oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outlet not working; timer not set.	Ensure the oven is securely plugged into a working electrical outlet. Turn the timer dial to the desired cooking time.
Food is not cooking evenly.	Incorrect rack position; uneven food placement; door not fully closed.	Adjust rack position for optimal cooking. Arrange food evenly on the pan/rack. Ensure the door is fully closed.
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal for initial use. Ensure good ventilation. It should dissipate after the first few uses.
Timer bell does not ring.	Timer dial not set correctly; 'Stay-On' mode selected.	Ensure the timer dial is set to a specific time, not 'Stay-On'. If in 'Stay-On' mode, the oven will not automatically turn off or ring.
Oven gets too hot on the exterior.	Normal operation for heating appliances.	Exterior surfaces will become hot during operation. Always use oven mitts and avoid touching hot surfaces. Ensure adequate clearance around the oven.

8. Specifications

- **Brand:** Complete Cuisine
- **Model Name:** CC-TOV4400
- **Capacity:** 9 Liters
- **Power Source:** Electric
- **Control Type:** Knob Control
- **Special Features:** 3 Cooking Modes (Toast, Bake, Broil), Dual Grill
- **Temperature Range:** 200°F - 465°F
- **Timer:** 60-minute with bell and 'Stay-On' function
- **Number of Shelves:** 1
- **Door Style:** Dropdown Door
- **Finish Type:** Painted
- **UPC:** 079902184774

9. Warranty and Customer Support

For warranty information or if you have any questions or concerns regarding your Complete Cuisine 4-Slice Toaster Oven, please

contact our customer support. Refer to the product packaging or the retailer's website for specific contact details and warranty terms.
Please have your model number (CC-TOV4400) and purchase information ready when contacting support.

© 2024 Complete Cuisine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question