Nasitip Sur3xYellow2388YC1829i

Nasitip 24V Kids Ride On Car Toy Instruction Manual - Model Sur3x2388YC1829i

This manual provides essential information for the safe assembly, operation, and maintenance of your Nasitip 24V Kids Ride On Car Toy. Please read thoroughly before use.

1. Safety Information

- Adult supervision is required at all times.
- Recommended age: 3-8 years.
- Maximum load capacity: 200 lbs (90 kg).
- Ensure all components are securely fastened before each use.
- Do not operate near stairs, steep inclines, roads, or water.
- Always use the provided charger.
- Do not modify the electrical system.
- Wear appropriate safety gear, such as a helmet.

2. What's in the Box

The package includes the following components:

- Kids ride on vehicle toy
- Remote control
- Wheels (4)
- Axles and steering components
- Charger
- Assembly hardware (screws, washers, nuts)
- Instruction Manual (this document)



Image: The Nasitip 24V Kids Ride On Car Toy in yellow, with its remote control.

3. Assembly Instructions

Follow these steps to assemble your ride-on car. Adult assembly is required.

1. **Prepare Components**: Unpack all parts and verify against the parts list. Remove any packaging ties.
2. **Install Front Axle**: Attach the front axle assembly to the underside of the car chassis using the provided screws and nuts. Ensure all connections are secure.

Video: This video demonstrates the assembly process for the Kids Ride on Car, including attaching axles and wheels.

3. **Attach Front Wheels**: Slide a washer onto the front axle, then attach a front wheel. Secure it with another washer and a nut. Repeat for the other front wheel. Attach the decorative wheel covers.
4. **Install Rear Axle and Wheels**: Attach the rear axle assembly to the chassis. Connect the motor wires if not pre-connected. Slide a washer onto the rear axle, then attach a rear wheel. Secure it with another washer and a nut. Repeat for the other rear wheel. Attach the decorative wheel covers.
5. **Install Foot Pedals**: Secure the foot pedals to the designated slots on the side of the car using the provided screws. Ensure the wiring is connected correctly.
6. **Install Steering Wheel**: Connect the steering wheel wiring to the car's main body. Insert the steering column into its slot and secure it with the provided screw.
7. **Connect Battery**: Locate the battery compartment (under the seat). Connect the battery terminals (red to red, black to black).
8. **Install Seat**: Place the seat onto the car and secure it with the provided screws. Ensure the seat belt is accessible.
9. **Final Checks**: Verify all screws are tightened and all connections are secure.

4. Operating Instructions

4.1. Powering On/Off

Press the red power button on the dashboard to turn the car on or off.

4.2. Driving Modes

The car features three driving modes:

- **Child-Controlled Driving**: The child operates the car using the steering wheel and foot pedal.
- **Parental Control (Rear Seat Pedal)**: An adult can control the car's speed using the rear foot pedal.
- **Remote Control**: Parents can override child control and operate the car using the included remote control.

4.3. Speed Control

Use the high/low speed control buttons on the dashboard to adjust the speed. The maximum speed is 4 MPH.

4.4. Music and Entertainment

The car comes with pre-installed music. Additional music can be played by connecting an external device (e.g., via USB or Bluetooth, if available).



Image: Close-up of the car's dashboard, highlighting the power button, speed controls, and music interface.

4.5. Remote Control Operation

The remote control allows parents to steer, accelerate, and brake the vehicle. It also features a "P" (parking/emergency brake) button for immediate stopping.



Image: An adult and child riding the Nasitip 24V Kids Ride On Car Toy, illustrating the two-seater design and parental supervision.

5. Charging and Maintenance

5.1. Charging the Battery

- Connect the charger to the charging port on the car.
- Plug the charger into a standard wall outlet.
- Charging time: 8-12 hours. Do not overcharge.
- Disconnect the charger once charging is complete.

5.2. General Maintenance

- Regularly inspect the car for loose screws, damaged parts, or worn tires.
- Clean the car with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Avoid exposing the car to rain or excessive moisture.
- Store the car in a dry, covered area when not in use.

6. Troubleshooting

6.1. Car Does Not Move

- Check if the battery is charged.
- Ensure all electrical connections are secure.
- Verify the power button is on.
- If using remote control, ensure it is paired and has fresh batteries.

6.2. Reduced Power or Speed

- The battery may be low; recharge it fully.
- The car may be overloaded; ensure it is within the 200 lbs weight limit.

6.3. Remote Control Not Working

- Replace the batteries in the remote control.
- Ensure the remote control is properly paired with the car (refer to pairing instructions in the full manual, if provided separately).

7. Specifications

Feature	Specification
Product Dimensions	39.37 x 22.83 x 11.02 inches
Item Weight	46.5 pounds
Item Model Number	Sur3xYellow2388YC1829i
Manufacturer Recommended Age	3 - 8 years
Battery	24V 7Ah
Motors	2 x 120W
Maximum Load	200 lbs (90 kg)
Maximum Speed	4 MPH



Image: Key specifications of the ride-on car, including battery, speed, charging time, playing time, age, and load capacity.

8. Warranty and Support

For warranty information, technical support, or replacement parts, please contact Nasitip customer service. Refer to the product packaging or the official Nasitip website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question