Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee airfryer kitchen appliances

TOPZEE 2.1 Quart Air Fryer User Manual

Model: airfryer kitchen appliances

1. Introduction

Thank you for choosing the TOPZEE 2.1 Quart Air Fryer. This compact and efficient appliance is designed to provide a healthier alternative to traditional frying, allowing you to cook a variety of foods with little to no oil. Its 1000-watt heating system ensures quick and even cooking, making it a valuable addition to any kitchen.
Key features include:

- Compact 2.1-quart capacity, ideal for 1-2 people.
- 1000 watts of 360-degree heating for rapid cooking without preheating.
- Intuitive digital touchscreen controls for ease of use.
- Designed for oil-free cooking, promoting healthier meals.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance's interior and basket are made of Acrylonitrile Butadiene Styrene (ABS) and other heat-resistant materials. While designed for cooking temperatures, avoid exposing the appliance to temperatures exceeding 400°F (204°C) for prolonged periods, as ABS can begin to decompose at higher temperatures.
- Do not use attachments not recommended by the appliance manufacturer, as this may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Product Overview



Image: The TOPZEE 2.1 Quart Air Fryer, featuring a sleek black and gold design with a pull-out basket and digital control panel on top.

Components:

1. Main Unit with Digital Touchscreen Control Panel
2. Removable Frying Basket
3. Basket Handle
4. Air Inlet (top)
5. Air Outlet (rear)
6. Power Cord

4. Setup and First Use

Unpacking:

- Carefully remove all packaging materials from the air fryer.
- Check that all components listed in the 'Product Overview' section are present and undamaged.

Before First Use:

- Clean the frying basket and any removable parts with warm soapy water. Rinse thoroughly and dry completely.
- Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.

5. Operating Instructions

Getting Started:

1. Plug the air fryer into a grounded electrical outlet. The digital display will illuminate.
2. Pull out the frying basket using the handle.
3. Place your food inside the basket. Do not overfill the basket to ensure even cooking.
4. Slide the frying basket back into the main unit until it clicks into place.

Using the Digital Touchscreen Control:

The air fryer features a digital touchscreen for setting time and temperature. While the interface is designed for ease of use, familiarizing yourself with its functions is recommended.

- **Power Button:** Press to turn the unit on/off or to start/pause cooking.
- **Temperature Control:** Use the temperature icons (e.g., up/down arrows or specific temperature presets) to adjust the cooking temperature. The range is typically from 180°F to 400°F.
- **Time Control:** Use the time icons (e.g., up/down arrows) to set the cooking duration. The timer can usually be set from 1 to 60 minutes.
- **Preset Functions:** Some models may have preset icons for common foods (e.g., fries, chicken, fish). Pressing

these will automatically set a recommended time and temperature.

Cooking Process:

1. After placing food in the basket and closing it, select your desired temperature and time using the touchscreen controls.
2. Press the Power button to start cooking. The air fryer does not require preheating, allowing for faster cooking times compared to traditional ovens.
3. During cooking, you may pull out the basket to shake or flip food for even browning. The air fryer will pause automatically and resume when the basket is reinserted.
4. Once the timer reaches zero, the air fryer will beep, indicating that cooking is complete.
5. Carefully pull out the basket and empty the cooked food onto a plate. Use heat-resistant utensils.

For specific recipes and cooking guidelines, refer to the specially designed cooking manual provided with your TOPZEE Air Fryer.

6. Maintenance and Cleaning

Regular cleaning of your air fryer will ensure optimal performance and extend its lifespan.

Cleaning the Frying Basket:

- After each use, allow the air fryer to cool completely before cleaning.
- Remove the frying basket. The bottom of the basket can be easily lifted out for separate cleaning, which is convenient for removing debris.
- Wash the basket and its removable bottom with warm water and a mild dish soap. Use a non-abrasive sponge to prevent scratching the non-stick surface.
- *Note: The frying basket is not dishwasher safe. Hand washing is recommended.*
- Rinse thoroughly and dry completely before storing or next use.

Cleaning the Main Unit:

- Wipe the exterior of the air fryer with a soft, damp cloth.
- Clean the interior of the appliance with a damp cloth and mild detergent if necessary. Ensure no water enters the electrical components.
- Never immerse the main unit in water or any other liquid.

Storage:

- Ensure the air fryer is clean and dry before storing.
- Store the appliance in a cool, dry place.

7. Troubleshooting

If you encounter issues with your TOPZEE Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the basket firmly into the unit until it clicks.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped during cooking; incorrect temperature/time.	Do not overfill the basket. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the basket thoroughly after each use. For fatty foods, a small amount of smoke is normal.
Digital controls are laggy or confusing.	User unfamiliarity with interface; temporary software glitch.	Refer to the 'Operating Instructions' section for detailed guidance. Unplug the unit for a few minutes and plug it back in to reset. Ensure hands are clean and dry when using the touchscreen.

8. Specifications

Feature	Specification
Brand	topzee
Model Name	airfryer kitchen appliances
Capacity	2.1 Quarts
Output Wattage	1000 Watts
Voltage	110 Volts (AC)
Control Method	Touch
Product Dimensions (D x W x H)	10.39"D x 10.89"W x 8.49"H
Color	Black + Gold
Material (Outer)	Polypropylene
Material (Inner)	Heat-resistant material (Acrylonitrile Butadiene Styrene (ABS))
Item Weight	5.89 pounds
Dishwasher Safe	No

9. Warranty and Support

For any questions, concerns, or support needs regarding your TOPZEE Air Fryer, please contact the seller or refer to the official TOPZEE brand store on Amazon for further assistance. Keep your purchase receipt for warranty purposes, if applicable.
Visit the TOPZEE Store on Amazon for more information.

© 2024 TOPZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2XMYK12

More documents and user manuals: **https://manuals.plus/**