ALLIMITY CASPER-1-NY

Allimity Voice Replaced Remote Control RC860 User Manual

Model: CASPER-1-NY

Introduction

This manual provides comprehensive instructions for the Allimity Voice Replaced Remote Control RC860. This remote is designed as a direct replacement for specific Casper/JVC Smart TV models, including **55UG6300** and **55UG6100**. It offers convenient control over your television without the need for complex setup or programming.

Product Overview

Familiarize yourself with the components and layout of your new remote control.





Figure 1: Front View of the Remote Control
This image displays the front of the Allimity RC860 remote control, highlighting its button layout including power, navigation, volume, channel, and dedicated app buttons for Netflix and YouTube, along with a microphone button for voice commands.



Figure 2: Back View with Battery Compartment
This image shows the rear of the remote control with the battery compartment cover removed, revealing the slots for two AAA alkaline batteries. This is where batteries are inserted or replaced.



Figure 3: Remote Control Dimensions
This image illustrates the approximate dimensions of the remote control, showing a length of 15.6 cm (6.14 inches) and a width of 4 cm (1.57 inches), providing a clear understanding of its physical size.

Setup

The Allimity RC860 remote control is designed for immediate use with compatible TV models without any complex programming.

1. Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) new **AAA Alkaline Batteries** into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: *Batteries are not included with the remote control and must be purchased separately.*

2. Initial Use

Once batteries are installed, the remote control is ready to operate your compatible Casper/JVC Smart TV. No additional setup or programming is required.

Operating Instructions

Point the remote control directly at your television's infrared receiver for optimal performance. The remote can be used effectively within a range of approximately 30 feet (9 meters).

Key Functions:

- **Power Button ():** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus, select options, and confirm choices.
- **Back Button ():** Returns to the previous screen or menu.
- **Home Button ():** Accesses the TV's home screen or smart hub.
- **Volume Up/Down ():** Adjusts the television's volume.
- **Mute Button ():** Mutes or unmutes the TV audio.
- **Channel Up/Down:** Changes TV channels.
- **Netflix Button:** Direct access to the Netflix application.
- **YouTube Button:** Direct access to the YouTube application.
- **Voice Control Button ():** Activates the voice control feature for compatible Smart TVs. Press and hold the button, speak your command, then release.

Note: *The functionality of specific buttons (e.g., voice control, dedicated app buttons) may depend on your TV model's features and internet connectivity.*

Maintenance

Proper care will ensure the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA Alkaline Batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

If you encounter issues with your remote control, try the following solutions:

Problem	Possible Cause / Solution
Remote is not responding.	• **Batteries:** Check if batteries are inserted correctly. Replace with new AAA Alkaline Batteries. • **Line of Sight:** Ensure there are no obstructions between the remote and the TV's infrared sensor. • **Distance:** Make sure you are within the effective operating range (approx. 30 feet).

Problem	Possible Cause / Solution
Voice control is not working.	• **TV Compatibility:** Verify your TV model supports voice control. • **Internet Connection:** Ensure your Smart TV is connected to the internet. • **Microphone:** Speak clearly and directly into the remote's microphone. • **Button Press:** Ensure you are pressing and holding the voice control button while speaking.
Specific buttons (e.g., Netflix, YouTube) are not working.	• **App Installation:** Ensure the respective app is installed and updated on your Smart TV. • **Internet Connection:** These apps require an active internet connection.

Specifications

Feature	Detail
Model Number	CASPER-1-NY (RC860)
Compatible TV Models	Casper/JVC Smart TV 55UG6300, 55UG6100
Dimensions (L x W x H)	5 x 1.5 x 0.5 inches (approx. 12.7 x 3.8 x 1.3 cm)
Item Weight	2.12 ounces (approx. 60 grams)
Material	ABS
Battery Type	2 x AAA Alkaline Batteries (not included)
Operating Range	Up to 30 feet (approx. 9 meters)
Special Feature	Voice Control, Ergonomic Design

Warranty and Support

For any questions, concerns, or technical assistance regarding your Allimity Voice Replaced Remote Control RC860, please refer to the seller's support channels or the platform where the product was purchased. Specific warranty information may be provided by the seller at the time of purchase.
Please retain your proof of purchase for any warranty claims.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question