Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee small air fryer

TOPZEE 2.1 Quarts Air Fryer User Manual

Model: small air fryer

Introduction

This TOPZEE 2.1 Quarts Air Fryer is designed to provide a healthier alternative to traditional frying, allowing you to prepare a variety of delicious meals with significantly less oil. Its compact and lightweight design makes it an ideal appliance for single servings or small families, offering convenient storage and portability. With its efficient heating system, you can quickly cook frozen ingredients to crispy perfection.

Please read this manual thoroughly before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

Familiarize yourself with the components of your TOPZEE Air Fryer:

- **Main Unit:** The primary housing containing the heating element and fan.
- **Control Panel:** Digital display with touch controls for temperature and time settings.
- **Frying Basket:** Non-stick basket for holding food during cooking.
- **Basket Handle:** For safely inserting and removing the frying basket.
- **Air Inlet:** Located at the top of the unit.
- **Air Outlet Vents:** Located at the back of the unit for hot air exhaust.



Figure 1: Front view of the TOPZEE 2.1 Quarts Air Fryer, highlighting its sleek design and digital control panel.



Figure 2: The air fryer positioned on a kitchen countertop, illustrating its compact and space-saving design.

Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Before first use, clean the frying basket and any removable parts with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 4 inches of space around the unit.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Basic Operation

1. **Prepare Food:** Place your desired food items into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks securely into place.
3. **Power On:** The digital display will illuminate.
4. **Set Temperature:** Use the temperature control buttons (usually indicated by +/- or specific icons) to set the desired cooking temperature (up to 400°F).
5. **Set Time:** Use the timer control buttons to set the desired cooking time.
6. **Start Cooking:** Press the start button to begin the air frying process. The air fryer will automatically begin heating.
7. **Shake Basket (Optional):** For some foods, it is recommended to shake the basket halfway through the cooking time to ensure even crisping. Carefully pull out the basket, shake, and reinsert. The air fryer will pause and resume cooking once the basket is reinserted.
8. **Completion:** Once the timer reaches zero, the air fryer will beep, indicating that cooking is complete.

9. **Remove Food:** Carefully pull out the basket using the handle. Use tongs to remove cooked food from the basket.

Preheating

This air fryer does not require preheating for most foods. You can directly cook frozen ingredients. However, for certain recipes or desired crispiness, you may preheat the unit by running it empty for 3-5 minutes at the desired temperature before adding food.

Cooking Guide

The following table provides general guidelines for common food items. Cooking times and temperatures may vary based on food quantity, thickness, and desired crispiness. A basic cooking manual with recipes is included with your product for more detailed instructions.

Food Item	Temperature (°F)	Time (Minutes)	Notes
Frozen Fries (thin)	380	15-20	Shake halfway
Chicken Wings	375	20-25	Flip halfway
Fish Fillets	350	12-18	Lightly oil
Vegetables (broccoli, bell peppers)	370	10-15	Toss with a little oil

Maintenance and Cleaning

Regular cleaning will extend the life of your air fryer and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Basket:** The non-stick frying basket is dishwasher safe. Alternatively, wash it with warm water, a mild detergent, and a non-abrasive sponge.
3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the basket firmly until it clicks into place.
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake or flip food items halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty food.	Clean the basket and interior thoroughly after each use. For fatty foods, consider using parchment paper or draining excess fat.

Problem	Possible Cause	Solution
Food is not crispy.	Insufficient cooking time/temperature; too much moisture.	Increase cooking time or temperature. Pat food dry before air frying. Lightly coat with oil for extra crispiness.

Specifications

- **Brand:** TOPZEE
- **Model Name:** small air fryer
- **Capacity:** 2.1 Quarts
- **Output Wattage:** 1000 Watts
- **Voltage:** 100 Volts
- **Max Temperature Setting:** 400°F (200°C)
- **Control Method:** Touch
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Product Dimensions:** 10.39"D x 10.91"W x 8.5"H
- **Item Weight:** 5.99 pounds
- **Non-stick Coating:** Yes
- **Dishwasher Safe Parts:** Basket

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact TOPZEE customer service through the retailer where the product was purchased. Please have your model number and purchase date available when contacting support.

For additional resources and frequently asked questions, visit the official TOPZEE store on Amazon:TOPZEE Store

© 2024 TOPZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2XPXPRD

More documents and user manuals: **https://manuals.plus/**