Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee K- AFT11001-UL

topzee 11-QT Large Air Fryer User Manual

Model: K-AFT11001-UL

Introduction

Thank you for choosing the topzee 11-QT Large Air Fryer. This appliance is designed to provide a healthier way to cook your favorite meals, utilizing rapid air circulation technology for crispy results with significantly less oil. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new air fryer. Please read it thoroughly before first use and retain it for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the basket is properly inserted and locked before operation.
- A short power-supply cord is provided to reduce the risk resulting from entanglement or tripping over a longer cord.
- Do not block any ventilation openings.

Product Overview

Components

- Main Air Fryer Unit with Digital Touch Control Panel
- 11-QT Cooking Basket
- Removable Basket Divider
- Nonstick Crisper Plates (2)

Key Features

- **Flexible Basket Design:** Easily switch between a single 11-QT basket for large meals or two 5.5-QT baskets using the removable divider for cooking different dishes simultaneously.
- **8-in-1 Cooking Functions:** Includes Air Fry, Roast, Broil, Bake, Reheat, Dehydrate, Keep Warm, and French Fries presets.
- **Sync Food Finish Function:** Allows two different dishes to finish cooking at the same time, even with different settings.
- **Dual Cook Function:** Synchronizes both cooking baskets to use the same temperature and time settings for double the food.
- **Wide Temperature Range:** Adjustable from 90°F to 400°F for precise cooking control.
- **Easy to Clean:** Non-stick, dishwasher-safe baskets, trays, and divider.



Figure 1: The topzee 11-QT Large Air Fryer, showcasing its dual basket configuration with the divider in place, cooking chicken and broccoli

simultaneously.

Setup

1. **Unpacking:** Carefully remove all packaging materials and any promotional labels from the air fryer.
2. **Cleaning:** Before first use, wash the basket, divider, and crisper plates thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry all parts completely. Wipe the interior and exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 6 inches of clear space on all sides and above the unit.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor may be present, which is normal and will dissipate.

Operating Instructions

General Operation

The air fryer features a digital touch control panel for easy selection of cooking functions, temperature, and time.



Figure 2: The digital touch control panel, illustrating the various cooking modes and settings available.

- **Power On/Off:** Press the power icon to turn the unit on or off.
- **Preheat:** Most functions include a preheat phase. Allow the unit to preheat for optimal results.
- **Temperature Adjustment:** Use the temperature controls (up/down arrows) to set the desired cooking temperature.
- **Time Adjustment:** Use the time controls (up/down arrows) to set the desired cooking duration.
- **Shake Reminder:** For certain foods, the air fryer may beep to remind you to shake or flip the contents of the basket for even cooking.

8-in-1 Cooking Functions

Select one of the preset functions for optimized cooking settings:

- **Air Fry:** Ideal for achieving crispy textures with minimal oil.
- **Roast:** Perfect for meats and vegetables, providing a tender interior and browned exterior.
- **Broil:** For quick browning and melting.

- **Bake:** Suitable for cakes, pastries, and other baked goods.
- **Reheat:** Warms up leftovers efficiently.
- **Dehydrate:** For making dried fruits, vegetables, or jerky.
- **Keep Warm:** Maintains food at a serving temperature after cooking.
- **French Fries:** Optimized setting for perfectly crispy French fries.

Flexible Basket Configuration

The air fryer offers versatile cooking options with its basket design:

- **Single 11-QT Basket Mode:** For large items like a whole chicken or family-sized meals, remove the basket divider to utilize the full 11-quart capacity.
- **Dual 5.5-QT Baskets Mode:** Insert the divider to create two separate 5.5-quart compartments, allowing you to cook two different dishes simultaneously.



Figure 3: The air fryer configured for 11-QT cooking mode, ideal for larger items like a whole chicken.



Figure 4: The air fryer in Dual Cook mode, utilizing two 5.5-QT baskets for simultaneous preparation of different foods.

Sync Food Finish Function

This feature allows you to cook two different foods with different settings (temperature and time) and have them complete cooking at the same moment. This ensures both dishes are hot and ready to serve together.

- Place food in both baskets.
- Set desired temperature and time for each basket independently.
- Activate the "Sync Food Finish" function (refer to control panel icons). The air fryer will automatically adjust the cooking start times for each basket to ensure simultaneous completion.



Figure 5: The Sync Food Finish function in action, allowing different foods to cook simultaneously and finish at the same time.

Dual Cook Function

Use this function to cook the same type of food in both baskets using identical temperature and time settings. This is ideal for preparing larger quantities of a single dish.

- Place the same food type in both baskets.
- Set the desired temperature and time for one basket.
- Activate the "Dual Cook" function (refer to control panel icons). The settings will be mirrored to the second basket.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your air fryer.

1. **Before Cleaning:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.

2. **Basket, Divider, and Crisper Plates:** These parts are non-stick and dishwasher-safe. For manual cleaning, wash them in hot, soapy water using a non-abrasive sponge. For stubborn food residue, soak the parts in warm water for about 10 minutes before cleaning.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid. Clean the interior with a damp cloth and mild detergent if necessary, ensuring no water enters the electrical components.
4. **Heating Element:** If necessary, gently clean the heating element with a cleaning brush to remove any food residue. Do not use abrasive materials.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Overcrowding the basket; not shaking/flipping food.	Do not overcrowd the basket. Cook in smaller batches if necessary. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the basket and crisper plate thoroughly after each use. For high-fat foods, place a piece of aluminum foil at the bottom of the basket to catch excess grease.
Food is not crispy.	Too much moisture; not enough oil (for certain foods); incorrect temperature/time.	Pat food dry before air frying. Lightly toss with oil for crispier results. Adjust temperature and time according to recipe or food type.
Basket does not slide in properly.	Basket or crisper plate not correctly positioned.	Ensure the crisper plate is flat at the bottom of the basket and the basket is aligned correctly with the main unit.

Specifications

Feature	Detail
Model Name	K-AFT11001-UL
Capacity	11 Quarts (single) / 2 x 5.5 Quarts (with divider)
Product Dimensions (D x W x H)	15.7"D x 15.4"W x 12"H
Item Weight	21.8 pounds
Color	Black
Material	Metal, Plastic (Inner Material: Plastic)
Output Wattage	1700 Watts
Voltage	120 Volts

Feature	Detail
Temperature Range	90°F - 400°F (Min: 95°F, Max: 400°F)
Control Method	Touch
Dishwasher Safe Parts	Yes (Baskets, trays, divider)
Special Features	11-QT large capacity, Switch to two 5.5-qt basket with divider, Temperature Control, Automatic Shut-Off, Programmable

Warranty and Support

The topzee 11-QT Large Air Fryer is designed for durability and performance. For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official topzee website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may also contact customer service through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D31SL5DV

More documents and user manuals: **https://manuals.plus/**