Baby Born 834145

BABY born Deluxe Pram Instruction Manual

Model: 834145

Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your BABY born Deluxe Pram. Please read this manual thoroughly before use to ensure safe and correct handling of the product. This pram is designed for BABY born dolls and other dolls up to 43cm in height.

Safety Information

- **Recommended Age:** Suitable for children aged 3 years and up.
- **Adult Supervision:** Adult supervision is recommended during assembly and initial use.
- **Choking Hazard:** Keep small parts away from young children during assembly.
- **Intended Use:** This product is a toy pram for dolls. It is not intended for carrying real infants, children, or pets.
- **Stability:** Ensure the pram is stable on flat surfaces before placing a doll inside.
- **Moving Parts:** Be aware of moving parts during folding and unfolding to prevent pinching.

What's in the Box

The BABY born Deluxe Pram package includes:

- BABY born Deluxe Pram frame and components
- Pram body/seat unit
- Canopy
- Storage basket
- Wheels

Note: Doll is not included with the pram.

Setup and Assembly

Follow these steps to assemble your BABY born Deluxe Pram:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in "What's in the Box" are present.
2. **Attach Wheels:** Securely attach the wheels to the pram frame. Ensure they click into place or are fastened according to the specific design.
3. **Assemble Frame:** Unfold the pram frame until it locks into its open position.
4. **Install Pram Body/Seat Unit:** Attach the main pram body or seat unit to the frame. This unit can be configured as a classic pram or a sporty jogger.
5. **Attach Canopy:** Secure the folding canopy to the pram body.
6. **Install Storage Basket:** Attach the storage basket to the lower part of the pram frame.



Image 1: The BABY born Deluxe Pram in its classic pram configuration, showing the main body, canopy, handle, and storage basket.



Image 2: The BABY born Deluxe Pram converted into a sporty jogger, featuring a more upright seat and a streamlined appearance.

Operating Instructions

- **Converting from Pram to Jogger:** The pram can be converted to a sporty jogger. Refer to the specific mechanisms on your pram for transforming the seat unit. This typically involves adjusting the backrest and footrest positions.
- **Adjusting Handle Height:** The handle height is adjustable from 46cm to 77cm to accommodate different users. Locate the adjustment buttons or levers on the handle and set it to a comfortable height.
- **Folding Canopy:** The canopy can be folded up or down to provide sun protection for the doll. Gently push or pull the canopy to adjust its position.
- **Using Storage Space:** The pram includes a storage basket located beneath the main doll compartment. This is suitable for carrying doll accessories or small items.
- **Folding for Storage:** The pram can be folded down for easy storage. Locate the folding mechanisms (usually latches or buttons on the frame) and follow the instructions to collapse the pram.



Image 3: A child pushing the BABY born Deluxe Pram with a doll securely placed inside, demonstrating typical use.



Image 4: A child reaching into the storage basket of the pram, illustrating its use for carrying doll accessories.



Image 5: A child adjusting the folding canopy of the pram, demonstrating how to provide shade for the doll.



Image 6: The BABY born Deluxe Pram in its folded state, ready for compact storage.

Maintenance

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap if necessary. Do not immerse the pram in water.
- **Storage:** Store the pram in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check all parts for wear and tear, especially wheels and folding mechanisms. Discontinue use if any part is damaged.

Troubleshooting

Pram does not fold correctly:
Ensure all locking mechanisms are disengaged before attempting to fold. Check for any obstructions.

Wheels are stiff or squeaky:
Check for debris caught in the wheels. A small amount of silicone-based lubricant can be applied to the wheel axles if necessary.

Pram feels unstable:
Verify that all assembly steps have been completed correctly and that all connections are secure. Ensure the pram is used on a flat, even surface.

Specifications

Model Number:	834145

Product Dimensions:	7.87 x 7.87 x 7.87 inches
Item Weight:	7.3 pounds
Recommended Age:	3 years and up
Compatible Doll Size:	Up to 43cm
Adjustable Handle Height:	46-77cm
Material:	Plastic (Note: "100% Plastic Free Packaging" refers to product packaging, not product material.)

Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official Baby Born website. Keep your proof of purchase for any warranty claims.
Manufacturer: BABY born

© 2025 BABY born. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question