VGR V-003

VGR V-003 Professional Salon Series Hair Clipper User Manual

Model: V-003 | Brand: VGR

Product Overview

The VGR V-003 Professional Salon Series Hair Clipper is designed for precise and efficient hair grooming. It features a powerful 9000 RPM motor, ceramic and powder metallurgic blades for sharpness and durability, and a digital display for monitoring battery life and speed settings. This clipper offers both corded and cordless operation, powered by a 2500mAh lithium battery providing up to 250 minutes of runtime. It includes 6 guide combs for versatile cutting lengths.



Image: The VGR V-003 Hair Clipper displayed with its complete set of accessories, including various guide combs, lubricating oil, a cleaning brush, and the USB charging cable.

Important Safety Instructions

- Do not use this appliance on wet skin or near water sources, including bathtubs, showers, basins, or other vessels containing water.
- Keep the appliance out of reach of children.
- Clean the clipper as recommended by the manufacturer to prevent skin irritation and maintain hygiene.
- Ensure the appliance is fully charged before first use to optimize battery life.
- Only use the provided charging cable and adapter (if applicable) to charge the device.

Setup and Initial Use

Charging the Clipper

Before first use, fully charge the VGR V-003 hair clipper. Connect the USB charging cable to the clipper's charging port and plug the other end into a suitable USB power source (e.g., computer, USB wall adapter). The digital display will indicate the charging status. A full charge takes approximately 3 hours and provides up to 250 minutes of cordless operation.



Image: The VGR V-003 Hair Clipper connected via its USB charging cable, illustrating the 3-hour charge time and 250-minute work time.

Attaching Guide Combs

The VGR V-003 comes with 6 guide combs (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm) to achieve various cutting lengths. To attach a guide comb, align the comb with the clipper blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.



Image: A close-up view of the VGR V-003 Hair Clipper demonstrating how a guide comb is attached and adjusted for cutting length.

Operating Your Hair Clipper

Powering On/Off and Turbo Mode

To turn the clipper on, slide the power switch upwards. To turn it off, slide the switch downwards. The VGR V-003 features a Turbo Mode for enhanced cutting power, especially useful for thicker hair. Activate Turbo Mode by pressing the power switch further upwards beyond the 'on' position, or as indicated by the specific switch design.



Image: A detailed view of the VGR V-003 Hair Clipper's on/off switch, highlighting its integrated Turbo mode functionality.

Adjusting Cutting Length

In addition to the guide combs, the VGR V-003 features an adjustable taper lever on the side of the clipper. This lever allows for fine-tuning of the cutting length between 0.5mm and 2.5mm without a guide comb, or to blend hair seamlessly when using guide combs. Move the lever up or down to adjust the blade position.



Image: The VGR V-003 Hair Clipper illustrating the adjustable taper lever for precise cutting length control and the LED display indicating power status.

Digital Display

The integrated digital display provides real-time information on the clipper's battery life and current speed setting. This allows for precise control and ensures you are aware of the remaining power during your grooming session.



Image: The VGR V-003 Hair Clipper showcasing its digital display, which provides real-time updates on battery life and speed settings, emphasizing its powerful 9000 RPM motor.

Care and Maintenance

Cleaning the Blades

After each use, turn off the clipper and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blades and the clipper head. For a more thorough cleaning, the blades can be rinsed under running water, ensuring the clipper body remains dry. Allow blades to air dry completely before reattaching or storing.

Blade Lubrication

To maintain optimal cutting performance and blade longevity, apply a few drops of the included lubricating oil to the blades after every few uses, or as needed. Turn the clipper on for a few seconds to distribute the oil evenly. Wipe off any excess oil with a soft cloth.

Storage

Store the clipper in a cool, dry place, away from direct sunlight and moisture. Ensure the clipper is clean and dry before storing. Keep all accessories, such as guide combs and the charging cable, together with the clipper.

Troubleshooting Guide

Issue	Possible Cause	Solution
Clipper not turning on.	Low battery; Power switch not fully engaged.	Charge the clipper fully; Ensure the power switch is pushed completely to the 'on' position.
Poor cutting performance or pulling hair.	Blades are dull, dirty, or not lubricated; Guide comb not properly attached.	Clean the blades thoroughly; Apply lubricating oil to the blades; Ensure the guide comb is securely attached.
Clipper making unusual noise.	Blades require lubrication; Debris caught in blades.	Lubricate the blades; Clean blades to remove any trapped hair or debris.
Battery not holding charge.	Improper charging; Battery degradation over time.	Ensure proper connection to charger; If issue persists, contact customer support for warranty service.

Product Specifications

Model Number	V-003
Brand	VGR
Blade Material	Ceramic & Powder Metallurgic Blades
Motor Speed	Up to 9000 RPM
Battery Type	2500mAh Lithium Ion
Runtime	Up to 250 minutes
Charge Time	Approximately 3 hours
Guide Combs	6 (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
Adjustable Taper Lever	0.5mm - 2.5mm
Power Source	Battery Powered (Corded/Cordless operation)
Dimensions	18 x 5 x 4 cm
Weight	335 g

Warranty Information

The VGR V-003 Professional Salon Series Hair Clipper is backed by a **one-year warranty** from the date of purchase.

This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For detailed warranty terms and conditions, please refer to the official VGR website or contact their customer support.

Customer Support

Should you encounter any issues not covered in this manual, or require further assistance, please contact VGR customer support. Refer to the product packaging or the official VGR website for the most up-to-date contact information.

When contacting support, please have your product model number (V-003) and proof of purchase readily available.

© 2024 VGR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question