Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CV-2677-FS21HS-L-SH

FS21HS-L Replaced Remote Control User Manual

Model: CV-2677-FS21HS-L-SH

Brand: ALLIMITY

Introduction

This manual provides instructions for the ALLIMITY FS21HS-L Replaced Remote Control, designed for compatibility with VIMA S4 2.1 FS21HS-L TV Sound Bar Soundbar Audio Speaker Systems. This remote serves as a direct replacement for your original or broken unit, requiring no complex setup or programming.



Image: The ALLIMITY FS21HS-L Replacement Remote Control, showcasing its sleek black design and button layout.

Setup

Battery Installation

The FS21HS-L remote control requires two (2) 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.







Image: The rear view of the remote control with the battery cover removed, showing the battery compartment for two AAA batteries.

Once batteries are installed, the remote control is ready for use with compatible VIMA S4 2.1 FS21HS-L TV Sound Bar systems without any additional setup or programming.

Operating Instructions

This remote control provides full functionality for your VIMA S4 2.1 FS21HS-L TV Sound Bar. Below is a guide to the primary buttons and their functions:





Image: A clear front view of the FS21HS-L remote control, highlighting the layout of its various control buttons.

- **Power Button** (●): Turns the sound bar on or off.
- **Mute Button** (●): Mutes or unmutes the sound.
- **PAIR**: Initiates pairing mode for Bluetooth or other wireless connections.
- **INPUT**: Cycles through available audio input sources (e.g., Optical, AUX, Bluetooth).
- **LUM**: Adjusts the display brightness or LED indicators on the sound bar.
- **RESET**: Resets sound settings or the sound bar to default configurations.
- **Volume Up (VOL+)** / **Volume Down (VOL-)**: Increases or decreases the master volume.
- **Playback Controls** (Play/Pause, Previous Track, Next Track): Used for media playback when connected via Bluetooth or USB.
- **-10** / **+10**: Jumps backward or forward by 10 units (e.g., for track skipping or specific adjustments).
- **TREBLE-** / **TREBLE+**: Adjusts the treble level of the audio output.
- **BASS-** / **BASS+**: Adjusts the bass level of the audio output.
- **Sound Modes** (MUSIC, NEWS, MOVIE, 3D): Selects pre-set equalizer modes optimized for different audio content.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries promptly when the remote's responsiveness decreases or it stops

functioning. Always use new alkaline batteries of the specified type (AAA). Do not mix old and new batteries, or different types of batteries.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage internal components or the casing.

Troubleshooting

If you encounter issues with your ALLIMITY FS21HS-L remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote and the sound bar's sensor.
  - Ensure you are within the effective operating range and line of sight of the sound bar.
- **Specific Buttons Not Working:**
  - Clean the remote's surface, especially around the unresponsive buttons, to remove any dirt or residue that might be preventing proper contact.
  - If cleaning and battery replacement do not resolve the issue, the button may be physically damaged.
- **Sound Bar Not Responding to Commands:**
  - Verify that the sound bar itself is powered on and functioning correctly.
  - Confirm that the remote control is indeed compatible with your specific VIMA S4 2.1 FS21HS-L TV Sound Bar model.

If problems persist after attempting these steps, contact customer support for further assistance.

Specifications

Feature	Detail
Model Number	CV-2677-FS21HS-L-SH
Brand	ALLIMITY
Compatible Devices	VIMA S4 2.1 FS21HS-L TV Sound Bar Soundbar Audio Speaker System
Power Supply	2 x 1.5V AAA Batteries (Not Included)
Special Feature	Wireless
Color	Black
Product Dimensions	6.5 x 1.38 x 0.72 inches (16.5 x 3.5 x 1.8 cm)
Item Weight	1.59 ounces (45 grams)




14 cm / 5.51 in
MUTE
PAIR
INPUT
LUM
RESET
VOL+
VOL-
-10
+10
TREBLE-
TREBLE+
BASS-
BASS+
MUSIC
MOVIE
NEWS
3D

Image: A diagram showing the dimensions of the remote control: approximately 14 cm (5.51 inches) in length and 4.4 cm (1.73 inches) in width.

Warranty and Support

This product is a replacement remote control. For specific warranty information or technical support, please refer to the documentation provided with your original VIMA S4 2.1 FS21HS-L TV Sound Bar or contact the manufacturer of the sound bar directly. For issues related to the ALLIMITY replacement remote, please contact the seller or ALLIMITY customer service.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3D6YVJT

More documents and user manuals: **https://manuals.plus/**