ALLIMITY RAV34-WN46680EU

ALLIMITY RAV34-WN46680EU Replacement Remote Control Instruction Manual

For Yamaha AV Receiver Models: HTR-6130, HTR-6320, RX-V363, RX-V365

1. Introduction

Thank you for choosing the ALLIMITY RAV34-WN46680EU replacement remote control. This remote is designed to function as a direct replacement for your original Yamaha AV Receiver remote, offering seamless compatibility with specified models. This manual provides essential information for its proper setup, operation, and maintenance.

2. Product Overview

The ALLIMITY RAV34-WN46680EU is a dedicated replacement remote control for various Yamaha AV Receiver models. It features a standard layout with clearly labeled buttons for controlling functions such as power, input selection, volume, menu navigation, and sound modes. No programming or setup is required; simply insert batteries to begin use.



Figure 2.1: Front view of the ALLIMITY RAV34-WN46680EU replacement remote control. This image displays the overall design and button layout of the remote.

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA 1.5V alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 3.1: Rear view of the remote control with the battery cover removed, showing the battery compartment for two AAA batteries.

3.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use with compatible Yamaha AV Receivers. No additional pairing or programming steps are required.

4. Operating Instructions

Point the remote control directly at your Yamaha AV Receiver. Ensure there are no obstructions between the remote and the receiver's infrared sensor.





Figure 4.1: Close-up view of the remote control's buttons, illustrating their layout and labels for various functions.

4.1 Key Functions

Button	Function
POWER	Turns the AV Receiver on or off.
STANDBY	Puts the AV Receiver into standby mode.
SCENE 1-4	Recalls preset scene settings for various listening environments.
CD, DVD, DTV/CBL, DVR, V-AUX, MD/CD-R, TUNER, MULTI CH IN	Selects the corresponding input source.
VOLUME +/-	Adjusts the master volume level.
MUTE	Mutes or unmutes the audio output.
MENU	Accesses the receiver's on-screen menu.
ENTER	Confirms selections within menus.
RETURN	Goes back to the previous menu or screen.
DISPLAY	Changes the information displayed on the receiver's front panel or on-screen display.
SLEEP	Sets the sleep timer for automatic power off.
AUDIO SEL	Selects audio input modes.
NIGHT	Activates or deactivates Night Listening Enhancer.
SUR.DECODE	Selects surround sound decoding modes.

Button	Function
ENHANCER	Activates or deactivates Compressed Music Enhancer.
STRAIGHT	Activates or deactivates Straight/Pure Direct mode.
INFO	Displays information about the current input or settings.
MODE-PTY SEEK-START	Functions related to tuner modes, program type search, and start.
PROG +/-	Navigates through radio presets or menu options.
PRESET ◀/▶	Navigates through radio presets.
LEVEL	Adjusts individual channel levels.
A/B/C/D/E	Selects speaker zones or other specific functions depending on the receiver model.

5. Maintenance

5.1 Cleaning

- Wipe the remote control with a soft, dry cloth to remove dust and smudges.
- Do not use abrasive cleaners, solvents, or chemical wipes, as these may damage the surface or markings.

5.2 Battery Replacement

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new AAA alkaline batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the AV Receiver's infrared sensor.
  - Confirm the remote is pointed directly at the receiver.
- **Limited functionality:**
  - Verify that your AV Receiver model is listed as compatible (HTR-6130, HTR-6320, RX-V363, RX-V365).
  - Some advanced functions specific to the original remote might not be replicated if they are unique to a particular Yamaha model's original remote.

7. Specifications

Feature	Detail
Model	RAV34-WN46680EU

Feature	Detail
Brand	ALLIMITY
Compatibility	Yamaha AV Receiver models: HTR-6130, HTR-6320, RX-V363, RX-V365
Power Supply	2 x AAA 1.5V batteries (not included)
Dimensions (L x W x H)	6.5 x 1.38 x 0.72 inches (16.5 x 3.5 x 1.8 cm)
Weight	1.59 ounces (45 grams)
Color	Black
Special Feature	Wireless (Infrared)



Figure 7.1: Side view of the remote control, illustrating its physical dimensions.

8. Warranty and Support

Specific warranty information for this replacement remote control is not provided in the product details. For any issues, questions, or support needs, please contact the seller directly through your purchase platform. They will be able to assist you with product-

related inquiries and potential returns or exchanges.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question