**EXTRALINK EX.39588**

# Extralink Air Fryer 2L 1000W Instruction Manual

Model: EX.39588

## Introduction

Thank you for choosing the Extralink Air Fryer 2L 1000W. This appliance uses rapid hot air circulation to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Please read this manual thoroughly before first use to ensure safe and optimal operation.




*Image: The Extralink Air Fryer in black, showcasing its compact design and a variety of dishes that can be prepared, including chicken, fish, vegetables, and fries.*

## Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the basket is properly inserted before operating.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

## Product Overview

The Extralink Air Fryer is designed for ease of use and efficient cooking. Familiarize yourself with its components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** LED touchscreen for setting time and temperature.
- **Frying Basket:** Removable, non-stick basket for holding food.
- **Handle:** For safely removing and inserting the frying basket.
- **Air Outlet:** Located at the back of the unit for hot air exhaust.




*Image: A detailed view of the Extralink Air Fryer's LED touchscreen, showing the digital display for temperature and time settings, and a finger interacting with the controls.*

## Setup and First Use

1. **Unpacking:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Cleaning:** Wash the frying basket and any removable parts with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and level surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides, and 10 cm (4 inches) above the appliance. Do not place it against a wall or other appliances.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

## Operating Instructions

## Basic Operation

1. **Prepare Food:** Place the ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks into place.
3. **Power On:** Plug in the appliance. The power indicator will light up.
4. **Set Temperature and Time:** Use the LED touchscreen to adjust the desired temperature (80°C to 200°C) and cooking time.
5. **Start Cooking:** Press the start button to begin the cooking process.
6. **Shake Basket (Mid-Cycle):** For some foods, it is recommended to shake the basket halfway through the cooking time to ensure even browning. Carefully pull out the basket, shake it, and then slide it back in. The appliance will resume cooking automatically.
7. **Check Doneness:** Once the timer finishes, carefully pull out the basket and check if the food is cooked to your preference.
8. **Serve:** Remove the food from the basket using tongs.
9. **Power Off:** Unplug the appliance after use.



*Image: An illustration demonstrating the 360-degree hot air circulation technology within the Extralink Air Fryer, alongside a visual guide for various food types and their recommended temperature settings.*

## Cooking Tips

- Smaller ingredients usually require a slightly shorter cooking time than larger ingredients.
- A larger amount of ingredients only requires a slightly longer cooking time, a smaller amount of ingredients only requires a slightly shorter cooking time.
- Adding a little oil to fresh potatoes for a crispy result is recommended. Fry your ingredients in the air fryer within a few minutes after you've added the oil.
- Snacks that can be prepared in an oven can also be prepared in the air fryer.
- The optimal amount for preparing crispy fries is 300-500 grams.
- Use pre-made dough for quick and easy preparation of filled snacks. Pre-made dough also requires a shorter cooking time than homemade dough.
- You can also use the air fryer to reheat ingredients. To reheat ingredients, set the temperature to 150°C (300°F) for up to 10 minutes.




*Image: The Extralink Air Fryer shown in a kitchen setting, illustrating its versatility in preparing different types of meals such as chicken, fish, vegetables, and fries, highlighting its multi-functional capabilities.*

## Maintenance and Cleaning

Regular cleaning of your Extralink Air Fryer will ensure optimal performance and extend its lifespan.

1. **Before Cleaning:** Always unplug the appliance and allow it to cool down completely before cleaning.
2. **Frying Basket:** The frying basket and any removable parts are dishwasher safe. Alternatively, they can be washed with hot water, dish soap, and a non-abrasive sponge. The non-stick coating ensures easy cleaning.
3. **Inside the Appliance:** Wipe the inside of the appliance with a damp cloth and a mild detergent. Do not use abrasive cleaners or steel wool.
4. **Outside the Appliance:** Clean the exterior with a damp cloth.
5. **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.




*Image: The non-stick frying basket of the Extralink Air Fryer being cleaned under running water in a sink, demonstrating its easy-to-clean design.*

## Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Air fryer does not turn on. | Appliance is not plugged in; power outlet is not working; basket not properly inserted. | Ensure the power cord is securely plugged into a working outlet. Check if the frying basket is fully pushed into the main unit. |
| Food is not cooked evenly. | Basket is overfilled; food not shaken during cooking. | Do not overfill the basket. Shake the basket halfway through the cooking time. |
| White smoke comes from the appliance. | Fat residue from previous use; oil/grease dripping onto the heating element. | Clean the basket and heating element thoroughly after each use. Ensure no excess oil is on the food. |
| Food is not crispy. | Not enough oil (for fresh ingredients); temperature too low; cooking time too short. | Add a small amount of oil to fresh ingredients. Increase temperature or cooking time as needed. |

## Specifications

| Feature | Detail |
|---|---|
| Brand | EXTRALINK |
| Model Number | EX.39588 |
| Capacity | 2 Liters |
| Power Output | 1000 Watts |
| Voltage | 230 Volts |
| Temperature Range | 80°C to 200°C |
| Control Method | LED Touchscreen |
| Material | Plastic (Exterior) |
| Special Features | Frying, baking, grilling, reheating; Dishwasher safe parts; Non-stick coating. |
| Product Dimensions (D x W x H) | 24cm x 24cm x 30cm |

## Warranty and Support

The Extralink Air Fryer 2L 1000W comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Extralink customer service through their official website or the contact information provided with your purchase.
Keep your purchase receipt as proof of purchase for warranty purposes.