Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl J309, J309ES, J5C09E Compatible

Onerbl 2-Prong AC Charging Cord Instruction Manual

For EverStart MAXX Jump Starters (Models J309, J309ES, J5C09E)

Introduction

This manual provides essential instructions for the safe and effective use of your Onerbl 2-Prong AC Charging Cord. This cord is designed as a replacement for specific EverStart MAXX Jump Starter models, including J309, J309ES, and J5C09E. Please read this manual thoroughly before use and retain it for future reference.

Product Overview

The Onerbl 2-Prong AC Charging Cord is a power supply cable designed to connect compatible EverStart MAXX Jump Starters to a standard electrical outlet for charging. It converts AC power from the wall outlet into the DC power required by your device.



Image: The Onerbl 2-Prong AC Charging Cord. This image displays the black power cord, coiled, with a standard two-prong AC plug on one end and a C7 (figure-8) connector on the other end.

Safety Information

- Ensure the charging cord is compatible with your device's power requirements before use.
- Do not use the cord if it is damaged, frayed, or has exposed wires.
- Avoid placing the cord in areas where it can be tripped over or damaged.

- Keep the cord away from water and excessive heat.
- Unplug the cord from the power outlet when not in use or during electrical storms.

Setup

1. **Inspect the Cord:** Before first use, carefully inspect the entire length of the Onerbl 2-Prong AC Charging Cord for any signs of damage, cuts, or fraying. Do not use if damaged.
2. **Identify Ports:** Locate the AC input port on your EverStart MAXX Jump Starter. This port is typically labeled for AC input or charging.
3. **Connect to Device:** Insert the C7 (figure-8) connector end of the Onerbl charging cord firmly into the AC input port of your EverStart MAXX Jump Starter.
4. **Connect to Power Outlet:** Insert the 2-prong AC plug end of the charging cord into a standard, grounded 120V AC electrical wall outlet.

Ensure both connections are secure before proceeding to operation.

Operating Instructions

Once the Onerbl 2-Prong AC Charging Cord is properly connected to both your EverStart MAXX Jump Starter and a power outlet, the jump starter should begin charging. Refer to your jump starter's specific instruction manual for details on charging indicators and expected charging times.

- **Charging Indication:** Most EverStart MAXX models have LED indicators that show charging status (e.g., charging, fully charged). Monitor these indicators.
- **Charging Duration:** Charge your jump starter for the duration recommended by its manufacturer. Overcharging can reduce battery life.
- **Disconnecting:** Once charging is complete, first unplug the 2-prong AC plug from the wall outlet, then disconnect the C7 connector from the jump starter.

Maintenance

- **Cleaning:** Keep the cord clean and free from dust and debris. Use a dry, soft cloth for cleaning. Do not use liquid cleaners.
- **Storage:** When not in use, coil the cord loosely and store it in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tight coiling or kinking, which can damage the internal wires.
- **Regular Inspection:** Periodically inspect the cord for any signs of wear, damage, or loose connections. Replace the cord immediately if any damage is observed.

Troubleshooting

Problem	Possible Cause	Solution
Jump starter not charging.	Cord not properly connected.	Ensure both ends of the cord are securely plugged in.
	Wall outlet is not active.	Test the wall outlet with another device.

Problem	Possible Cause	Solution
	Cord is damaged.	Inspect the cord for damage. Replace if necessary.
Cord feels warm during charging.	Normal operation.	A slight warmth is normal. If it becomes excessively hot or emits smoke/smell, discontinue use immediately and unplug.

Specifications

- **Product Type:** 2-Prong AC Charging Cord
- **Compatibility:** EverStart MAXX Jump Starter Models J309, J309ES, J5C09E (and similar models requiring a 2-prong AC input)
- **Input Connector:** NEMA 1-15P (2-prong AC plug)
- **Output Connector:** IEC C7 (figure-8)
- **Voltage:** 120V AC (standard household)
- **Brand:** Onerbl
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd

Warranty and Support

For warranty information or technical support regarding your Onerbl 2-Prong AC Charging Cord, please refer to the documentation provided at the time of purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Shenzhen Waweis Technology Co., Ltd
Brand: Onerbl

© 2024 Onerbl. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3L4RSLW

More documents and user manuals: **https://manuals.plus/**