Hangrui H2

Hangrui Kids Instant Print Camera H2 User Manual

Model: H2

Introduction

Welcome to the Hangrui Kids Instant Print Camera H2 user manual. This guide provides essential information for setting up, operating, and maintaining your new instant print camera. Designed for children aged 3-12, this camera offers instant black-and-white photo printing, 1080p HD video recording, and various creative features to inspire young photographers.

What's in the Box

- Hangrui Kids Instant Print Camera H2 (Green)
- 3 Rolls of Printing Paper (Non-toxic, odorless, carbon dust-free, BPA-free)
- 32GB SD Card (Pre-installed)
- USB Charging Cable
- Neck Lanyard
- Color Markers
- Stickers
- User Manual

Product Overview

The Hangrui Kids Instant Print Camera H2 is a versatile digital camera featuring a 3.0-inch HD IPS protective screen. It supports instant black-and-white printing, 1080p video recording, digital zoom, timelapse, loop recording, music playback, and puzzle games. The camera is lightweight and designed for portability, making it an ideal companion for travel and outdoor activities.



Image: Front view of the Hangrui Kids Instant Print Camera H2, showcasing its 3.0-inch HD screen, instant print function, 1080P video, time-lapse, multi-funny frames, free 32G SD card, MP3, graffiti DIY, burst shooting, and USB charging capabilities.



Image: Back view of the Hangrui Kids Instant Print Camera H2, highlighting its 3.0-inch IPS screen and 32MP HD pixels for high-quality images and videos.

Setup Instructions

1. **Charging the Camera:** Connect the provided USB charging cable to the camera's USB port and a power source. The built-in 1000mAh rechargeable battery lasts 6 to 8 hours on a full charge.
2. **Inserting Printing Paper:** Open the paper compartment cover. Insert a roll of thermal printing paper, ensuring the paper feeds correctly through the slot. Close the cover securely.
3. **SD Card:** The camera comes with a pre-installed 32GB SD card. Ensure it is properly seated in the SD card slot. This card stores thousands of photos and videos.
4. **Power On/Off:** Press and hold the power button to turn the camera on or off.



Image: The Hangrui Kids Instant Print Camera H2 displayed with its accessories, including three rolls of printing paper, a 32GB SD card, a set of colorful markers, a USB charging cable, and a neck lanyard.

Operating Instructions

Navigation

Use the arrow buttons below the screen to navigate through the menu options (Photo, Video, Album, Settings, Music, Wallpaper). Press the shutter button (top right) to select an option or take a photo.

Taking Photos

1. Select the "Photo" icon from the main menu.
2. Frame your shot using the 3.0-inch HD IPS screen.
3. Press the shutter button to capture the image.
4. To instantly print, select the desired photo from the album and press the print button.

Your browser does not support the video tag.

Video: A demonstration of taking a photo and instantly printing it using the Hangrui Kids Instant Print Camera. The video shows the camera interface and the physical printout.

Video Recording

1. Select the "Video" icon from the main menu.
2. Press the shutter button to start recording.
3. Press the shutter button again to stop recording.
4. Videos are saved to the 32GB SD card.



Image: The Hangrui Kids Instant Print Camera H2 displaying its 1080P video recording capability and a 5-second time-lapse function, showing children playing outdoors.

Creative Modes

- **Time-lapse:** Set a timer (e.g., 5 seconds) to capture photos automatically.
- **Burst Shooting:** Take multiple photos in quick succession.
- **Funny Frames:** Choose from multiple built-in frames to add to your photos before printing.

- **Graffiti DIY:** Use the included markers to color and customize your black-and-white prints.



Image: The Hangrui Kids Instant Print Camera H2 displaying its feature of digital frames with multiple themes, allowing children to add creative borders to their photos.



Image: A child engaged in coloring a black-and-white instant print photo, demonstrating the Graffiti DIY feature of the Hangrui Kids Instant Print Camera H2 using the provided markers.

Maintenance

- Keep the camera clean by wiping it with a soft, dry cloth.
- Avoid exposing the camera to extreme temperatures or moisture.
- Store the camera in a safe place when not in use to prevent damage.
- Ensure the printing paper is stored in a cool, dry place to maintain quality.

Troubleshooting

Problem	Solution
Camera not turning on	Ensure the battery is charged. Connect to a power source using the USB cable.

Problem	Solution
Photos not printing	Check if printing paper is correctly loaded and there is enough paper. Ensure the paper compartment is closed.
Poor print quality	Ensure the printing paper is fresh and not expired. Avoid excessive heat or direct sunlight on the paper.
Cannot save photos/videos	Check if the 32GB SD card is properly inserted. Ensure the SD card is not full.

Specifications

- **Model:** H2
- **Screen:** 3.0-inch HD IPS Protective Screen
- **Video Resolution:** 1080p HD
- **Storage:** 32GB SD Card (Included)
- **Battery:** Built-in 1000mAh Rechargeable Battery
- **Battery Life:** 6-8 hours on full charge
- **Printing:** Instant Black-and-White Thermal Printing
- **Paper Type:** Non-toxic, odorless, carbon dust-free, BPA-free thermal paper
- **Dimensions:** 7.83 x 5.28 x 2.36 inches
- **Item Weight:** 14 ounces

Warranty and Support

For any product inquiries, technical support, or warranty claims, please contact Hangrui customer service. Protection plans are available for extended coverage. Refer to your purchase documentation for specific warranty details and contact information.
For additional support, visit the Hangrui Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question