Tefal EY245B50

T-fal Easy Fry Max Digital Air Fryer Instruction Manual

Model: EY245B50

Introduction

The T-fal Easy Fry Max Digital Air Fryer is engineered to provide a convenient and healthier alternative to traditional frying. Utilizing advanced hot air technology, it circulates hot air rapidly to cook food evenly, producing crispy exteriors and tender interiors with little to no added oil. This manual provides essential information for the safe and effective operation of your appliance.



Figure 1: T-fal Easy Fry Max Digital Air Fryer, showcasing its sleek design and a basket filled with crispy fries.

Key Features:

- **Versatile Cooking:** Features 10 preset programs for a wide variety of dishes including fries, chicken, steak, fish, dessert, pizza, nuggets, vegetables, shrimp, and bacon.
- **Generous Capacity:** A 5.3-quart (5 L) nonstick basket accommodates up to 2.2 lbs of food, suitable for family-sized meals.
- **User-Friendly Interface:** Intuitive digital touchscreen control panel allows for easy selection of preset programs or manual adjustment of time and temperature.
- **Efficient Cooking:** Cooks food up to 46% faster than a conventional oven, saving valuable time.
- **Healthier Results:** Advanced hot air technology enables cooking with up to 90% less fat compared to traditional deep frying.
- **Easy Cleanup:** Dishwasher-safe PTFE nonstick basket and removable drawer simplify post-cooking cleanup.



Figure 2: The T-fal Easy Fry Max enables healthier cooking with little to no added fat, as demonstrated by the variety of dishes.

Safety Information

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the appliance on a stable, heat-resistant surface, away from walls or other appliances.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation. The exterior surfaces may become hot.
- Do not block the air inlet or outlet vents during operation.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Allow the appliance to cool down completely before handling or cleaning.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.

- Use only accessories recommended by the manufacturer.
- The appliance features automatic shut-off functionality for safety.

What's Included

Your T-fal Easy Fry Max Digital Air Fryer package includes:

- Main Air Fryer Unit
- Removable 5.3-quart (5 L) Nonstick Basket
- Removable Drawer
- Instruction Manual (this document)
- Recipe Book (digital access or included)

Setup

Before first use, follow these steps to prepare your air fryer:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the basket and drawer thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
3. Wipe the inside and outside of the main unit with a damp cloth.
4. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is adequate space (at least 4 inches) around the appliance for proper air circulation.
5. Insert the basket into the drawer, then slide the drawer back into the main unit until it clicks into place.

First Time Use - Temperature Unit Setting:

When starting your product for the first time, you may need to switch the temperature display from Celsius (°C) to Fahrenheit (°F) or vice versa.



Figure 3: To switch between Celsius and Fahrenheit, press and hold the (+) and (-) buttons simultaneously for 2 seconds.

Operating Instructions

The T-fal Easy Fry Max offers both preset programs and manual control for diverse cooking needs.

General Operation:

1. Plug the appliance into a grounded wall outlet.
2. Carefully pull the drawer out of the air fryer.
3. Place your ingredients into the air fryer basket. Do not exceed the MAX fill line.
4. Slide the drawer back into the air fryer.
5. Select a preset program or manually set the temperature and time using the digital touchscreen.
6. Press the Start/Stop button to begin cooking.
7. Some recipes may require shaking or turning ingredients halfway through cooking. The air fryer does not prompt for this, so monitor your food.

8. When cooking is complete, the timer will beep. Carefully pull out the drawer and remove the food.



Figure 4: The intuitive digital touchscreen allows for easy selection of cooking programs and manual adjustments.

Preset Cooking Programs:

The air fryer comes with 10 versatile preset programs for common dishes. These programs automatically set optimal time and temperature for consistent results.



Figure 5: Air frying made simple with 10 pre-set cooking programs for various foods.

- Fries
- Nuggets
- Vegetables
- Fish
- Dessert
- Pizza
- Chicken
- Bacon
- Steak
- Shrimp

Official Product Video:

Your browser does not support the video tag.

Video 1: Official T-fal 'EASY FRY Max' product overview. This video highlights the key features and benefits of the air fryer, including

its large capacity and ability to produce crispy results with less added fat.

Maintenance & Cleaning

Proper maintenance ensures the longevity and optimal performance of your T-fal Easy Fry Max Air Fryer.

Cleaning the Basket and Drawer:

The nonstick basket and drawer are designed for easy cleaning.



Figure 6: The non-stick plate and basket are dishwasher safe for convenient and mess-free cleaning.

- Always unplug the air fryer and allow it to cool completely before cleaning.
- Remove the basket and drawer from the main unit.
- The basket and drawer are dishwasher-safe. Alternatively, they can be washed by hand using hot water, dish soap, and a non-abrasive sponge.
- For stubborn food residue, soak the basket and drawer in warm, soapy water for about 10 minutes before cleaning.

- Ensure all parts are thoroughly dry before reassembling or storing.

Cleaning the Main Unit:

- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Clean the heating element inside the air fryer with a cleaning brush to remove any food residue.
- Never immerse the main unit in water or any other liquid.

Troubleshooting

If you encounter issues with your T-fal Easy Fry Max, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Drawer not fully inserted.	Ensure the power cord is securely plugged into a grounded outlet. Push the drawer firmly until it clicks into place.
Food is not cooked evenly.	Too much food in the basket; Food not shaken/turned.	Cook in smaller batches. Shake or turn ingredients halfway through cooking.
Food is not crispy.	Not enough oil (for certain foods); Temperature too low; Cooking time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time.
White smoke coming from the appliance.	Greasy residue from previous use; High-fat ingredients.	Clean the basket and heating element thoroughly. Drain excess fat from ingredients.
Appliance smells during first use.	Protective substances burning off.	This is normal and will dissipate after a few uses. Ensure good ventilation.

Specifications

Feature	Detail
Model Name	Easy Fry Max, Air fryer, 5L Capacity, 10 Auto Cooking Programs
Model Number	EY245B50
Capacity	5.3 Quarts (5 Liters)
Color	Grey
Material	Plastic
Product Dimensions	14.76"D x 10.75"W x 12.76"H
Item Weight	8.36 Pounds
Output Wattage	1500 Watts

Feature	Detail
Voltage	120 Volts
Control Method	Touch Control
Max Temperature Setting	200°C (392°F)
Nonstick Coating	Yes (PTFE)
Dishwasher Safe Parts	Basket and Drawer
Manufacturer	Groupe SEB
Country of Origin	China
UPC	010942228653

Warranty & Support

T-fal products are manufactured to high quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official T-fal website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact T-fal customer service. Contact details can typically be found on the T-fal website or in your product packaging.

© 2024 T-fal. All rights reserved.