masterbee P79

masterbee Kid Camera Instant Print Photo

Model: P79 - Instruction Manual

1. Introduction

The masterbee Kid Camera Instant Print Photo (Model P79) is a versatile digital camera designed for children aged 3 to 12. It combines the fun of instant printing with digital photography and video recording. This manual provides detailed instructions for setting up, operating, and maintaining your camera to ensure a safe and enjoyable experience.
Key features include:

- **Instant Print Function:** Equipped with 2 print modes (grayscale, dot matrix) and 3 color depth options (light, medium, dark). Utilizes advanced thermal printing technology, requiring no ink and being BPA-free. Comes with 3 rolls of printing paper.
- **Multi-functional Digital Camera:** Captures colorful pictures and HD 1080p videos. Includes a music player and puzzle games. Offers multiple frames, color filters, and mirror effects for creative expression.
- **High Definition and Selfie Camera:** Features front and rear dual lenses for easy selfies. Automatically adjusts parameters for high-definition results. Includes digital zoom, timelapse, and loop recording functions. Equipped with a 2.4-inch large IPS screen.
- **Large Memory Capacity and Battery:** Comes with a pre-inserted 32GB SD card, capable of storing thousands of photos. Built-in large rechargeable battery provides 6 to 8 hours of use on a full charge.

2. Package Contents

Please check the box for the following items:

- masterbee Kid Camera (Model P79)
- USB Charging Cable
- Neck Lanyard
- 3 Rolls of Thermal Printing Paper
- 32GB SD Card (pre-installed in camera)
- User Manual

3. Setup

3.1 Charging the Camera

Before first use, fully charge the camera using the provided USB cable. Connect the small end of the USB cable to the camera's charging port (located under a silicone tab on the side) and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.

3.2 Inserting/Removing SD Card

The camera comes with a 32GB SD card pre-installed. If you need to remove or replace it, gently open the silicone tab on the side of the camera. Press the SD card inward until it clicks, then release to eject it. To insert, push the card into the slot until it clicks into place.

3.3 Loading Printing Paper

The camera uses thermal printing paper. To load a new roll:

1. Locate the paper compartment latch on the bottom front of the camera.
2. Gently pull the latch to open the paper compartment cover.
3. Insert a new roll of thermal paper. Ensure the smooth, printable side of the paper is facing upwards, and the rough side is facing downwards.
4. Pull a small length of paper out of the compartment.
5. Close the paper compartment cover firmly until it clicks.
6. Tear off any excess paper by pulling upwards against the serrated edge.

Important: If the paper is installed in the wrong direction, it will not print.



Figure 3.3: Correct paper loading direction for instant printing.

4. Operating Instructions

4.1 Power On/Off

Press and hold the power button (usually located on the top or side) for a few seconds to turn the camera on or off. The screen will light up, displaying the main menu.

4.2 Navigation

Use the directional buttons (up, down, left, right) to navigate through the menu options. Press the 'OK' button to select an option.

4.3 Photo Mode

From the main menu, select the camera icon. The screen will display a live view. Press the shutter button (usually on top) to take a picture. The camera features front and rear dual lenses. To switch between front and rear cameras, press the power button once quickly.



Figure 4.3: Camera features including dual lenses and digital zoom.

4.3.1 Frames and Filters

In photo mode, use the directional buttons to browse and select various frames, color filters, and mirror effects to add creativity to your pictures.



Figure 4.3.1: Creative frames and filters for photos.

4.3.2 Digital Zoom & Timelapse

The camera supports digital zoom (up to 16x) and timelapse functions (2s, 5s, 10s). These can be accessed and adjusted through the camera's settings menu.

4.4 Video Mode

From the main menu, select the video camera icon. Press the shutter button to start recording 1080p HD video. Press it again to stop recording. Videos are saved to the SD card.



Figure 4.4: 1080P HD video recording capability.

4.5 Instant Printing

After taking a picture, you can choose to print it instantly or later from the photo album. The camera offers 2 print modes (grayscale and dot matrix) and 3 types of color depth printing (light, medium, dark).



Figure 4.5: Digital storage and instant print options.

4.6 Games

The camera includes several puzzle games designed to develop concentration and thinking skills. Select the game icon from the main menu to access them.



Figure 4.6: Built-in music player and puzzle games.

4.7 Music Player

The camera has a music player function. Load MP3 files onto the SD card to play music directly from the device. Select the music icon from the main menu.

4.8 Flashlight Function

The camera is equipped with a flashlight. To activate it, press the designated flashlight button (refer to the camera's physical buttons for exact location, often near the lens). This can be useful in low-light conditions.

Video 4.8.1: Demonstration of various camera features and functions.

Video 4.8.2: Close-up view of the instant print quality from the camera.

5. Maintenance

To ensure the longevity and optimal performance of your masterbee Kid Camera, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the camera body and screen. Do not use liquid cleaners or abrasive

materials.

- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Paper Handling:** Use only compatible thermal printing paper. Store paper rolls in a dry place to prevent damage.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the camera regularly, even if not in use, to maintain battery health.

6. Troubleshooting

If you encounter any issues with your camera, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Camera does not turn on	Low battery	Charge the camera fully.
No picture prints	Paper loaded incorrectly or no paper	Check paper direction (smooth side up) and ensure a roll is loaded.
Poor print quality	Low battery, old paper, or incorrect print settings	Charge battery, replace paper roll, adjust print depth in settings.
Cannot record video	No SD card or full SD card	Ensure SD card is inserted. Delete old files or replace SD card if full.

7. Specifications

Feature	Detail
Brand	masterbee
Model Name	P79
Color	Purple
Photo Sensor Technology	CMOS
Effective Still Resolution	20 MP
Video Resolution	1080p
Digital Zoom	16 x
Screen Size	2.4 Inches
Display Type	IPS
Memory Storage Capacity	32 GB (SD Card included)
Battery Cell Type	Lithium Ion
Item Weight	0.42 Kilograms
Special Feature	Instant black-and-white thermal printing

8. Warranty and Support

The masterbee Kid Camera (Model P79) comes with a **1-year warranty** from the manufacturer, masterbee. For any product inquiries, technical support, or warranty claims, please contact masterbee customer service through your retailer or the official masterbee website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question