Wekily S50

Wekily S50 Wireless Earbuds User Manual

Model: S50

Introduction

This manual provides detailed instructions for the proper use and maintenance of your Wekily S50 Wireless Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

Package Contents

Verify that all items listed below are included in your package:

- Wekily S50 Wireless Earbuds (2 units)
- Charging Case (1 unit)
- Mini USB Type-C Charging Cable (1 unit)
- Ear Caps (6 units: S/M/L sizes)
- User Manual (1 unit)



Image: Wekily S50 Wireless Earbuds and Charging Case. The earbuds are shown in their open charging case, displaying the LED power indicator.

Product Overview

The Wekily S50 Wireless Earbuds feature Bluetooth 5.3 connectivity, a digital LED power display on the charging case,

HiFi stereo sound with 14.2mm drivers, and ENC noise-cancelling microphones for clear calls. They are designed for comfort and durability with an IPX7 waterproof rating.



Image: Diagram illustrating the internal components of the Wekily S50 earbud, highlighting the 14.2mm dynamic speakers for Hi-Fi stereo sound quality, ENC Noise Cancelling, and HD Call features.



Image: The Wekily S50 charging case with its lid open, showing the digital LED display indicating the battery percentage of both the charging case and the individual earbuds (L/R).

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up to confirm charging.
2. Connect the provided USB Type-C cable to the charging port on the case and plug the other end into a USB power adapter (not included) or a computer's USB port.
3. The digital LED display on the charging case will show the current battery level of the case and the charging status of each earbud.
4. A full charge typically takes about 1 hour for the earbuds and case. The earbuds provide 6-8 hours of playback on a

single charge, and the charging case extends total playtime to up to 48 hours.



Image: The Wekily S50 charging case connected via a USB-C cable, illustrating the 48-hour total battery life, 8 hours per earbud charge, and 1-hour fast charging capability.

2. Pairing with Your Device

The earbuds utilize Bluetooth 5.3 for a stable and efficient connection.

1. **First-Time Pairing:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "S50" from the list of found devices. Once connected, you will hear a confirmation tone.
4. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case, provided Bluetooth is enabled on your device.



Image: A visual guide demonstrating the one-step pairing process for the Wekily S50 earbuds. Opening the case initiates quick connect, and closing it leads to automatic disconnection and charging. A smartphone screen shows "S50" as a paired Bluetooth device.

3. Wearing the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size and ensure a secure fit.

1. Select the ear tips (S/M/L) that best fit your ear canals. A good seal is crucial for bass response and noise isolation.
2. Gently insert the earbuds into your ears and rotate them slightly until they feel secure and comfortable. The ergonomic design helps distribute pressure evenly.



Image: Illustration of the ergonomic design of the Wekily S50 earbuds, showing how they fit into the ear canal at a 45-degree angle. Also displayed are the three different ear tip sizes (S, M, L) for customized comfort and fit.

Operating Instructions

The Wekily S50 earbuds feature smart touch controls for easy management of audio and calls.

Touch Controls

Function	Action
Power On	Open the charging case.
Power Off	Place earbuds back into the charging case and close the lid.
Play/Pause Music	Single tap on either earbud.

Function	Action
Next Track	Double tap the Right earbud.
Previous Track	Double tap the Left earbud.
Volume Up	Triple tap the Right earbud.
Volume Down	Triple tap the Left earbud.
Answer/End Call	Single tap on either earbud during an incoming call or active call.
Reject Call	Press and hold either earbud for 2 seconds during an incoming call.
Activate Voice Assistant	Press and hold either earbud for 3 seconds.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove ear tips and clean them with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Keep charging contacts on both earbuds and case clean to ensure proper charging.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing the device in extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

If you encounter issues with your Wekily S50 earbuds, refer to the following common solutions:

- **Earbuds not charging:**
  - Ensure the earbuds are correctly seated in the charging case.
  - Check if the charging case has sufficient battery or is connected to a power source.
  - Clean the charging contacts on both the earbuds and the case.
- **Earbuds not pairing:**
  - Make sure Bluetooth is enabled on your device.
  - Ensure the earbuds are out of the charging case and in pairing mode.
  - Forget "S50" from your device's Bluetooth list and try pairing again.
  - If only one earbud connects, try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise place both back in case, close, then reopen).
- **No sound or low volume:**
  - Adjust the volume on both your device and the earbuds.
  - Ensure the earbuds are properly connected to your device.

- Check for debris blocking the earbud speakers.

- **Connection drops frequently:**
  - Ensure there are no significant obstacles between the earbuds and your device.
  - Stay within the Bluetooth range (up to 15 meters).
  - Minimize interference from other wireless devices.

Specifications

Key technical specifications for the Wekily S50 Wireless Earbuds:

Feature	Detail
Model Name	S50
Bluetooth Version	5.3
Bluetooth Range	Up to 15 meters (49 feet)
Audio Driver Type	Dynamic Driver (14.2mm)
Battery Life (Earbuds)	6-8 hours per charge
Total Playtime (with Case)	Up to 48 hours
Charging Time	Approx. 1 hour (earbuds and case)
Charging Port	USB Type-C
Water Resistance	IPX7
Noise Control	Passive Noise Cancellation, ENC Noise Cancelling Mic
Control Method	Touch Control
Earbud Weight	Approx. 4 grams (each)
Case Weight	Approx. 30 grams
Material	Plastic
Compatible Devices	iOS/Android smartphones, tablets, laptops, TVs, etc.



Image: The back of the Wekily S50 product packaging, displaying detailed specifications such as impedance, distortion, audio protocols, and response frequency.

Safety Information

- Do not disassemble, repair, or modify the product.
- Avoid exposing the product to extreme temperatures, direct sunlight, or fire.
- Keep the product away from water and liquids, despite its IPX7 rating, to prevent damage.
- Do not use the earbuds at excessively high volumes for prolonged periods to prevent hearing damage.
- Keep out of reach of children and pets.

Warranty and Support

Wekily products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official Wekily website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question