TopMate B0D3T7JSHJ

TopMate Wireless Keyboard and Mouse Ultra Slim Combo User Manual

Model: B0D3T7JSHJ

1. Introduction

This manual provides comprehensive instructions for the TopMate Wireless Keyboard and Mouse Ultra Slim Combo. This combo offers a 2.4G wireless connection, designed for efficient and quiet operation across various devices. Please read this manual thoroughly before use to ensure proper setup and functionality.



Image 1.1: TopMate Wireless Keyboard and Mouse Combo (Blue Black color variant).

2. Package Contents

Verify that all items are present in the package:

- Wireless Keyboard
- Wireless Mouse
- USB Nano Receiver (stored in the mouse battery compartment)
- 2 x AA Batteries (for keyboard)
- 2 x AAA Batteries (for mouse)
- Keyboard Protective Cover
- User Manual (this document)

3. Setup Instructions

3.1. Battery Installation

1. **For the Mouse:** Open the battery compartment cover on the underside of the mouse. Insert 2 AAA batteries, ensuring correct polarity (+/-). The USB Nano receiver is typically stored here. Remove the receiver. Close the cover.
2. **For the Keyboard:** Open the battery compartment cover on the underside of the keyboard. Insert 2 AA batteries, ensuring correct polarity (+/-). Close the cover.



Image 3.1: Underside of the mouse showing battery compartment and USB receiver storage.



Image 3.2: AA and AAA batteries for keyboard and mouse.

3.2. Connecting the Wireless Combo

1. Locate the USB Nano receiver, typically stored in the mouse's battery compartment.
2. Plug the USB Nano receiver into an available USB port on your computer (PC, laptop, desktop, Chromebook, Smart TV, etc.).
3. Turn on the mouse using the ON/OFF switch located on its underside. The keyboard does not have a separate power switch; it activates upon key press.
4. The keyboard and mouse should automatically connect to your device. No additional drivers are typically required.



Image 3.3: USB Nano receiver connected to a laptop.

4. Operating Instructions

4.1. Keyboard Functions

- **Full-Size Layout:** The keyboard features a full-size layout, including a numeric keypad for data entry.
- **Function Keys (F1-F12):** The keyboard includes 12 function keys that provide quick access to multimedia controls and system functions. These may include volume control, media playback, email, and web browser shortcuts. Functionality may vary slightly depending on the operating system. *Note: Hotkeys may not be fully compatible with Mac systems.*
- **Scissor Switch Keys:** The scissor-switch key mechanism provides a quiet and responsive typing experience, reducing noise during use.



Image 4.1: Keyboard layout highlighting function keys.



Image 4.2: Illustration of scissor switch keys for silent typing.

4.2. Mouse Functions

- **Adjustable DPI:** The mouse features adjustable DPI (Dots Per Inch) settings, allowing you to customize cursor sensitivity. The default setting is 1600 DPI. You can cycle through available DPI settings (e.g., 800-1200-1600-2000-2400) by pressing the DPI button, usually located near the scroll wheel.
- **Silent Clicks:** The mouse is designed for silent clicking, minimizing disturbance in quiet environments.



Image 4.3: Mouse with adjustable DPI settings.

4.3. Compatibility

The wireless combo is compatible with various operating systems, including Windows XP / ME / Vista / 7 / 8 / 10 / 11. It works with devices that have a USB slot, such as PCs, laptops, Macbooks, desktops, Chromebooks, and Smart TVs.



Image 4.4: Compatibility with multiple device types.

5. Maintenance

5.1. Battery Management

- **Battery Life:** The included batteries typically last between 3 to 5 months, depending on usage conditions.
- **Replacement:** Replace batteries when performance degrades or devices become unresponsive. Use high-quality AA batteries for the keyboard and AAA batteries for the mouse.
- **Mouse Power Switch:** To conserve battery life, turn off the mouse using the ON/OFF switch on its underside when not in use for extended periods. The keyboard does not have a power switch.



Image 5.1: Wireless connection setup, illustrating the USB receiver.

5.2. Cleaning and Protection

- **Keyboard Cover:** Use the included keyboard protective cover to shield the keyboard from dust, spills, and debris.
- **Cleaning:** For general cleaning, wipe the surfaces of the keyboard and mouse with a soft, damp cloth. Ensure devices are powered off before cleaning. Avoid harsh chemicals.



Image 5.2: Keyboard with its protective cover in place.



Image 5.3: The keyboard cover provides protection against liquids.

6. Troubleshooting

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low batteries; USB receiver not properly connected; device out of range.	Replace batteries in both devices. Ensure the USB receiver is securely plugged into a working USB port. Move devices closer to the receiver (within 10m/393.7in).
Lag or delayed response	Low batteries; interference from other wireless devices.	Replace batteries. Move the receiver to a different USB port, preferably one closer to the devices. Reduce interference by moving other wireless devices away.
Mouse cursor erratic or not moving smoothly	Low mouse battery; dirty optical sensor; incorrect DPI setting.	Replace mouse batteries. Clean the optical sensor on the underside of the mouse. Adjust DPI settings using the DPI button.
Function keys not working on Mac	Limited compatibility with Mac OS hotkeys.	Some hotkeys may not be fully supported on Mac systems. Standard typing functions will work.

7. Specifications

Feature	Detail
Brand	TopMate
Model	B0D3T7JSHJ
Connectivity Technology	2.4G Wireless
Wireless Range	Up to 10 meters (393.7 inches)
Keyboard Dimensions (L x W x H)	Approx. 14.55 x 5.5 x 0.8 inches (37 x 14 x 2 cm)
Mouse Dimensions (L x W x H)	Approx. 4.3 x 2.25 x 0.82 inches (11 x 5.7 x 2.1 cm)

Feature	Detail
Item Weight	1.52 pounds (combined)
Keyboard Battery Type	2 x AA batteries
Mouse Battery Type	2 x AAA batteries
Key Type	Scissor Switch
Mouse DPI Settings	Adjustable (e.g., 800-1200-1600-2000-2400 DPI)
Compatible Operating Systems	Windows XP / ME / Vista / 7 / 8 / 10 / 11



Image 7.1: Physical dimensions of the keyboard and mouse.

8. Warranty and Support

8.1. Product Warranty

This TopMate Wireless Keyboard and Mouse Combo is covered by a 2-Year Warranty. If any quality issues occur with the product within two years from the date of purchase, a replacement will be provided free of charge.

8.2. Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact TopMate customer support. Refer to the product packaging or the official TopMate website for the most current contact information.

© 2025 TopMate. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question