Hatteker HT-6188H

Hatteker 8-in-1 Multi-Functional Grooming Kit User Manual

Model: HT-6188H
Brand: Hatteker

Introduction

This manual provides comprehensive instructions for the safe and effective use of your Hatteker 8-in-1 Multi-Functional Grooming Kit. This versatile device is designed to meet all your grooming needs, including beard, mustache, hair, nose, ear, and body trimming.

Safety Information

Important Safety Precautions:

- Always unplug the trimmer before cleaning or changing attachments.
- Keep blades away from water unless the device is specifically designed for wet use and is unplugged.
- Do not use on dry or irritated skin.
- Avoid contact with eyes.
- Always supervise children when using the trimmer.
- Store in a dry place.
- Follow the manufacturer's instructions for cleaning and maintenance.

Package Contents

Your Hatteker 8-in-1 Multi-Functional Grooming Kit includes the following items:

- Main Trimmer Unit
- T-Blade Groomer
- 4 Guide Combs for T-Blade (1mm, 3mm, 5mm, 7mm)
- Hair Clipper

- 7 Guide Combs for Hair Clipper (3mm, 6mm, 9mm, 12mm, 15mm, left and right comb row)
- Precision Trimmer
- Razor Head
- Beard Trimmer Head
- Nose/Ear Hair Trimmer Head
- Body Groomer Head
- USB Charging Cable
- Cleaning Brush
- Storage Base
- Storage Pouch



Image: All components of the Hatteker 8-in-1 Multi-Functional Grooming Kit, including the main unit, various trimmer heads, guide combs, charging cable, cleaning brush, and storage base.

Setup

Initial Charging

Before first use, fully charge the trimmer.

1. Connect the USB charging cable to the trimmer's USB-C port.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The LED display will indicate charging status. A full charge takes approximately 1.5 hours and provides up to 180 minutes of cordless operation.



Image: Close-up of the Hatteker trimmer's smart LED display, showing battery level, RPM, and lock status.

Attaching and Detaching Trimmer Heads

To change the trimmer head:

1. Ensure the trimmer is turned off.
2. Gently pull the currently attached head upwards to detach it from the main unit.
3. Align the desired trimmer head with the slot on the main unit and push down firmly until it clicks into place.



Image: The Hatteker grooming kit displaying the main unit and its various interchangeable heads, including T-blade, precision trimmer, razor, nose/ear trimmer, and body groomer.

Operating Instructions

Power On/Off and Speed Adjustment

Press the power button to turn the trimmer on or off. The LED display will show the current RPM (motor speed) and battery level.
To adjust the motor speed (6000RPM, 6500RPM, 7000RPM), use the speed adjustment buttons located near the power button.

Your browser does not support the video tag.

Video: This video demonstrates the various functions of the Hatteker 8-in-1 Multi-Functional Grooming Set, including how to adjust motor speed, change attachments, and use it for different grooming needs.

Using Guide Combs

Select the appropriate guide comb for your desired hair length. The T-blade groomer comes with 1mm, 3mm, 5mm, and 7mm combs. The hair clipper has 3mm, 6mm, 9mm, 12mm, 15mm, and specialized left/right ear combs.
For the precision trimmer, use the adjustable dial to select lengths from 1mm to 10mm.



Image: Illustration showing the different hair cutting length options available with the Hatteker trimmer, including various guide combs for the T-blade and hair clipper, and the adjustable dial for the precision trimmer.

Specific Grooming Applications

Beard and Mustache Trimming

Attach the beard trimmer head or T-blade with the desired guide comb. Move the trimmer against the direction of hair

growth for an even trim.

Hair Clipping

Use the hair clipper head with appropriate guide combs for cutting hair on the head. Start with a longer comb and gradually reduce length as needed.

Nose and Ear Hair Trimming

Attach the nose/ear hair trimmer head. Gently insert the trimmer into the nostril or ear canal, rotating slightly to trim unwanted hair.

Body Grooming

Use the body groomer head for trimming body hair. The R-Type 360° Skin-Friendly Blunt-Edge Blades ensure a safe and comfortable experience.



Image: A collage demonstrating the Hatteker trimmer being used for various grooming tasks, including nose trimming, beard trimming, hair clipping, and body grooming.

Maintenance

Cleaning

The Hatteker trimmer is 100% waterproof, making it easy to clean.

1. Turn off the trimmer and detach the head.
2. Use the included cleaning brush to remove any hair clippings from the blades.
3. Rinse the trimmer head and the main unit under running tap water.
4. Allow all parts to air dry completely before reattaching or storing.

Storage

Store the trimmer and its accessories in the provided storage base or pouch to keep them organized and protected.



Image: The Hatteker trimmer and its various attachments neatly organized in the provided storage base, with a separate pouch for travel or additional storage.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully.
Trimmer pulls hair or cuts poorly.	Blades are dirty or dull; incorrect attachment.	Clean the blades thoroughly. Ensure the correct attachment is securely in place.
LED display not working.	Low battery or internal issue.	Charge the trimmer. If the issue persists, contact customer service.

Specifications

Model Number: HT-6188H

Product Dimensions: 2.72 x 6.18 x 9.06 inches

Item Weight: 1.52 Pounds (690 Grams)

Charging Time: Approximately 1.5 hours

Operating Time: Up to 180 minutes

Motor Speeds: 6000RPM, 6500RPM, 7000RPM (Adjustable)

Waterproof Rating: 100% Waterproof (IPX6)

Blades: R-Type 360° Skin-Friendly Blunt-Edge Blades

Country of Origin: China

Warranty and Customer Support

Hatteker offers a comprehensive problem-solving and answering service. If you encounter any problems with your trimmer within 12 months of purchase, please do not hesitate to contact our customer service team.
For support, please refer to the contact information provided in your product packaging or visit the official Hatteker website.

© 2024 Hatteker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question