Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OSOTEK H200 Lite

OSOTEK H200Lite Cordless Wet Dry Vacuum Cleaner and Mop

Model: H200Lite

Brand: OSOTEK

Introduction

The OSOTEK H200Lite Cordless Wet Dry Vacuum Cleaner and Mop is designed to simplify floor cleaning by combining vacuuming, mopping, and self-cleaning functionalities into a single, efficient device. It is engineered to effectively manage both wet and dry messes across various hard floor types, offering a comprehensive cleaning solution for your home.

What's in the Box

- OSOTEK H200Lite Main Unit
- Charging Dock
- Hard Floor Cleaning Solution
- Cleaning Brush
- Roller Brush (pre-installed)
- HEPA Filter (pre-installed)
- User Manual



Figure 1: OSOTEK H200Lite Cordless Wet Dry Vacuum Cleaner with included accessories.

Setup

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure all listed items are present.
2. **Assemble Handle:** Insert the handle into the main unit until it clicks securely into place.
3. **Install Roller Brush:** If not pre-installed, remove the roller brush cover, install the roller brush, and then reattach the cover.
4. **Charge Battery:** Place the main unit onto the charging dock. Connect the charging dock to a power outlet. The digital

display will indicate charging status. Ensure the unit is fully charged before first use.



Figure 2: Digital display indicating battery charge level.

5. **Fill Clean Water Tank:** Remove the clean water tank from the main unit. Fill it with clean water and add the recommended amount of OSOTEK Hard Floor Cleaning Solution. Reinsert the tank into the main unit.



Figure 3: Diagram showing the clean and dirty water tanks.

Operating Instructions

The OSOTEK H200Lite offers versatile cleaning modes and features for optimal performance on hard floors.

1. Power On and Mode Selection

- Press the Power button on the handle to turn on the unit.
- The digital display will show the current mode and battery level.
- Press the Mode button to cycle through Standard Mode, Turbo Mode, and Suction Mode.

2. 3-in-1 Cleaning Functionality

This unit vacuums, mops, and washes simultaneously, handling both wet and dry messes efficiently.



Figure 4: The H200Lite performing 3-in-1 cleaning on various floor types.

3. Maneuverable 180° Flat Design

The unit can recline up to 180 degrees, allowing it to reach under low furniture like sofas and beds, ensuring thorough cleaning of hidden dust and dirt.



Figure 5: The 180° flat design enables cleaning in hard-to-reach areas.

4. Edge-to-Edge Cleaning

With its innovative dual-edge design, the vacuum cleaner can clean right up against walls and into corners, leaving no dirt or dust behind.



Figure 6: The dual-edge design ensures comprehensive cleaning along edges.

5. Innovative Anti-Tangle Brush

The specially designed anti-tangle brush prevents hair from wrapping around it, making it ideal for pet owners and ensuring consistent cleaning performance.



Figure 7: The anti-tangle brush effectively handles hair without tangling.

6. Self-Propelling Feature

The front self-propelling feature assists in moving the vacuum forward, reducing user effort during cleaning.



Figure 8: The self-propelling feature makes cleaning effortless.

7. Smart LED Display

The integrated LED display provides real-time information on battery status, cleaning mode, and alerts for easy operation.



Figure 9: The smart LED display provides essential operational information.

8. Official Product Video

Your browser does not support the video tag.

Video 1: Official OSOTEK Cordless Wet Dry Vacuum Mop Combo demonstration. This video provides a comprehensive overview of the product's features and operation, including its 3-in-1 cleaning capabilities, maneuverability, and smart functions.

Maintenance

1. Auto Self-Cleaning

After each use, place the unit back on the charging dock and activate the one-touch self-cleaning feature. This will clean the brush

roll and internal components, reducing manual cleaning effort.



Figure 10: The self-cleaning function ensures the unit remains hygienic.

2. Emptying Dirty Water Tank

Regularly empty the dirty water tank after each cleaning session. The tank is designed to separate solid debris from liquid waste for easier disposal.

- Remove the dirty water tank from the main unit.
- Separate the solid debris filter and dispose of solid waste.
- Pour out the dirty water.
- Rinse the tank and filter with clean water and allow to air dry before reassembling.

3. Cleaning the Roller Brush and Filter

Periodically remove the roller brush and HEPA filter for manual cleaning to ensure optimal performance. Rinse them under running water and allow them to air dry completely before reinserting.

Troubleshooting

Problem	Possible Cause	Solution
Unit not turning on	Battery is low or depleted.	Charge the unit fully.
Poor suction	Dirty water tank full, filter clogged, or roller brush tangled.	Empty dirty water tank, clean filter, clear tangled hair from brush.
Leaves streaks/excess water	Dirty water tank full, roller brush dirty, or incorrect solution ratio.	Empty/clean dirty water tank, clean roller brush, adjust cleaning solution.
Unpleasant odor	Dirty water tank/brush not cleaned properly.	Thoroughly clean dirty water tank, roller brush, and internal components. Ensure proper drying.

Specifications

- **Brand:** OSOTEK
- **Model Name:** H200 Lite
- **Color:** White
- **Special Feature:** Wet/Dry, Self-Cleaning, Cordless, Digital Display, Anti-Tangle Brush
- **Filter Type:** Cartridge
- **Capacity:** 750 Milliliters (Clean Water Tank)
- **Runtime:** 30 minutes
- **Form Factor:** Handheld
- **Product Dimensions:** 12"L x 11"W x 31"H
- **Item Weight:** 11 pounds
- **Battery Description:** Lithium-Ion
- **Controller Type:** Push Button
- **Control Method:** Touch
- **Indoor/Outdoor Usage:** Indoor

Warranty and Support

For warranty information, technical support, or any inquiries regarding your OSOTEK H200Lite, please refer to the official OSOTEK website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D459BQRQ

More documents and user manuals: **https://manuals.plus/**