De'Longhi ECAM292.81.SB

De'Longhi Magnifica Evo ECAM292.81.SB Fully Automatic Coffee Machine User Manual

Model: ECAM292.81.SB

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi Magnifica Evo ECAM292.81.SB Fully Automatic Coffee Machine. Please read this manual thoroughly before using the appliance and keep it for future reference.

2. Important Safety Instructions

- Read all instructions carefully before use.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage.
- Keep the appliance out of reach of children.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug.
- Only use accessories recommended by the manufacturer.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Avoid contact with moving parts.

3. Product Overview

The De'Longhi Magnifica Evo ECAM292.81.SB is a fully automatic bean-to-cup coffee machine designed for preparing a variety of coffee and milk-based beverages. It features a user-friendly control panel and an integrated LatteCrema system for automatic milk frothing.



Image 3.1: The De'Longhi Magnifica Evo ECAM292.81.SB coffee machine, showcasing its sleek design and the LatteCrema milk system preparing a latte macchiato.

Key Features:

- 7 direct selection buttons for Espresso, Coffee, Long Coffee, Cappuccino, and Latte Macchiato.
- High-quality conical burr grinder with 13 adjustable grinding levels.
- Integrated LatteCrema System for automatic milk preparation.
- Colored control panel with LED lighting for intuitive operation.
- Removable brewing unit for easy cleaning.
- Automatic descaling and cleaning functions.

- Option to use pre-ground coffee.

4. Initial Setup

1. **Unpacking:** Carefully remove the appliance from its packaging. Remove all protective films and accessories.
2. **First Use:** Fill the water tank with fresh water up to the MAX level. Fill the bean hopper with coffee beans. Plug the appliance into a power outlet.
3. **Rinsing Cycle:** The machine will perform an automatic rinsing cycle. Follow the on-screen prompts.
4. **Water Hardness:** It is recommended to set the water hardness level according to your local water supply. Refer to the detailed manual for instructions on testing and setting water hardness.
5. **Grinder Adjustment:** The grinder can be adjusted to suit your preferred coffee strength. Turn the grinder adjustment dial inside the bean hopper. Adjustments should only be made when the grinder is operating.



Image 4.1: A hand adjusting the grinder setting dial located within the coffee bean hopper.

5. Operating Instructions

5.1 Making Coffee

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place one or two cups under the coffee spouts.
3. Select your desired beverage by pressing the corresponding button on the control panel (e.g., Espresso, Coffee, Long Coffee).
4. The machine will automatically grind the beans and brew your coffee.
5. For two cups, press the desired beverage button twice in quick succession (if available for that beverage).



Image 5.1: A user's finger pressing a selection button on the illuminated control panel of the coffee machine.

5.2 Using Pre-Ground Coffee

1. Open the lid of the pre-ground coffee funnel.
2. Add one level scoop of pre-ground coffee (for one cup). Do not add more than one scoop.
3. Select your desired beverage. The machine will use the pre-ground coffee.

6. LatteCrema System (Milk System)

The LatteCrema System allows for automatic preparation of milk-based beverages like Cappuccino and Latte Macchiato. It ensures a dense and creamy milk foam.



Image 6.1: Various components of the LatteCrema milk system, including the milk carafe and frothing mechanism, laid out for cleaning or assembly.

6.1 Preparing Milk Beverages

1. Fill the milk carafe with fresh cold milk.
2. Attach the milk carafe to the machine's frothing spout.
3. Place a cup under the coffee spouts and the milk spout.
4. Select your desired milk beverage (e.g., Cappuccino, Latte Macchiato, MyLatte).
5. The machine will automatically dispense milk foam and coffee.

6.2 Cleaning the Milk System

After each use, it is crucial to clean the LatteCrema system to prevent milk residue buildup. The machine will prompt you to perform a cleaning cycle. Remove the milk carafe and disassemble its components for thorough cleaning under running water. Some components are dishwasher safe.

7. Maintenance

7.1 Daily Cleaning

- **Drip Tray and Grounds Container:** Empty and clean daily. The machine will indicate when the grounds container is full.
- **Brewing Unit:** The brewing unit should be removed and rinsed under running water at least once a week. Ensure it is completely dry before reinserting.
- **Water Tank:** Rinse the water tank regularly and refill with fresh water.

7.2 Descaling

The machine will indicate when descaling is required. Descaling is essential to remove mineral deposits and maintain optimal performance. Use only De'Longhi descaling solution and follow the instructions provided with the descaler and on the machine's display.

8. Troubleshooting

This section addresses common issues you might encounter. For more detailed troubleshooting, refer to the full product manual or contact customer support.

Problem	Possible Cause	Solution
Coffee is not hot enough	Cold cups, machine not preheated, low coffee temperature setting.	Preheat cups, allow machine to fully preheat, adjust coffee temperature in settings.
No coffee dispensed	Water tank empty, brewing unit blocked, coffee spout blocked.	Fill water tank, clean brewing unit, clean coffee spouts.
Milk not frothing correctly	Milk system dirty, milk too warm, incorrect milk type.	Clean milk system thoroughly, use cold fresh milk, try different milk types.
Machine requires descaling	Mineral buildup in the internal circuits.	Perform the descaling cycle as prompted by the machine.

9. Specifications

Technical data for the De'Longhi Magnifica Evo ECAM292.81.SB coffee machine:

Feature	Specification
Brand	De'Longhi
Model Number	ECAM292.81.SB

Feature	Specification
Color	Silver/black
Product Dimensions (D x W x H)	44 x 24 x 36 cm
Capacity (Water Tank)	1.8 Liters
Power / Wattage	1450 watts
Voltage	240
Material	Plastic
Item Weight	9.6 Kilograms
Special Features	Milk Frother
Coffee Maker Type	Espresso Machine
Style	7 drinks
Specific Uses For Product	Cappuccino, Espresso, Latte

10. Warranty and Support

Your De'Longhi Magnifica Evo ECAM292.81.SB coffee machine is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, spare parts, or to locate an authorized service center, please visit the official De'Longhi website or contact their customer support directly. Keep your proof of purchase for warranty claims.

Official De'Longhi Website: www.delonghi.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question