Taylor Swoden Dual Blaze Air Fryer XXL

Taylor Swoden Dual Blaze 8L Air Fryer User Manual

Model: Dual Blaze Air Fryer XXL (B302021XF-209789)

Introduction Safety Instructions Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Taylor Swoden Dual Blaze 8L Air Fryer. This manual provides essential information for the safe and efficient use of your appliance. Please read it thoroughly before first use and keep it for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

3. Product Overview and Components

The Taylor Swoden Dual Blaze 8L Air Fryer features a robust design with an all-metal inner chamber and a transparent viewing window for convenient cooking monitoring.



Image: Front view of the Taylor Swoden Dual Blaze 8L Air Fryer, showcasing its sleek design and viewing window.

Main Components:

- Main Unit with Control Panel
- Removable Cooking Basket
- Non-stick Crisper Plate
- Viewing Window
- Power Cord



Image: Diagram showing the all-metal inner chamber of the air fryer, designed for durability and odor elimination.

4. Setup and First Use

4.1 Unpacking

- Remove all packaging materials from the air fryer.
- Check that all components are present and undamaged.

4.2 Initial Cleaning

- Wipe the exterior of the air fryer with a damp cloth.
- Wash the cooking basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
- Dry all parts thoroughly before use.

4.3 Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance for proper ventilation.
- Do not place the air fryer directly against a wall or under cabinets during operation.

5. Operating Instructions

5.1 Control Panel Overview

The air fryer features an intuitive color touchscreen panel for easy operation.



Image: Detailed view of the air fryer's color touchscreen control panel, displaying various preset cooking functions and manual controls.

5.2 Basic Operation

1. **Power On:** Plug the power cord into a grounded wall outlet. The display will illuminate.
2. **Place Food:** Pull out the cooking basket, place the crisper plate inside, and then add your food. Do not overfill.
3. **Select Function:** Choose one of the 10 preset cooking programs or manually set the temperature and time.

4. **Adjust Settings:** Use the temperature (80-200°C) and time (1-60 minutes) adjustment buttons to customize settings if not using a preset.
5. **Start Cooking:** Press the Start/Pause button to begin cooking.
6. **Monitor Cooking:** Use the transparent viewing window to check food progress without opening the basket. The internal light can be activated via the control panel.
7. **End Cooking:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and remove food.

5.3 Preset Programs and Modes

The air fryer includes 10 preset cooking programs and 3 operational modes (Sauté, Crispy Roast, Bake) for various dishes. Select the desired icon on the touchscreen for automatic temperature and time settings, which can then be adjusted manually if needed.

5.4 Customizable Preheat Function

The air fryer offers a flexible preheat program. You can choose to preheat or not, and the system adjusts the time based on the target temperature, ensuring optimal cooking conditions.

5.5 Dual Heating System

This air fryer utilizes a Dual Heating System for 360° crispy results and faster cooking, reducing the need for shaking or turning food frequently.



Image: Illustration of the Dual Heating System, showing heat distribution for even cooking and crisping.

5.6 Cooking Capacity

With an 8-liter capacity, the air fryer can accommodate large portions, such as a whole chicken, making it suitable for families.



Image: Visual representation of the 8L capacity, showing various food items like a roasted chicken, fries, and vegetables that can be cooked.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

6.1 Cleaning After Each Use

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the cooking basket and crisper plate. These parts are dishwasher safe for easy cleaning. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
3. Wipe the interior of the air fryer with a damp cloth or sponge. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or scouring pads.
4. Clean the exterior of the appliance with a damp cloth.
5. Ensure all parts are completely dry before reassembling or storing.

6.2 Storage

Store the air fryer in a cool, dry place. Ensure the power cord is neatly wrapped and secured.

7. Troubleshooting

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on	Not plugged in; Power outlet malfunction; Appliance fault.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If the problem persists, contact customer support.
Food is not cooked evenly	Basket overloaded; Food not shaken/turned; Incorrect temperature/time.	Do not overload the basket. Shake or turn food halfway through cooking. Adjust temperature and time settings as needed.
White smoke coming from appliance	Grease residue from previous use; Fatty food being cooked.	Clean the basket and crisper plate thoroughly. For fatty foods, ensure the crisper plate is in place to drain excess fat.
Appliance emits unusual odor	New appliance odor; Food residue.	Initial use may produce a slight odor, which is normal. Ensure the appliance is clean. The all-metal inner chamber is designed to minimize odors.

8. Technical Specifications

Feature	Specification
Model Name	Dual Blaze™ Air Fryer XXL
Model Number	B302021XF-209789
Brand	Taylor Swoden
Capacity	8 Liters
Power	2000 Watts
Voltage	220 Volts (AC)
Control Method	Touchscreen
Temperature Range	60°C - 200°C
Timer	Up to 60 minutes
Dimensions (L x W x H)	37.7 x 28.8 x 35 cm
Non-stick Coating	Yes
Dishwasher Safe Parts	Cooking basket, Crisper plate



Image: Diagram illustrating the product dimensions (Length, Width, Height) of the Taylor Swoden Dual Blaze 8L Air Fryer.

9. Warranty and Support

Taylor Swoden products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Taylor Swoden website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Taylor Swoden customer service through the contact information provided on our website or in your product packaging.

© 2024 Taylor Swoden. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question