ATOZEE ATQ8Black

ATOZEE 7 Inch Android Tablet User Manual

Model: ATQ8Black | Brand: ATOZEE

1. Introduction

Thank you for choosing the ATOZEE 7 Inch Android Tablet. This compact and portable device is designed for a variety of uses, from entertainment to productivity. Featuring a responsive Quad-core processor, 32GB of internal storage (expandable up to 1TB), and 4GB of RAM, it offers a smooth multitasking experience. The 7-inch IPS HD touch screen provides clear visuals with a resolution of 1024x600 pixels. Equipped with dual cameras (2MP front, 5MP rear) and a 3000mAh battery, this tablet is suitable for everyday use, including browsing, media consumption, and video calls.

2. What's in the Box

- ATOZEE 7 Inch Android Tablet
- Charging Cable

3. Product Overview



Figure 3.1: Front and Rear View of the ATOZEE 7 Inch Android Tablet. This image displays the tablet from both the front, showing its

screen, and the back, highlighting its textured finish and rear camera placement.



Figure 3.2: Camera Capabilities. This image illustrates the tablet's 2MP front camera and 5MP rear camera, demonstrating their use for video calls and capturing moments.




Figure 3.3: Display Quality. This image highlights the 7-inch IPS FHD display with 1024x600 resolution, emphasizing its visual clarity for an excellent viewing experience.



Figure 3.4: Memory and Storage. This image showcases the tablet's 4GB RAM and 32GB ROM, along with its support for up to 1024GB TF card expansion for additional storage.

Physical Features:

- **Screen:** 7-inch IPS HD Touch Screen (1024x600 pixels)
- **Front Camera:** 2MP, located above the screen
- **Rear Camera:** 5MP, located on the back panel
- **Ports:** Includes a charging port and a microSD card slot for storage expansion.
- **Buttons:** Power button and volume controls.

4. Setup

4.1 Initial Charging

Before first use, fully charge your tablet using the provided charging cable and a compatible power adapter. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up and the ATOZEE logo appears.
- **To Power Off:** Press and hold the Power button until a power-off menu appears. Select 'Power off' and confirm.
- **To Restart:** From the power-off menu, select 'Restart'.

4.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Accept terms and conditions.
- Set up your Google account (recommended for full access to Google services like the Play Store).
- Set up screen lock (PIN, pattern, or password).

4.4 Inserting a MicroSD Card

The tablet supports microSD card expansion up to 1TB. To insert a card:

1. Locate the microSD card slot on the side of the tablet.
2. Gently insert the microSD card into the slot with the gold contacts facing down until it clicks into place.
3. The tablet will detect the new storage. You may be prompted to format the card for internal or portable storage.

5. Operating Instructions

5.1 Basic Navigation

The tablet uses a capacitive touch screen. Use the following gestures:

- **Tap:** To select an item or open an app.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through pages or lists.
- **Pinch-to-Zoom:** To zoom in or out on images or web pages.

5.2 Connecting to Wi-Fi

1. Go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted, then tap**Connect**.

5.3 Bluetooth Pairing

1. Go to **Settings** > **Connected devices** > **Connection preferences** > **Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure the device you wish to pair is in pairing mode.
4. Select the device from the 'Available devices' list and follow any on-screen prompts to complete pairing.

5.4 Using the Cameras

The tablet features a 2MP front camera and a 5MP rear camera.

- Open the **Camera** app.

- Tap the camera switch icon to toggle between front and rear cameras.
- Tap the shutter button to take a photo or start/stop video recording.

5.5 Downloading Apps

As a GMS certified Android tablet, you can download a wide variety of applications from the Google Play Store.

1. Open the **Play Store** app.
2. Search for the desired app using the search bar.
3. Tap **Install** on the app's page.
4. The app will download and install automatically.

5.6 Battery Management

The 3000mAh battery provides up to 8 hours of usage. To optimize battery life:

- Reduce screen brightness.
- Turn off Wi-Fi and Bluetooth when not in use.
- Close unused applications running in the background.
- Enable battery saver mode in **Settings** > **Battery**.

6. Maintenance

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals or abrasive materials.

6.2 Software Updates

Periodically check for system updates to ensure optimal performance and security.

- Go to **Settings** > **System** > **System update**.
- Follow the on-screen instructions to download and install any available updates. Ensure your tablet is sufficiently charged before starting an update.

6.3 Storage Management

To maintain performance, regularly manage your tablet's storage.

- Go to **Settings** > **Storage** to view storage usage.
- Uninstall unused apps.
- Clear cache data for apps.
- Move large files (photos, videos) to the microSD card or cloud storage.

6.4 Battery Care

- Avoid extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charging cable or a certified equivalent.

7. Troubleshooting

This section addresses common issues you might encounter with your ATOZEE tablet.

Problem	Possible Cause	Solution
Tablet does not turn on	Low battery; System crash	Charge the tablet for at least 30 minutes. Press and hold the power button for 10-15 seconds to force restart.
Slow performance/Lagging	Too many apps running; Low storage; Outdated software	Close background apps. Clear app caches. Free up storage space. Check for system updates. Restart the tablet.
Wi-Fi connection issues	Incorrect password; Router issue; Tablet Wi-Fi module issue	Ensure correct Wi-Fi password. Restart your Wi-Fi router. Forget the network and reconnect. Restart the tablet.
Apps crashing or not downloading	Insufficient storage; App incompatibility; Software glitch	Free up storage. Clear Play Store cache. Ensure app is compatible with Android 12.0. Restart tablet.
Touch screen unresponsive in corners	Software glitch; Screen protector interference	Restart the tablet. Remove any screen protectors to test if they are causing interference. Ensure screen is clean.
Poor signal reception (Wi-Fi/Bluetooth)	Interference; Distance from source	Move closer to the Wi-Fi router or Bluetooth device. Avoid physical obstructions. Check for other interfering devices.

8. Specifications

Feature	Specification
Model Name	ATQ8Black
Operating System	Android 12.0
Processor	Quad-core processor
RAM	4GB (2GB fixed + 2GB extended)
Internal Storage (ROM)	32GB
Expandable Storage	Supports up to 1TB microSD card
Screen Size	7 Inches
Screen Resolution	1024 x 600 pixels IPS HD
Front Camera	2MP
Rear Camera	5MP
Wireless Connectivity	WiFi 6 (802.11ac), Bluetooth
Battery Capacity	3000mAh Lithium Ion
Average Battery Life	Up to 8 hours

Feature	Specification
Dimensions (LxWxH)	8 x 0.3 x 5 inches
Item Weight	8 ounces
Color	Black

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

Seller: YINGJIE-US

For further assistance, you may also visit the product page on Amazon or contact Amazon customer service.

© 2025 ATOZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question