Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CLARION JM_FLEXON

CLARION JM-FLEXON Trolley 50 W Bluetooth Party Speaker User Manual

Model: JM_FLEXON
Brand: CLARION

1. Introduction

Thank you for choosing the CLARION JM-FLEXON Trolley 50 W Bluetooth Party Speaker. This portable mono channel speaker is designed to deliver powerful audio with versatile connectivity options, including Bluetooth, AUX, and USB. It features a guitar input and comes with two UHF microphones for karaoke and public address applications. Please read this manual carefully to ensure proper use and maintenance of your speaker.

2. Package Contents

Please check the box for the following items:

- 1 Pc Speaker Unit
- 1 Pc Remote Control
- 2 Pcs UHF Microphone

3. Product Overview

The JM-FLEXON speaker is a robust audio system built for portability and performance. It features a durable construction with an extendable trolley handle and wheels for easy transport. The top panel provides intuitive controls for various functions, including audio input selection, volume adjustments, and microphone settings.



Figure 3.1: Front view of the CLARION JM-FLEXON Trolley Speaker with included UHF microphones.



Figure 3.2: Detailed view of the top control panel, showing various knobs and buttons for audio adjustments and input selection.



Figure 3.3: Angled perspective of the speaker's top section, highlighting the integrated handle and control interface.





Figure 3.4: Rear view of the speaker, illustrating the extended trolley handle for convenient mobility.

4. Setup

1. **Unpacking:** Carefully remove the speaker and all accessories from the packaging.
2. **Initial Charging:** Before first use, it is recommended to fully charge the speaker. Connect the power cable to the DC 15V IN port on the speaker and plug it into a power outlet. The charging indicator will illuminate.
3. **Positioning:** Place the speaker on a stable, flat surface. Ensure adequate ventilation around the unit.
4. **Power On:** Locate the Power ON/OFF switch on the control panel and switch it to the 'ON' position. The display will light up.

5. Operating Instructions

5.1 Power On/Off

To power on the speaker, toggle the 'Power' switch to the 'ON' position. To power off, toggle the switch to the 'OFF' position.

5.2 Volume Control

Use the 'Volume' knob on the control panel to adjust the master volume of the speaker. Turn clockwise to increase volume and counter-clockwise to decrease.

5.3 Mode Selection

Press the 'MODE' button on the control panel or remote control to cycle through available input modes: Bluetooth (BT), AUX, USB, and FM Radio.

5.4 Microphone Usage

The speaker comes with two UHF microphones. Insert fresh batteries into the microphones. Turn on the microphones. Adjust the 'MIC VOL' knob to control the microphone volume and the 'ECHO' knob to add echo effect to the microphone sound.

5.5 Guitar Input

Connect your guitar to the 'GT IN' port using a 1/4" TRS cable. Adjust the 'GT VOL' knob to control the guitar input volume.

5.6 Equalizer Controls

Use the 'TREBLE' and 'BASS' knobs to fine-tune the audio output according to your preference. Turn clockwise to increase the respective frequency and counter-clockwise to decrease.

6. Connectivity

6.1 Bluetooth Pairing

1. Turn on the speaker and switch to Bluetooth mode using the 'MODE' button. The display will show 'BT'.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for available devices and select 'JM-FLEXON' from the list.
4. Once paired, the speaker will indicate a successful connection, and you can start playing audio wirelessly.

6.2 AUX Connection

Connect an external audio device (e.g., MP3 player, laptop) to the 'AUX IN' port using a 3.5mm TRS audio cable. Switch the speaker to AUX mode using the 'MODE' button.

6.3 USB Playback

Insert a USB flash drive containing MP3 audio files into the 'USB' port. The speaker will automatically switch to USB mode and begin playing the audio files. Use the playback controls (Play/Pause, Next, Previous) on the control panel or remote.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct

sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.
- **Ventilation:** Ensure that the speaker's ventilation openings are not blocked to prevent overheating.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Speaker not charged; Power switch off; Power cable loose	Charge the speaker; Turn power switch ON; Check power cable connection
No sound	Volume too low; Incorrect input mode; Audio cable not connected properly	Increase volume; Select correct input mode (BT/AUX/USB); Reconnect audio cable
Bluetooth not pairing	Speaker not in BT mode; Device Bluetooth off; Speaker too far from device	Switch speaker to BT mode; Enable Bluetooth on device; Move device closer to speaker
Microphone not working	Microphone off; Low microphone battery; MIC VOL too low	Turn on microphone; Replace batteries; Increase MIC VOL

9. Specifications

Feature	Detail
Model Number	JM_FLEXON
Speaker Type	Subwoofer, Mono Channel
Mounting Type	Floor Standing
Connectivity Technology	AUX, Bluetooth, USB
Audio Input	Guitar (1/4" TRS), AUX (3.5mm TRS)
Included Components	Speaker Unit, Remote Control, 2 UHF Microphones
Material	Engineered Wood, Metal, Plastic
Product Dimensions (LxWxH)	37 x 40.5 x 70.5 cm
Colour	Black
Compatible Devices	Smartphone, Tablet

10. Warranty and Support

This CLARION JM-FLEXON Trolley Speaker comes with a**1 Year Warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty.

For any product-related queries, technical assistance, or warranty claims, please contact CLARION Customer Care:
Customer Care: 8100-028-028
Manufacturer: Clarion Computers Private Limited

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D49PQKNB

More documents and user manuals: **https://manuals.plus/**