Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUARY A44

EUARY A44 Cordless Vacuum Cleaner Instruction Manual

Model: A44

1. Introduction

Thank you for choosing the EUARY A44 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance:

- Read all instructions before using the vacuum cleaner.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (e.g., chlorine bleach, ammonia cleaner, drain cleaner).
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

- Use extra care when cleaning on stairs.
- Do not charge the unit outdoors.
- Only use the charger supplied by the manufacturer.

3. Package Contents

Please check the package for the following components:

- Main Vacuum Body
- Extension Wand
- Motorized Floor Brush (Series 5)
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount Dock
- Power Adapter
- User Manual

4. Product Diagram

Familiarize yourself with the parts of your EUARY A44 Cordless Vacuum Cleaner.



Image: Overview of the EUARY A44 Cordless Vacuum Cleaner, highlighting its 600W motor and 55KPa suction power. The image displays the main unit, extension tube, and floor brush, with an inset showing the internal motor components.

5. Setup and Assembly

1. **Charging the Battery:** Before first use, fully charge the vacuum cleaner. Connect the power adapter to the charging port on the main body and plug it into a wall outlet. The animated color screen will indicate charging status.
2. **Assembling the Vacuum:**
   - Insert the extension wand into the main vacuum body until it clicks securely.

- Attach the motorized floor brush to the other end of the extension wand until it clicks.
- For handheld use, attach desired accessories (crevice tool, 2-in-1 brush) directly to the main vacuum body.

3. **Wall Mount Installation:** Choose a suitable location near a power outlet. Secure the wall mount dock to the wall using the provided screws and anchors.



Image: Diagram illustrating the internal battery structure of the EUARY A44, showing 8x3000mAh cells and indicating a runtime of up to 60 minutes on a single charge.

6. Operating Instructions

1. **Power On/Off:** Press the power button on the handle to turn the vacuum cleaner on or off.
2. **Adjusting Suction Power:** The vacuum features 3 suction speeds. Press the mode button to cycle through Eco, Mid, and Max power settings. The animated color screen will display the current mode.
3. **Using the Floor Brush:** The motorized floor brush is suitable for various floor types, including carpets and hard floors. Its anti-tangle design helps prevent hair from wrapping around the roller.
4. **Monitoring Status:** The intelligent OLED color screen provides real-time information on battery level, current suction mode, and alerts for brush or airway blockages.



Image: A user operating the EUARY A44 Cordless Vacuum Cleaner, with an inset showing the intelligent OLED color screen displaying icons for Eco, Mid, Max modes, battery level, and blockage alerts.



Image: Detailed view of the upgraded Series 5 floor brush, demonstrating its effectiveness on both hard floors and carpets. The image highlights the brush's anti-hair tangle features and suction capabilities.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. **Emptying the Dust Cup:** Press the release button to detach the dust cup from the main body. Open the bottom lid and empty contents into a trash bin. Close the lid and reattach the dust cup.
2. **Cleaning Filters:** The vacuum features an 11-level H13 HEPA filtration system. Regularly remove and clean the

stainless steel filter, cyclone filter, and HEPA filter. Rinse with water and ensure they are completely dry before reassembling.

3. **Cleaning the Floor Brush:** Periodically check the motorized floor brush for tangled hair or debris. Use scissors or a cleaning tool to remove any obstructions from the roller.



Image: The EUARY A44 Cordless Vacuum Cleaner's large 1600ml dust cup being emptied, demonstrating the easy-release mechanism for debris disposal.



Image: An exploded view diagram illustrating the 11-level filtration system of the EUARY A44, including the H13 HEPA filter, designed to capture 99.99% of fine dust and efficiently separate dirt.

8. Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged.	Charge the battery fully.

Problem	Possible Cause	Solution
Low suction power.	Dust cup is full; Filters are clogged; Airway is blocked.	Empty the dust cup; Clean or replace filters; Check for blockages in the extension wand or floor brush.
Floor brush stops rotating.	Hair or debris tangled in the brush; Brush motor overloaded.	Clean the floor brush roller; Turn off and restart the vacuum.
Short battery runtime.	Battery not fully charged; Battery degradation over time.	Ensure battery is fully charged before use; Contact support if runtime significantly decreases.

9. Specifications

- **Brand:** EUARY
- **Model Number:** A44
- **Power:** 600 Watts
- **Maximum Suction:** 55 KPa
- **Voltage:** 220 Volts
- **Number of Speeds:** 3
- **Battery:** 8x3000 mAh (Integrated)
- **Runtime:** Up to 60 minutes (Eco mode)
- **Filter Type:** H13 HEPA Cyclonic Filter
- **Dust Cup Capacity:** Not explicitly stated in JSON, but images suggest large capacity.
- **Special Features:** High-power motor, long battery life, H13 HEPA filtration, animated color screen, anti-hair tangle brush.
- **Recommended Surface:** All floors
- **Item Weight:** 3.9 Kilograms
- **Package Dimensions:** 43.5 x 32.5 x 19.2 cm

10. Warranty and Support

EUARY provides continuous product maintenance service. If you encounter any issues with your EUARY A44 Cordless Vacuum Cleaner, please do not hesitate to contact our customer support. We are committed to providing effective solutions to resolve your concerns.
For assistance, please refer to the contact information provided with your purchase or visit the official EUARY website.

© 2024 EUARY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4DQHCCF

More documents and user manuals: **https://manuals.plus/**