Uetmulik CTR 4UHR2 01 BP

Uetmulik Power Recliner Hand Control

Model: CTR 4UHR2 01 BP

User Manual

Introduction

This manual provides comprehensive instructions for the Uetmulik Power Recliner Hand Control, Model CTR 4UHR2 01 BP. This replacement control unit is designed for lift chairs and electric sofas equipped with power recline, power lumbar, and heat functions. It also includes a convenient USB charging port. Please read this manual thoroughly before installation and operation to ensure proper function and safety.

Safety Information

Important Safety Precautions:

- Always unplug the chair before installing or removing the replacement part.
- Keep children and pets away from the chair during operation and maintenance.
- Do not attempt to repair or modify the chair's electrical components.
- If you're unsure about any aspect of the installation or operation, consult a professional.

Package Contents

Verify that all items are present in your package:

- 1 x Uetmulik Power Recliner Hand Control (Model CTR 4UHR2 01 BP)
- 1 x USB Cable (integrated)



Image: The Uetmulik Power Recliner Hand Control unit with its attached cables, ready for installation.

Setup and Installation

Before beginning installation, ensure the power recliner or sofa is unplugged from the wall outlet.

1. **Identify Connections:** Locate the existing hand control's connection points on your recliner. The Uetmulik CTR 4UHR2 01 BP control features a 5-pin male connection and a 6-pin lock connection. Ensure these match your chair's existing ports.



Image: Detailed view of the 5-pin male connector and the 6-pin lock connector on the control unit's cables.

2. **Disconnect Old Control:** Carefully disconnect the old hand control from your recliner. Note the orientation of the connectors.
3. **Connect New Control:** Align the 5-pin male connector from the new hand control with the corresponding port on your recliner and push firmly until it clicks into place. Repeat for the 6-pin lock connection.



Image: A close-up view of the 6-pin lock connector, showing its internal pin configuration.

4. **Secure Cables:** Route the cables neatly to prevent them from being pinched or tangled during chair operation.
5. **Power On:** Once connections are secure, plug the recliner back into the wall outlet.

Operating Instructions

The hand control features three primary buttons and a USB charging port.



Image: The control panel of the hand control, displaying the three control buttons and the integrated USB charging port.

- **Recline/Incline Control:** The buttons on the control panel are typically used to adjust the recline position of the chair, as well as the power lumbar and power headrest functions. Press and hold the appropriate button to move the chair to your desired position. Release the button to stop movement.
- **Heat Function:** If your chair supports a heat function, one of the buttons may activate or deactivate it. Refer to your chair's specific manual for details on button assignments.
- **USB Charging Port:** The integrated USB port allows you to charge compatible electronic devices, such as smartphones or tablets. Simply connect your device's USB charging cable to the port on the hand control.

Maintenance

To ensure the longevity and proper function of your hand control:

- **Cleaning:** Wipe the surface of the hand control with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the plastic.
- **Cable Inspection:** Periodically check the cables for any signs of wear, fraying, or damage. If damage is observed, discontinue use and replace the control unit.
- **Avoid Liquid Exposure:** Keep the hand control away from liquids to prevent electrical damage.

Troubleshooting

If you encounter issues with your hand control, try the following steps:

- **Control Not Responding:**
  - Ensure the recliner is securely plugged into a working power outlet.
  - Check all cable connections between the hand control and the chair's motor system. Disconnect and reconnect them to ensure a firm connection.
  - Verify that the 5-pin and 6-pin connectors are correctly inserted and not damaged.

- **USB Port Not Charging:**
  - Confirm the recliner is powered on and plugged into an active outlet.
  - Try a different USB cable or device to rule out issues with the charging cable or device.
  - Ensure the USB cable is fully inserted into the port.
- **Intermittent Functionality:**
  - Inspect cables for any visible damage, kinks, or pinches.
  - Ensure the connections are not loose.

If problems persist after attempting these troubleshooting steps, contact customer support or a qualified technician.

Specifications

Feature	Detail
Model Number	CTR 4UHR2 01 BP
Brand	Uetmulik
Manufacturer	Raffel Systems
Color	Black
Material	Plastic
Item Weight	8 ounces
Size (Control Unit)	Approximately 7 x 9 x 2.5 inches (overall dimensions, refer to image for specific control panel size)
Cable Length	5.1ft and 4.3ft (dual cables)
Connections	5 Pin Male, 6 Pin Lock
Features	Power Recline, Power Lumbar, Heat, USB Charging Port



Image: The hand control unit with an overlay indicating its approximate length of 10.5 cm / 4.1 inches.


MOD: CTR 4UHR2 01 BP
PO# CN008679 10/23
PATENT PENDING
MADE IN CHINA A1

Image: A close-up of the label attached to the cable, showing "MOD: CTR 4UHR2 01 BP" and manufacturing details.

Warranty Information

Specific warranty details for this product may vary. Please refer to the product packaging or contact the seller directly for information regarding warranty coverage and terms.

Customer Support

For further assistance, technical support, or inquiries regarding your Uetmulik Power Recliner Hand Control, please contact the seller through the platform where the purchase was made. Provide your order number and product model (CTR 4UHR2 01 BP) for faster service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question