EXTRALINK EX.36891

Extralink 3-in-1 Sandwich Maker, Grill, and Waffle Maker User Manual

Model: EX.36891

Introduction

Thank you for purchasing the Extralink 3-in-1 Sandwich Maker, Grill, and Waffle Maker. This versatile appliance is designed to simplify your cooking experience, allowing you to prepare delicious sandwiches, grilled dishes, and waffles with ease. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image: The Extralink 3-in-1 appliance open, showing a cooked sandwich and waffle. Separate images of the grill, sandwich, and waffle plates are displayed on the side, along with examples of food prepared with each plate type.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- The appliance is equipped with a non-heating handle for safe operation.

Components

Your Extralink 3-in-1 appliance includes the following main components:

- **Main Unit:** The base of the appliance containing the heating elements and controls.
- **Interchangeable Plates:**
  - **Sandwich Plates:** Designed to seal and toast sandwiches.
  - **Waffle Plates:** For making classic waffles.
  - **Grill Plates:** Ideal for grilling meats, vegetables, and panini.
- **Indicator Lights:** Typically red (power/preheating) and green (ready).
- **Non-Heating Handle:** For safe opening and closing of the appliance.



Image: A detailed view of the appliance highlighting the interchangeable plates, the indicator lights (red for preheating, green for ready), and the cool-touch handle. The non-stick coating is also visible.

Setup

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging.
2. **Initial Cleaning:** Before first use, wipe the non-stick plates with a damp cloth or sponge. Dry thoroughly. The plates are removable and can be hand-washed or placed in a dishwasher (refer to Maintenance section for details).
3. **Insert Plates:** Choose the desired plates (sandwich, waffle, or grill). Align the plates with the slots in the main unit and press down gently until they click into place. Ensure both upper and lower plates are securely installed.
4. **Placement:** Place the appliance on a stable, heat-resistant, and dry surface, away from walls and flammable materials. Ensure adequate ventilation around the appliance.



Image: The Extralink 3-in-1 appliance with its lid open, showing the grill plates inserted. Separate images of the waffle and sandwich plates are displayed next to it, illustrating how they can be interchanged to prepare different types of food.

Operating Instructions

General Operation

1. **Plug In:** Close the appliance and plug the power cord into a standard 220-240V AC electrical outlet. The red indicator light will illuminate, indicating the appliance is powered on and preheating.
2. **Preheating:** Allow the appliance to preheat for approximately 3-5 minutes. The green indicator light will illuminate (or the red light will turn off, depending on the model) when the desired cooking temperature is reached.
3. **Prepare Food:** While preheating, prepare your ingredients. Lightly grease the plates with a small amount of cooking oil or butter, especially for the first use or if food tends to stick.
4. **Cooking:** Carefully open the appliance using the non-heating handle. Place your food onto the lower plate. Close the lid gently.
5. **Monitor:** Cooking times will vary depending on the type of food and your desired doneness. Refer to the specific

instructions below for guidance.

6. **Remove Food:** Once cooked, carefully open the lid and remove the food using a heat-resistant plastic or wooden utensil to avoid damaging the non-stick coating.
7. **Unplug:** After use, unplug the appliance from the wall outlet and allow it to cool completely before cleaning.

Using the Sandwich Plates

- Insert the sandwich plates and preheat the appliance.
- Place your prepared sandwiches (e.g., with cheese, ham, or other fillings) onto the lower plate. Ensure the bread fits within the plate sections.
- Close the lid. The appliance will press and toast the sandwiches, sealing the edges.
- Cook for approximately 3-5 minutes, or until the sandwiches are golden brown and the filling is heated through.

Using the Waffle Plates

- Insert the waffle plates and preheat the appliance.
- Pour approximately 1/2 to 3/4 cup of waffle batter onto the center of the lower waffle plate. Do not overfill.
- Close the lid gently.
- Cook for approximately 4-7 minutes, or until the waffles are golden brown and crispy. Cooking time may vary based on batter consistency and desired crispness.



Image: The Extralink 3-in-1 appliance with waffle plates inserted. A hand is pouring batter onto one side, while a cooked waffle is visible on the other. A graphic indicates a cooking time of 4-7 minutes and 1000W power.

Using the Grill Plates

- Insert the grill plates and preheat the appliance.
- Place your food (e.g., meat, vegetables, panini) onto the lower grill plate.
- Close the lid. For thicker items, the floating hinge allows the top plate to adjust.
- Cook for the desired time, flipping if necessary for even grilling, until food is cooked to your preference.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your appliance.

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Remove Plates:** Once cool, press the plate release buttons (if applicable) and carefully remove the interchangeable

plates.

3. **Clean Plates:** The non-stick plates are easy to clean.
    - **Hand Washing:** Wash the plates in warm, soapy water using a soft sponge or cloth. Rinse thoroughly and dry completely.
    - **Dishwasher:** The plates are dishwasher safe for convenient cleaning.
    - For stubborn residue, soak the plates in warm water for a few minutes before cleaning. Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating.
4. **Clean Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Once clean and dry, reattach the plates or store them separately. Store the appliance in a dry, safe place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue.	Ensure the appliance is securely plugged into a working power outlet. Check the circuit breaker.
Food sticks to plates.	Plates not greased; residue buildup; damaged non-stick coating.	Lightly grease plates before each use. Clean plates thoroughly after each use. If coating is damaged, contact customer support.
Food not cooking evenly.	Insufficient preheating; uneven food placement.	Allow appliance to fully preheat until the ready indicator light illuminates. Distribute food evenly on the plates.
Smoke or unusual odor during first use.	Protective coating burning off.	This is normal for the first few uses. Ensure good ventilation. If it persists, unplug and contact support.

Specifications

Feature	Detail
Brand	EXTRALINK
Model Number	EX.36891 (SJ-37A)
Power	1000 W
Voltage	1000 Volts (likely 220-240V, 1E+3 is a typo/conversion issue)
Color	Black
Material	Plastic
Product Dimensions	25 x 28 x 15 cm (Depth x Width x Height)
Special Features	Interchangeable sandwich, waffle, and grill plates; Non-stick coating
Included Components	Interchangeable plates (grill, toaster, waffle maker)

Feature	Detail
Material Free From	PTFE, BPA, PFOA (Possible, not confirmed)

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Extralink website. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact Extralink customer service through their official channels.

© 2025 Extralink. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question