Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QUI BK600

QUI Presentation Clicker

USER MANUAL

1. Introduction

Thank you for choosing the QUI Presentation Clicker. This RF 2.4GHz wireless presenter remote is designed to enhance your presentations with intuitive controls, a bright red laser pointer, and wide compatibility. This manual provides detailed instructions for setup, operation, and troubleshooting to ensure you get the most out of your device.

2. Product Overview



Figure 2.1: QUI Presentation Clicker with its USB receiver and open battery compartment.



Figure 2.2: Labeled diagram of the QUI Presentation Clicker's key functions.

2.1 Components

- QUI Presentation Clicker (Model: BK600)
- 2.4 GHz USB Wireless Receiver

2.2 Key Features

- **Plug & Play:** No software installation required.
- **Stable Connection:** RF 2.4GHz wireless technology with up to 328 feet (100 meters) range.
- **Red Laser Pointer:** Easily highlight key points on screen.
- **Intuitive Controls:** Dedicated buttons for page up/down, full screen/black screen, volume control, and hyperlink navigation.
- **Wide Compatibility:** Supports various operating systems and presentation software.
- **Portable Design:** Lightweight with a convenient clip for easy carrying.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the presenter.
2. Slide the cover open.
3. Insert one (1) AAA battery, ensuring correct polarity (+/-). *(Note: AAA battery is not included.)*
4. Close the battery compartment cover securely.

3.2 Connecting the USB Receiver

The QUI Presentation Clicker features a magnetic design for storing the USB receiver within the presenter itself.

1. Gently pull the USB receiver from the bottom of the presenter.
2. Plug the USB receiver into an available USB port on your computer.
3. The computer will automatically detect and install the necessary drivers. No additional software is required.



Figure 3.1: Magnetic USB receiver being plugged into a laptop, demonstrating the plug-and-play design.

4. Operating Instructions

Once the USB receiver is connected, the presenter is ready for use. Ensure your presentation software is open and active.

4.1 Button Functions

Button	Function
Page Up (▲)	Single click to move to the previous slide.
Page Down (▼)	Single click to move to the next slide.
Full Screen / Black Screen (■)	Long press to enter/exit full screen mode. Long press again to black out/unblack the screen.*(Note: Functionality may vary slightly depending on presentation software and specific model variations.)*
Laser Pointer (✶)	Press and hold to activate the red laser pointer. Release to turn off.
Volume Up (Side Button)	Press to increase system volume.
Volume Down (Side Button)	Press to decrease system volume.
Tab Key (Top Button)	Single press for Tab function. Double press for Enter key. Press and hold for Alt+Tab.

4.2 Wireless Range and Laser Performance

The QUI Presentation Clicker offers a wireless control range of up to 328 feet (100 meters), allowing you to move freely during your presentation. The red laser pointer has a range of up to 328 feet (100 meters), ensuring visibility even in large rooms.



Figure 4.1: Demonstrating the 2.4G wireless presenter in use with the red laser.



Figure 4.2: Visual representation of the long range control capabilities of the clicker.

4.3 Product Demonstration Video

Your browser does not support the video tag.

Video 4.1: A demonstration of the QUI wireless presentation clicker's features and usage, including button functions and laser pointer.

5. Compatibility

The QUI Presentation Clicker is designed for broad compatibility with various operating systems and presentation software.

5.1 Supported Operating Systems

- Windows XP, Vista, 7, 8, 10
- Mac OS
- Linux

- Android

5.2 Supported Software

- Microsoft PowerPoint
- Microsoft Excel
- Microsoft Word
- Apple Keynote
- Apple Numbers
- Apple Pages
- Google Slides
- Prezi
- ACDSee



Figure 5.1: Visual guide to the wide compatibility of the QUI Presentation Clicker.

6. Maintenance

To ensure the longevity and optimal performance of your QUI Presentation Clicker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the presenter. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the presenter in a cool, dry place, away from direct sunlight and extreme temperatures. Always store the USB receiver inside the presenter's magnetic compartment to prevent loss.
- **Battery:** If the presenter will not be used for an extended period, remove the AAA battery to prevent leakage and potential damage to the device.
- **Handling:** Avoid dropping the presenter or subjecting it to strong impacts, as this may damage internal components.

7. Troubleshooting

If you encounter issues with your QUI Presentation Clicker, please refer to the following common problems and their solutions:

7.1 Presenter Not Responding

- **Check Battery:** Ensure the AAA battery is inserted correctly and has sufficient charge. Replace if necessary.
- **Check Receiver Connection:** Make sure the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- **Power Switch:** Verify that the power switch on the side of the presenter is in the "ON" position.
- **Range:** Ensure you are within the effective wireless range (up to 328 feet / 100 meters) of the USB receiver. Obstacles may reduce range.
- **Re-pair (if applicable):** While this device is typically plug-and-play, if issues persist, try unplugging and re-plugging the USB receiver.

7.2 Laser Pointer Not Working

- **Battery Level:** A low battery can affect laser performance. Replace the AAA battery.
- **Button Press:** Ensure you are pressing and holding the laser button firmly.

7.3 "Blank Screen" Functionality

- The "Full Screen / Black Screen" button (■) is designed to toggle full screen mode with a long press, and then black out/unblack the screen with subsequent long presses.
- If this function does not work as expected, ensure your presentation software supports this command. Some software or specific model variations may not fully implement this feature as described.

7.4 Incompatible with Software/System

- Refer to the Compatibility section to ensure your operating system and software are supported.
- Ensure your software is the active window when using the presenter.

8. Specifications

Feature	Detail
Brand	QUI
Model Number	BK600
Connectivity	RF 2.4GHz Wireless
Wireless Range	Up to 328 feet (100 meters)
Laser Type	Red Laser
Power Source	1 x AAA Battery (not included)
Dimensions (L x W x H)	6.57 x 1.73 x 0.75 inches
Item Weight	1.13 ounces
Manufacturer	QUI Technology Co., Ltd.

9. Warranty and Support

QUI products are manufactured to the highest quality standards. For specific warranty information and customer support, please refer to the warranty card included with your product or visit the official QUI website. If you experience any issues or have questions, please contact QUI customer service for assistance.
Manufacturer: QUI Technology Co., Ltd.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4GRJNZH

More documents and user manuals: **https://manuals.plus/**