Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-629

PINDOWS Women's Digital Sports Watch

Model: PDS-629

Introduction

Thank you for choosing the PINDOWS PDS-629 Women's Digital Sports Watch. This multi-functional timepiece is designed for active individuals, offering robust features and a stylish appearance suitable for both daily wear and various indoor and outdoor activities. Please read this manual carefully to understand the watch's functions and ensure proper use and maintenance.


PINDOWS
LIGHT
START
MODE
RESET
WR 50M
SPL
ALM
PINDOWS
12:43 58
WR 50M

Figure 1: PINDOWS PDS-629 Digital Sports Watch (Green)

Key Features

- **Multi-functional Display:** Features an automatic calendar, LED backlight, alarm, 12/24-hour format, hourly chime, and stopwatch.
- **50M Water Resistance:** Designed to withstand splashes, rain, and brief immersion. *Note: Avoid exposure to steam or hot water, and do not operate buttons underwater.*
- **Stylish Design:** Available in 8 vibrant colors with a modern sports dial, enhancing your personal style.
- **High Brightness LED:** Ensures clear time readability even in low-light conditions or during rainy weather.
- **Durable Construction:** Equipped with a long-lasting Japanese battery (up to 2 years), high-quality TPU band, robust ABS case, and a clear plexiglass mirror.
- **Comfort and Resilience:** Offers a comfortable wearing experience, with shock-resistant and drop-resistant properties, high transparency, pressure resistance, and wear resistance.



Figure 2: Watch showcasing its stylish design

Product Specifications

Specification	Detail
Battery	1 CR2032 battery (included)
Product Size	4.4 x 3.6 x 1.35 cm
Weight	110 g
Manufacturer	PINDOWS
Product Model Number	PDS-629
Department	Womens
Band Material	TPU
Case Material	ABS
Bottom Cover Material	Stainless Steel
Case Diameter	1.7 inch / 43 mm
Case Thickness	0.65 inch / 16.5 mm
Band Width	0.78 inch / 20 mm
Band Length	6.9 inch - 8.7 inch



Figure 3: Product Parameters and Dimensions

Setup Guide

Your PINDOWS watch comes with several buttons for various functions. Familiarize yourself with the button layout:



Figure 4: Watch Button Layout and Functions

1. Time and Date Setting

1. In normal time display mode, press the **MODE** button repeatedly until the seconds begin to flash.
2. Press the **RESET** button to cycle through the setting options: Seconds → Hour → Minute → Month → Date → Day of Week.
3. Use the **START** button to adjust the flashing value.
4. Once all settings are complete, press the **MODE** button to exit setting mode.

2. Alarm Setting

1. From normal time display, press the **MODE** button twice to enter Alarm Mode.
2. The hour digits will flash. Use the **START** button to set the desired alarm hour.
3. Press the **RESET** button to move to the minute digits, then use the **START** button to set the desired alarm minute.
4. Press **MODE** to exit Alarm Setting Mode.

5. To activate/deactivate the alarm, press **START** and **RESET** simultaneously in Alarm Mode. An alarm icon will appear/disappear.

3. 12/24 Hour Format

In normal time display mode, press the **RESET** button to toggle between 12-hour (AM/PM indicator) and 24-hour formats.

Operating Instructions

1. LED Backlight

Press the **LIGHT** button (top left) to illuminate the display. The backlight will stay on for a few seconds, making it easy to read the time in dark environments.



Figure 5: LED Backlight in action

2. Stopwatch Function

1. From normal time display, press the **MODE** button once to enter Stopwatch Mode. The display will show '00:00:00'.

2. Press the **START** button to begin timing.
3. Press **START** again to pause the stopwatch. Press **START** to resume.
4. To reset the stopwatch to zero, press **RESET** while the stopwatch is paused.
5. Press **MODE** to return to normal time display.

3. Hourly Chime

To activate or deactivate the hourly chime, press and hold the **RESET** button while in normal time display mode. A chime icon will appear/disappear on the display to indicate its status.

Water Resistance Guidelines

Your PINDOWS watch is rated for 50 meters (5ATM) water resistance. This means it is suitable for daily use, hand washing, rain, and brief immersion in water. However, it is important to adhere to the following guidelines to prevent damage:

- Do not press any buttons while the watch is submerged in water.
- Avoid exposing the watch to hot water, steam, or saunas. Extreme temperature changes can compromise the watch's seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.



Figure 6: Watch demonstrating 50M water resistance

Maintenance and Care

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Chemicals:** Avoid contact with solvents, detergents, perfumes, and cosmetics, as these can damage the watch band and case.
- **Battery Replacement:** When the display dims or functions become erratic, it may be time to replace the CR2032 battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure water resistance is maintained.



Figure 7: Watch back cover detail

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the CR2032 battery.
Buttons are unresponsive.	Watch is in an incorrect mode or internal malfunction.	Try pressing the MODE button repeatedly to cycle through modes. If issue persists, contact support.
Time is inaccurate.	Incorrect setting or low battery.	Re-set the time following the 'Time and Date Setting' instructions. Consider battery replacement if problem recurs.
Water inside the watch.	Water resistance compromised due to improper use (e.g., pressing buttons underwater, exposure to hot water).	Immediately stop using the watch and seek professional repair. Water damage is typically not covered under warranty if guidelines are not followed.

Warranty and Support

PINDOWS values its customers and provides a **12-month warranty service** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or failure to follow the water resistance guidelines.

For warranty claims, technical support, or any inquiries regarding your PINDOWS watch, please contact our customer service team through the platform where you purchased the product. We are committed to providing products and services that satisfy our customers.

© 2024 PINDOWS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4JP78BK

More documents and user manuals: **https://manuals.plus/**