Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum AR2076-S

Arzum Airtasty Smart Air Fryer User Manual

Model: AR2076-S

1. Introduction

Thank you for choosing the Arzum Airtasty Smart Air Fryer. This appliance is designed to provide a healthy and convenient way to cook your favorite meals with less oil. Featuring a large 7.5-liter capacity, digital touch control, and smart IoT connectivity, it offers versatility and ease of use for various recipes.
Please read this manual carefully before using the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and extend the life of your air fryer.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Do not place anything on top of the appliance.
- Do not use the appliance for any purpose other than described in this manual.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- The appliance is intended for household use only.

3. Product Components

Familiarize yourself with the parts of your Arzum Airtasty Smart Air Fryer:



Main Unit: Houses the heating element, fan, and control panel. Features a digital display and touch controls for temperature and time settings. The front includes a transparent glass panel to monitor cooking progress.



Removable Basket: The primary cooking container, designed with a non-stick coating for easy food release and cleaning. It has a handle for safe removal.



Grill Rack: An accessory that fits inside the basket, ideal for grilling smaller items or elevating food for better air circulation.



Cake Pan: An additional accessory for baking items like brownies or small cakes within the air fryer.

4. Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials from the air fryer.

2. **Cleaning:** Before first use, clean the basket and any accessories (grill rack, cake pan) with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm of free space around the appliance for proper ventilation.
4. **Preheating (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell may be present, which is normal and will dissipate.

5. Operating Instructions

Basic Operation

1. Plug the power cord into a grounded wall outlet.
2. Pull the basket out of the air fryer. Place your ingredients inside the basket. Do not exceed the MAX fill line.
3. Slide the basket back into the air fryer.
4. The digital display will illuminate. Use the touch controls to set the desired temperature and cooking time. The air fryer features 7 automatic cooking programs for common foods.
5. Press the Start/Pause button to begin cooking.
6. During cooking, you can pull out the basket to shake or flip ingredients. The air fryer will automatically pause and resume when the basket is reinserted.
7. Once the cooking time is complete, the air fryer will beep and automatically shut off. Carefully pull out the basket and empty the cooked food.

Smart Features (IoT Connectivity)

The Arzum Airtasty Smart Air Fryer can be controlled remotely via IoT technology. Refer to the dedicated mobile application instructions for pairing your device and utilizing smart cooking functions from anywhere.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your air fryer.

- **Before Cleaning:** Always unplug the air fryer and allow it to cool down completely before cleaning.
- **Basket and Accessories:** The removable basket, grill rack, and cake pan are dishwasher safe. For manual cleaning, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes.
- **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Never immerse the main unit in water or any other liquid. Clean the interior with a damp cloth and mild detergent if necessary.
- **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.
- **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet.
Food is not cooked evenly.	Too much food in the basket; food not shaken/flipped.	Cook in smaller batches; shake or flip ingredients halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use; high-fat ingredients.	Clean the basket and heating element thoroughly. For high-fat foods, drain excess oil.
Food is not crispy.	Not enough oil; temperature too low; cooking time too short.	Lightly coat food with oil; increase temperature or cooking time.

8. Technical Specifications

Brand: Arzum

Model: AR2076-S

Color: Black

Capacity: 7.5 Liters

Power: 1750 Watts

Material: Plastic

Dimensions (D x W x H): 39 x 40 x 44 cm

Weight: 5 Kilograms

Special Features: Temperature Control, Automatic Shut-off, Digital Display, Touch Control, IoT Connectivity

9. Warranty and Support

The expected product life for the Arzum Airtasty Smart Air Fryer is**3 years** from the date of purchase invoice.
Please retain your purchase receipt as proof of purchase for any warranty claims.
For technical support, service, or further inquiries, please contact Arzum customer service through the contact information provided on your product packaging or the official Arzum website.

© 2024 Arzum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4K68XPQ

More documents and user manuals: **https://manuals.plus/**