Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alupssuc RH-120-1700U4-1

Alupssuc 8FT Christmas Inflatable with LED Countdown Clock: Snowman, Santa, and Gingerbread Man Instruction Manual

Model: RH-120-1700U4-1 | Brand: Alupssuc

Important Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Keep the inflatable away from all heat sources, including open flames, heaters, and direct sunlight for prolonged periods.
- Ensure proper ventilation around the blower to prevent overheating. Do not obstruct the air intake or exhaust.
- Securely anchor the inflatable using the provided stakes and ropes to prevent it from becoming a projectile in high winds or adverse weather conditions.
- Do not operate the inflatable in extreme weather, such as heavy rain, snow, or strong winds.
- Keep children and pets away from the inflatable during inflation and deflation to prevent entanglement or injury.
- Always unplug the inflatable when not in use or during maintenance.
- Inspect the power cord and plug regularly for any signs of damage. Do not use if damaged.

Package Contents

Verify that all components are present before assembly:

- 1 x 8FT Christmas Inflatable (Snowman, Santa, Gingerbread Man with LED Countdown Clock)
- 1 x Blower (Premium Fan for quick inflation)
- 7 x Ground Stakes
- 3 x Ropes
- 1 x 3m Long Power Cord
- 1 x Instruction Manual (This document)
- 1 x Storage Box



Figure 1: Included components for the Alupssuc Christmas Inflatable.

Setup Instructions

Follow these steps to set up your Alupssuc Christmas Inflatable:

1. **Unpack:** Carefully remove the inflatable and all accessories from the storage box.
2. **Position:** Choose a flat, clear area in your yard or indoor space, free from sharp objects or debris.
3. **Unfold:** Lay the inflatable flat on the ground, ensuring the fabric is spread out and not tangled.
4. **Secure Zipper:** Locate the zipper at the bottom of the inflatable and ensure it is fully closed to prevent air leakage during inflation.
5. **Connect Blower:** Ensure the blower is upright and connected to the inflatable's air intake.
6. **Power On:** Plug the power cord into a suitable outdoor-rated electrical outlet. The inflatable will begin to inflate automatically.

7. **Anchor:** Once fully inflated, use the provided ground stakes to secure the base of the inflatable to the ground. Attach the ropes to the designated loops on the inflatable and secure them to additional stakes in the ground, pulling taut to maintain stability.



Figure 2: Securing the inflatable with ground stakes and ropes.



Figure 3: Visual guide for inflatable setup steps.

Operating Instructions

LED Christmas Countdown Clock

The integrated LED countdown clock allows you to display the remaining days until Christmas. Follow these steps to set the countdown:

1. **Remove Insulation:** Before first use, locate and remove the transparent insulating piece from the countdown clock unit.
2. **Connect DC Cable:** Ensure the DC cable for the countdown clock is properly connected.
3. **Start Setting:** Press the "SET" button for 3 seconds to enter the setting mode. The year (yr) will flash.
4. **Set Year:** Press "+" or "-" to adjust the year.
5. **Set Month:** Press "SET" to switch to the Month (M) interface. Press "+" or "-" to adjust the month.
6. **Set Day:** Press "SET" to switch to the Day (D) interface. Press "+" or "-" to adjust the day.
7. **Set Hour:** Press "SET" to switch to the Hour (H) interface. Press "+" or "-" to adjust the hour.
8. **Set Minute:** Press "SET" to switch to the Minute (Min) interface. Press "+" or "-" to adjust the minute.
9. **Set Second:** Press "SET" to switch to the Second (Sec) interface. Press "+" or "-" to adjust the second.
10. **Exit Setting:** After completing all steps, press the "SET" button to exit the setting mode. The countdown timer (CDT) will flash, indicating the settings are saved and the countdown has started.

The countdown time can be set for up to 98 days (e.g., from September 19th to December 25th).

How to use the countdown clock



1. Remove the transparent insulation sheet



2. Connect the DC cable



3. Start setting the countdownt time

Steps for setting countdown clock

1. press the " SET" for 3 second to start, at the same time, the yr will flash. Then press "+" or "– " to set year.
2. press "SET" to switch to M interface, press "+" or "– " to set month.
3. press "SET"to switch to D interface, press "+" or "– " to set day.
4. press "SET" to switch to H interface, press "+" or "– " to set hour.
5. press " SET" to switch to Min interface, press"+" or "– " to set minute.
6. press " SET" to switch to Sec interface, press "+" or "– " to set second.
7. After completing above steps, press the "SET" to exit the setting mode.

At the same time, CDT will flash which indicates the setting is correct fully and countdown starts to run.



Figure 4: Instructions for setting the LED Countdown Clock.

Maintenance

- **Cleaning:** To clean the inflatable, wipe it with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Ensure it is completely dry before storing.
- **Storage:** Deflate the inflatable completely. Fold it neatly and place it back into its original storage box or a similar protective container. Store in a cool, dry place away from direct sunlight and pests.
- **Inspection:** Periodically check the fabric for tears or punctures. Small holes can often be repaired with a patch kit (not included). Inspect the blower and power cord for any damage before each use.
- **Blower Care:** Ensure the blower's air intake is free from debris (leaves, dirt, etc.) to maintain optimal inflation speed and prevent motor strain.

Troubleshooting

Problem	Possible Cause	Solution
Inflatable does not inflate or inflates slowly.	Power cord not plugged in. Zipper at the bottom is open. Blower air intake is blocked. Tear or hole in the fabric.	Ensure the power cord is securely plugged into a working outlet. Close the zipper completely. Clear any debris from the blower's air intake. Inspect the inflatable for damage and repair if necessary.
Inflatable sways or falls over.	Not properly anchored. Strong winds.	Ensure all stakes and ropes are securely fastened and taut. Do not operate in strong winds. Deflate and store until weather improves.
LED Countdown Clock not working.	Insulation piece not removed. DC cable disconnected. Incorrect setting.	Remove the transparent insulation piece. Check the DC cable connection. Refer to "Operating Instructions" to reset the clock.

Specifications

Feature	Detail
Model Number	RH-120-1700U4-1
Brand	Alupssuc
Dimensions (Inflated)	Approximately 8 feet wide (2.4 meters)
Product Dimensions (Packaged)	25.8 x 14.8 x 32.8 cm
Item Weight	1.6 kg (3.52 Pounds)
Material	Durable Polyester
Special Features	LED Christmas Countdown Clock, Internal LED Lights, Integrated Blower
Characters	Snowman, Santa, Gingerbread Man
Power Cord Length	3 meters



Figure 5: Approximate dimensions of the inflatable.

Warranty and Support

Alupssuc is committed to providing high-quality products and customer satisfaction. For any questions, concerns, or support needs regarding your Christmas inflatable, please contact our customer service team.

You can reach us through the "Contact Sellers" option on the platform where you purchased the product. Please provide your order number and a detailed description of the issue for prompt assistance. We aim to resolve all inquiries within 24 hours.

Specific warranty details may vary by region and retailer. Please retain your proof of purchase for warranty claims.

© 2024 Alupssuc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4LZW8YD

More documents and user manuals: **https://manuals.plus/**