Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CTTINKT CTTINKT 8-inch Front Wheel (Replacement for Ryobi RY40108 / Part 330073005)

CTTINKT 8-inch Front Wheel Instruction Manual

Replacement for Ryobi RY40108 20-inch Cordless Push Lawnmower (OEM Part 330073005)

1. Introduction

This instruction manual provides essential information for the safe and effective installation, operation, and maintenance of your new CTTINKT 8-inch Front Wheel. This wheel is designed as a direct replacement for the front wheel on the Ryobi RY40108 20-inch Cordless Push Lawnmower, corresponding to Ryobi OEM part number 330073005. Please read this manual thoroughly before attempting any installation or maintenance procedures.

2. Safety Information

Always prioritize safety when working with power tools and replacement parts. Failure to follow these safety guidelines may result in injury or damage to equipment.

- **Disconnect Power:** Before beginning any work on the lawnmower, ensure the battery pack is removed to prevent accidental startup.
- **Wear Protective Gear:** Always wear appropriate personal protective equipment, including safety glasses and work gloves, to protect against sharp edges or debris.
- **Stable Work Area:** Work on a flat, stable surface. Use blocks or stands to secure the lawnmower if it needs to be tilted or lifted.
- **Proper Tools:** Use only the correct tools for the job to avoid stripping fasteners or damaging components.
- **Inspect Components:** Before installation, inspect the new wheel and surrounding lawnmower components for any damage or defects.

3. Package Contents

Verify that all items are present upon opening the package:

- 1 x CTTINKT 8-inch Front Wheel (Replacement for Ryobi RY40108)

4. Installation Instructions

Follow these steps to replace the front wheel on your Ryobi RY40108 20-inch Cordless Push Lawnmower.

1. **Prepare the Lawnmower:** Ensure the lawnmower is turned off and the battery pack is removed. Place the lawnmower on a

stable, flat surface. For easier access, you may need to tilt the lawnmower onto its side, ensuring the carburetor (if applicable) is facing upwards to prevent fuel leakage.

2. **Remove the Old Wheel:** Locate the center bolt or nut securing the old wheel to the axle. Use an appropriate wrench or socket to loosen and remove this fastener. Carefully pull the old wheel off the axle. Note the position of any washers or spacers for correct reassembly.
3. **Clean the Axle:** Clean any debris, grass, or rust from the axle and surrounding area where the wheel mounts. This ensures a smooth fit for the new wheel.
4. **Install the New Wheel:** Align the new CTTINKT 8-inch Front Wheel with the axle. If there were any washers or spacers, place them back in their original positions. Slide the new wheel onto the axle.
5. **Secure the New Wheel:** Reinstall the center bolt or nut. Tighten it securely, but do not overtighten, as this can damage the wheel or axle. The wheel should spin freely without excessive wobble.
6. **Test the Installation:** Once the new wheel is securely attached, gently spin it by hand to ensure it rotates smoothly and without obstruction. Reinsert the battery pack and perform a brief functional check of the lawnmower in a safe area.



Figure 1: The CTTINKT 8-inch Front Wheel. This image displays the wheel's design, featuring a black plastic hub with multiple spokes and a solid black rubber tire, ready for installation on a compatible lawnmower axle.

5. Operation

Once properly installed, the CTTINKT 8-inch Front Wheel functions as an integral part of your Ryobi RY40108 20-inch Cordless Push Lawnmower. It facilitates smooth movement and maneuverability of the lawnmower during operation. No special operational procedures are required for the wheel itself beyond its correct installation.

6. Maintenance

Regular maintenance helps prolong the life of your wheel and ensures optimal lawnmower performance.

- **Cleaning:** After each use, remove any accumulated grass clippings, dirt, or debris from the wheel and axle area. A stiff brush or cloth can be used.
- **Inspection:** Periodically inspect the wheel for signs of wear, cracks, or damage to the tire or hub. Check that the wheel remains securely fastened to the axle.
- **Lubrication:** The wheel is designed for low maintenance. However, if the axle area appears dry or stiff, a light application of a suitable lubricant (e.g., silicone spray) to the axle shaft (not the wheel tread) can improve rotation.

7. Troubleshooting

If you encounter issues with your front wheel, consider the following common solutions:

- **Wheel Not Turning Freely:**
  - Check for grass or debris wrapped around the axle.
  - Ensure the mounting bolt/nut is not overtightened.
  - Verify that no other lawnmower components are obstructing the wheel's rotation.
- **Excessive Wobble:**
  - Ensure the mounting bolt/nut is securely tightened.
  - Check for proper placement of any washers or spacers during installation.
  - Inspect the axle for bends or damage.
- **Unusual Noise:**
  - Clean the wheel and axle area thoroughly.
  - Apply a small amount of lubricant to the axle if friction is suspected.
  - Inspect for internal damage to the wheel hub or axle.

If problems persist after troubleshooting, contact customer support.

8. Specifications

Brand	CTTINKT
Model (Replacement For)	Ryobi RY40108 20-inch Cordless Push Lawnmower (OEM Part 330073005)
Manufacturer Part Number	635401072075
Wheel Size / Rim Diameter	8 Inches
UPC	635401072075

Vehicle Service Type	Mower

9. Warranty and Support

For warranty information or technical support regarding your CTTINKT 8-inch Front Wheel, please refer to the purchase documentation or contact the seller directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question