Orbegozo CG5020

Orbegozo CG5020 Thermos Drip Coffee Maker User Manual

Model: CG5020

Introduction

Thank you for choosing the Orbegozo CG5020 Thermos Drip Coffee Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Orbegozo CG5020 is a drip coffee maker designed for convenience and efficiency, featuring a durable stainless steel and black finish. Key components include the water reservoir, filter basket, and an insulated thermos carafe.



Image showing the Orbegozo CG5020 coffee maker with its stainless steel and black design, including the water reservoir, filter basket area, and insulated carafe.

Key Features:

- **Capacity:** 12 cups (1.2 liters)
- **Filter:** Removable permanent filter
- **Carafe:** 1.2 L double-layer stainless steel insulated thermos carafe to keep coffee warm for hours
- **Safety:** Automatic shut-off function

- **Convenience:** Anti-drip protection, water level indicator, non-slip feet
- **Power:** 800 W
- **Accessories:** Includes a measuring spoon

Setup

1. **Unpacking:** Carefully remove the coffee maker and all accessories from the packaging. Dispose of packaging materials responsibly.
2. **Initial Cleaning:** Before first use, wash the permanent filter, thermos carafe, and measuring spoon in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
3. **Placement:** Place the coffee maker on a flat, stable, heat-resistant surface, away from water sources and direct heat. Ensure there is adequate ventilation around the unit.
4. **First Brew Cycle (Cleaning):** Fill the water reservoir to the MAX level with cold water. Do not add coffee grounds. Place the empty permanent filter in the filter basket. Close the lid. Place the empty thermos carafe on the warming plate. Plug the power cord into a suitable electrical outlet. Press the ON/OFF switch to start a brewing cycle. Allow the cycle to complete. Discard the water from the carafe. Repeat this process once or twice to ensure the appliance is clean.

Operating Instructions

Follow these steps to brew coffee with your Orbegozo CG5020 coffee maker:

1. **Fill Water Reservoir:** Open the top lid and fill the water reservoir with fresh, cold water. Use the water level indicator on the side to measure the desired number of cups. Do not exceed the MAX level.
2. **Add Coffee Grounds:** Place the permanent filter into the filter basket. Add the desired amount of ground coffee into the filter. A general guideline is one level measuring spoon (approximately 7g) per cup, but adjust to your taste.
3. **Close Lid and Position Carafe:** Close the top lid securely. Ensure the thermos carafe is correctly positioned on the warming plate. The anti-drip feature will only function properly if the carafe is in place.
4. **Start Brewing:** Plug the coffee maker into a power outlet. Press the ON/OFF switch. The indicator light will illuminate, signifying that the brewing process has started.
5. **Serving:** Once the brewing cycle is complete, the coffee maker will automatically shut off. The indicator light will turn off. Carefully remove the thermos carafe to serve. The double-layer insulation will keep your coffee warm for an extended period.
6. **Enjoy:** Pour and enjoy your freshly brewed coffee.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Daily Cleaning:

- Always unplug the appliance and allow it to cool completely before cleaning.
- Remove the permanent filter and discard used coffee grounds. Wash the filter, filter basket, and

thermos carafe in warm, soapy water. Rinse thoroughly and dry.

- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Never immerse the main unit, power cord, or plug in water or any other liquid.

Descaling:

Mineral deposits from water can build up in your coffee maker over time, affecting performance and coffee taste. Descale your coffee maker every 2-4 months, or more frequently if you have hard water.

1. Fill the water reservoir with a solution of white vinegar and water (e.g., 1 part vinegar to 2 parts water).
2. Place the permanent filter (without coffee) and the empty carafe in position.
3. Start a brewing cycle. After about half the solution has brewed through, turn off the coffee maker and let it soak for 15-20 minutes.
4. Turn the coffee maker back on and let the remaining solution brew through.
5. Discard the solution from the carafe.
6. Run 2-3 cycles with fresh, cold water to rinse out any remaining vinegar taste.

Troubleshooting

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee does not brew.	No power; ON/OFF switch not pressed; water reservoir empty.	Check power connection; press ON/OFF switch; fill water reservoir.
Coffee is too weak.	Not enough coffee grounds; coffee grounds too coarse; too much water.	Add more coffee; use finer grounds; use less water.
Coffee overflows from filter basket.	Too much coffee grounds; filter clogged; carafe not positioned correctly.	Reduce coffee grounds; clean filter; ensure carafe is fully seated.
Coffee tastes bad.	Appliance needs descaling; old coffee grounds in filter; poor water quality.	Descale the coffee maker; clean filter thoroughly; use filtered water.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Brand:** Orbegozo
- **Model Number:** CG5020
- **Capacity:** 12 Cups (1.2 Liters)
- **Power:** 800 W
- **Voltage:** 220-240 V (AC)
- **Frequency:** 50/60 Hz
- **Product Dimensions (L x W x H):** 25 x 25 x 30 cm

- **Item Weight:** 2 Kilograms
- **Special Features:** Thermal (Insulated Carafe), Automatic Shut-off, Anti-drip Protection, Water Level Indicator, Non-slip Feet, Permanent Filter

Warranty and Support

This Orbegozo CG5020 Thermos Drip Coffee Maker is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or service inquiries, please contact your local Orbegozo customer service or the retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.