Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-AV24H3-NP

ALLIMITY Replacement Remote Control for Hisense AntteQ LED TVs

Model: MM-AV24H3-NP

1. Introduction

This manual provides instructions for the ALLIMITY Replacement Remote Control, model MM-AV24H3-NP. This remote is designed to be fully compatible with various Hisense AntteQ LED TV models, offering a seamless replacement experience.
Key features include:

- **Easy to Use:** No programming or complex installation is required.
- **Full Functionality:** Designed to cover all functions of the original remote control.
- **Ergonomic Design:** Lightweight and comfortable to hold, ensuring extended use without fatigue.
- **Stable Performance:** Provides a longer transmission distance and stable remote control performance.





Image 1: Front view of the ALLIMITY Replacement Remote Control.

2. Setup and Battery Installation

The ALLIMITY Replacement Remote Control requires two AAA batteries (not included) for operation. No programming or pairing is necessary; simply insert the batteries, and the remote is ready to use with compatible Hisense AntteQ LED TVs.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the

compartment.

4. Slide the battery cover back into place until it clicks securely.





Image 2: Back view of the remote control, illustrating the battery compartment.

2.2 Initial Use

Once batteries are installed, point the remote control towards your Hisense AntteQ LED TV and press the Power button. The remote should function immediately without any additional setup.

3. Operating Instructions

The remote control provides access to all standard functions of your Hisense AntteQ LED TV. Below is a general overview of common button functions:

- **Power Button (●):** Turns the TV on or off.
- **Input Button:** Selects the input source (HDMI, AV, etc.).
- **Number Buttons (0-9):** Directly selects TV channels.
- **GUIDE:** Displays the electronic program guide.
- **CH.LIST:** Shows the channel list.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel.
- **Mute Button:** Mutes or unmutes the TV audio.
- **EXIT:** Exits the current menu or function.
- **Home Button (⌂):** Returns to the TV's home screen or smart TV interface.
- **TEXT:** Activates or deactivates teletext.
- **SUBTITLE:** Toggles subtitles on or off.
- **INFO:** Displays information about the current program.
- **Dedicated App Buttons (NETFLIX, YouTube, prm video, plex, BROWSER, Disny, free, deezer):** Provides direct access to streaming services and the web browser.

This remote control is compatible with the following Hisense AntteQ LED TV models:

- EN2ZF30
- AV24H3, AV32H3, AV42F3, AV50D1
- AG24N1C, AG24F1DCU, AG32H3, AG42F3, AG50D1
- AB24F1D, AB32D1, AB42D1, AB50D1

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the remote will not be used for several weeks or months to prevent potential leakage and damage.

4.3 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote is pointed directly at the TV.
- **Short operating range:**
  - Replace the batteries.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.
- **Specific buttons not working:**
  - This remote is designed to replicate original functions. If a specific button does not work, verify if the original remote had that function for your specific TV model.
  - Clean the remote control, especially around the non-functioning buttons, to remove any debris that might be preventing proper contact.

6. Specifications

Brand	ALLIMITY
Item Model Number	MM-AV24H3-NP
Connectivity Technology	Infrared
Special Feature	Ergonomic Design

Compatible Devices	Hisense AntteQ LED TVs (EN2ZF30, AV24H3, AV32H3, AV42F3, AV50D1, AG24N1C, AG24F1DCU, AG32H3, AG42F3, AG50D1, AB24F1D, AB32D1, AB42D1, AB50D1)
Number of Buttons	40
Maximum Range	10 Meters
Item Weight	59 Grams
Country of Origin	China





Image 3: Front view of the remote control, illustrating its dimensions (18 cm / 7.09 in length, 4.5 cm / 1.77 in width).

7. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the retailer or the point of purchase. Information regarding spare parts availability and software updates for this specific remote control is currently unavailable.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4VDBQDX

More documents and user manuals: **https://manuals.plus/**