Freaks and Geeks Wired Controller for PS4

Freaks and Geeks Wired Controller for PS4 User Manual

Model: Wired Controller for PS4

Introduction

Thank you for choosing the Freaks and Geeks Wired Controller for PlayStation 4. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new controller. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: Front view of the Freaks and Geeks Wired Controller for PS4. This image displays the controller's layout, including the D-pad, action buttons (illuminated), analog sticks, and central touchpad.

Setup

The Freaks and Geeks Wired Controller is designed for simple plug-and-play functionality with your PlayStation 4 console.

Connecting the Controller

1. Ensure your PlayStation 4 console is powered on.
2. Locate an available USB port on your PlayStation 4 console.
3. Insert the USB connector of the Freaks and Geeks Wired Controller into the USB port on your PS4. The controller features an extra-long 3-meter cable for flexible placement.
4. The console should automatically detect the controller. The illuminated buttons will light up, indicating a successful connection.
5. The controller is now ready for use.



Image: Rear view of the Freaks and Geeks Wired Controller, showing the integrated USB cable connection point. This illustrates where the cable extends from the controller.

Operating the Controller

This section details the key features and functions of your Freaks and Geeks Wired Controller.

Key Features

- **Dual Vibration:** Experience immersive feedback with dual vibration motors that respond to in-game actions.
- **Clickable Central Touchpad:** The central touchpad is fully functional and clickable, providing additional input options for compatible games.
- **3.5mm Headphone Jack:** Connect your gaming headset directly to the controller for audio and chat functionality.
- **Illuminated Buttons:** The action buttons feature backlighting for enhanced visibility and aesthetic appeal.
- **Extra-Long 3-Meter Cable:** The extended cable provides ample length for comfortable gaming from a distance.

Button Layout and Functions

The controller features a standard PlayStation layout. Refer to the image below for button identification.



Image: Detailed front view of the Freaks and Geeks Wired Controller. This image highlights the D-pad, left and right analog sticks, action buttons (Triangle, Circle, Cross, Square), Share, Options, PS button, and the clickable touchpad.

- **D-Pad:** Directional input.
- **Left/Right Analog Sticks:** For movement and camera control.
- **Action Buttons (Triangle, Circle, Cross, Square):** Primary in-game actions.
- **SHARE Button:** Share gameplay moments.
- **OPTIONS Button:** Access in-game menus.
- **PS Button:** Access the PS4 system menu.
- **L1/R1 Buttons:** Shoulder buttons.
- **L2/R2 Triggers:** Analog triggers for precise input.

Maintenance

Proper care and maintenance will extend the life of your controller.

Cleaning

- Disconnect the controller from the PS4 before cleaning.
- Use a soft, dry cloth to wipe down the surface of the controller.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive materials, as these can damage the controller's finish and internal

components.

- Use a cotton swab or compressed air to clean around buttons and analog sticks.

Storage

- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid wrapping the cable too tightly around the controller to prevent damage to the cable or its connection point.
- Keep the controller away from dust and liquids.

TROUBLESHOOTING

If you encounter issues with your Freaks and Geeks Wired Controller, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Controller not recognized by PS4.	Loose USB connection, faulty USB port, console software issue.	• Ensure the USB cable is securely plugged into both the controller and the PS4. • Try a different USB port on the PS4. • Restart the PS4 console. • Ensure the PS4 system software is up to date.
Buttons or analog sticks are unresponsive.	Dirt/debris, internal malfunction, software glitch.	• Clean around the affected buttons/sticks (refer to Maintenance section). • Disconnect and reconnect the controller. • Restart the PS4 console. • Test the controller with another game or application to isolate the issue.
Vibration function not working.	Game settings, console settings, internal malfunction.	• Check in-game settings to ensure vibration is enabled. • Verify PS4 system settings for controller vibration. • Ensure the game supports vibration feedback.
Headphone jack not producing audio or microphone not working.	Headset connection, console audio settings, headset compatibility.	• Ensure the headset is fully plugged into the 3.5mm jack. • Check PS4 audio output settings (Settings > Devices > Audio Devices). • Test the headset with another device to confirm it is working.
Controller is sometimes not recognized as a Sony device.	Third-party controller compatibility nuances.	• This is a known characteristic of some third-party controllers. • Try disconnecting and reconnecting the controller. • Restarting the PS4 may resolve temporary recognition issues.

Specifications

Below are the technical specifications for the Freaks and Geeks Wired Controller for PS4.

- **Brand:** Freaks and Geeks
- **Model:** Wired Controller for PS4
- **Connectivity:** USB (Wired)
- **Cable Length:** 3 meters
- **Compatible Devices:** PlayStation 4
- **Special Features:** Dual Vibration, Clickable Central Touchpad, 3.5mm Headphone Jack, Illuminated Buttons
- **Number of Buttons:** 16
- **Color:** Black
- **Dimensions (L x W x H):** Approximately 19 x 8 x 17 cm
- **Manufacturer:** Trade Invaders
- **Country of Origin:** China

Warranty and Returns

Information regarding an explicit manufacturer's warranty for this product is not available in the provided data. However, standard return policies may apply.

- **Return Policy:** A 30-day return/replacement policy is typically offered by the retailer. Please refer to your purchase documentation or the retailer's website for specific details regarding returns and replacements.

Support

For further assistance or if you encounter issues not covered in this manual, please refer to the following:

- **Included User Manual:** A physical user manual is included with the product. Please consult it for additional details.
- **Retailer Support:** Contact the retailer from whom you purchased the product for customer service and technical support.
- **Manufacturer Website:** Visit the official Freaks and Geeks website for potential FAQs, support resources, or contact information.

© 2026 Freaks and Geeks. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question