Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hitachi RAS-MJ36N-W

Hitachi RAS-MJ36N-W Air Conditioner User Manual

Model: RAS-MJ36N-W | Brand: Hitachi

1. Introduction

This user manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your Hitachi RAS-MJ36N-W Air Conditioner. Please read this manual thoroughly before using the appliance and retain it for future reference. This air conditioner is designed to provide both cooling and heating functions for optimal indoor comfort.



Figure 1.1: Hitachi RAS-MJ36N-W Indoor Unit. This image displays the sleek, white indoor unit of the Hitachi RAS-MJ36N-W air conditioner, featuring the Hitachi logo on the left and 'STAINLESS CLEAN ' (Shirokuma-kun) text on the right, indicating its clean design and brand series.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the power supply voltage matches the specifications of the unit.
- Do not operate the air conditioner with wet hands.
- Do not insert fingers or objects into the air inlet/outlet.
- Keep the area around the outdoor unit clear of obstructions.

- In case of abnormal operation, strange sounds, or smoke, immediately turn off the unit and disconnect the power supply. Contact qualified service personnel.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Components

The Hitachi RAS-MJ36N-W Air Conditioner system includes the following main components:

- **Indoor Unit:** Responsible for circulating conditioned air within the room.
- **Outdoor Unit:** Houses the compressor and condenser, responsible for heat exchange with the outside environment.
- **Remote Control:** Used to operate and adjust the settings of the air conditioner.

4. Setup and Installation Requirements

The installation of the Hitachi RAS-MJ36N-W Air Conditioner requires professional expertise. It is strongly recommended that installation be performed by a qualified and certified technician to ensure proper functioning, safety, and compliance with local regulations. The following diagrams illustrate key aspects of standard installation:

4.1 Standard Installation Overview




Figure 4.1: Standard Air Conditioner Installation Diagram. This diagram illustrates the typical setup for an air conditioner, showing the indoor unit, outdoor unit, piping, and electrical outlet. Key clearances (e.g., 5cm above/left for indoor unit, 25cm front/5cm left/right for outdoor unit) and the need for a dedicated power outlet are highlighted.

Key steps in standard installation typically include:

1. **Indoor Unit Installation:** Securely mount the indoor unit on a wall, ensuring sufficient space (e.g., 5cm or more above and to the left/right) for proper airflow and maintenance.
2. **Outdoor Unit Installation:** Place the outdoor unit on a stable, level surface (e.g., flat ground or veranda with plastic blocks), maintaining adequate clearances (e.g., 25cm or more in front, 5cm or more to the left/right) for ventilation.
3. **Piping Connection:** Connect the refrigerant pipes and drain hose between the indoor and outdoor units, typically up to 4 meters with tape wrapping.
4. **Vacuuming (Air Purge):** Evacuate air from the refrigerant lines to ensure optimal performance.
5. **Electrical Connection:** Connect the unit to a dedicated 100V power outlet. Ensure the power supply matches the unit's requirements.

4.2 Important Installation Points




Figure 4.2: Important Installation Points. This image details specific requirements for air conditioner installation, including clearances for indoor and outdoor units, considerations for wall penetration, piping connections, vacuuming, and electrical outlet requirements.

- **Indoor Unit Placement:** Requires a flat wall with sufficient strength. Ensure at least 5cm clearance above and to the left/right for service space.
- **Outdoor Unit Placement:** Must be on a flat surface or veranda floor. Requires at least 25cm clearance in front and 5cm to the left/right. Additional costs may apply for special installations (e.g., using metal fittings or on a rooftop).
- **Pipe Hole Drilling:** If no existing hole, a new one (up to 20cm thick for wood/mortar) can be drilled. Special materials like RC, ALC, or tile walls may incur additional costs.
- **Piping Connection:** Refrigerant pipes, communication wires, and drain hoses are taped together. Extension of piping beyond 4m will incur additional charges. Insulation materials may be required depending on the environment, leading to extra costs. Concealed piping also incurs additional costs.
- **Vacuuming (Air Purge):** This process requires access to the customer's power source. Your cooperation is appreciated.
- **Electrical Outlet:** Connect to a dedicated air conditioner circuit. Confirm the voltage (100V) is suitable for the air conditioner. Installation using non-dedicated outlets, extension cords, etc., is not possible according to manufacturer standards.

5. Operating Instructions

Your Hitachi RAS-MJ36N-W Air Conditioner offers various modes to ensure your comfort. Use the remote control to select the desired mode and settings.

5.1 Basic Operation

- **Power On/Off:** Press the **ON/OFF** button on the remote control.
- **Mode Selection:** Press the **MODE** button to cycle through modes: Cooling, Heating, Dry, Fan, Auto.
- **Temperature Adjustment:** Use the **TEMP UP/DOWN** buttons to set your desired temperature.
- **Fan Speed:** Adjust fan speed using the **FAN SPEED** button.

5.2 Cooling Mode

Select Cooling mode for effective temperature reduction. Set the temperature to your comfort level. The unit will cool the room to the set temperature.

5.3 Heating Mode

Select Heating mode to warm your room. Set the desired temperature. The unit will heat the room to the set temperature.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your air conditioner. Always turn off the unit and disconnect power before performing any maintenance.

- **Air Filter Cleaning:** Clean the air filters regularly (e.g., every two weeks or as needed). Remove filters, wash with water, dry thoroughly, and reinsert.
- **Outdoor Unit Cleaning:** Keep the outdoor unit clear of debris, leaves, and other obstructions. Ensure the coils are clean for efficient heat exchange.
- **Professional Servicing:** It is recommended to have your air conditioner professionally serviced at least once a year to check refrigerant levels, clean coils, and inspect overall system health.

7. Troubleshooting

If you encounter issues with your air conditioner, refer to the following common troubleshooting steps. If the problem persists, contact qualified service personnel.

Problem	Possible Cause	Solution
Unit does not turn on	No power; Remote control batteries low	Check power supply/circuit breaker; Replace remote batteries
Insufficient cooling/heating	Dirty air filters; Obstruction of air flow; Incorrect mode/temperature setting	Clean air filters; Remove obstructions; Adjust settings
Unusual noise	Loose parts; Obstruction in fan; Unit not level	Contact service technician; Check for obstructions; Ensure unit is level
Water leakage	Clogged drain hose; Improper installation	Clear drain hose; Contact service technician for inspection

8. Specifications

The following are the technical specifications for the Hitachi RAS-MJ36N-W Air Conditioner:

Specification	Value
Brand Name	Hitachi (HITACHI)
Product Model Number	RAS-MJ36N-W
Form Factor	Mini-split
Special Features	Cooling and Heating Function
Voltage	100 Volts
Product Dimensions (D x W x H)	25 x 79.5 x 29.5 cm
Cooling Capacity	3.6 Kilowatts

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Hitachi website. In case of initial defects or malfunctions, manufacturer repair services are available. Please note that returns, exchanges, or cancellations of the product are generally not possible after installation is complete.

For any concerns regarding installation environment or potential additional costs, it is highly recommended to consult with the retailer or installer before placing your order. Pre-installation estimates may be available for a fee.

© 2024 Hitachi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4Y6NHFQ

More documents and user manuals: **https://manuals.plus/**