oneisall RFC-676Pro

oneisall RFC-676Pro Professional Cordless Dog Clippers User Manual

Model: RFC-676Pro | Brand: oneisall

Safety Information Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Safety Information

To ensure safe operation and prevent injury or damage, please read and adhere to the following safety guidelines:

- Keep the clippers away from water and do not immerse them in liquid.
- Avoid using the clippers on infants or very young animals without proper precautions.
- Always follow recommended cleaning and maintenance procedures to ensure optimal performance and hygiene.
- Utilize the safety lock feature to prevent accidental activation, especially during storage or when not in use.
- Do not attempt to disassemble or repair the clippers yourself. Contact customer support for assistance.
- Ensure the charging cable and adapter are in good condition before charging.

2. Product Overview

The oneisall RFC-676Pro Professional Cordless Dog Clippers are designed for efficient and quiet pet grooming. This kit provides a comfortable and effective grooming experience for various hair types.

Key Features:

- **Cordless and Rechargeable:** Offers flexibility and ease of use without being tethered to an outlet.
- **Low Noise Operation:** Engineered to minimize noise and vibration, helping to keep pets calm during grooming.

- **Detachable Metal Combs:** Durable and effective for consistent clipping across various hair lengths.
- **Heavy-Duty Blades:** Designed for efficient cutting through thick, curly, fine, or wavy hair.
- **IPX7 Waterproof:** Allows for easy cleaning under running water.

Package Contents:

- oneisall RFC-676Pro Dog Clippers
- Set of Detachable Metal Guide Combs (various lengths)
- Charging Base
- USB Charging Cable
- Cleaning Brush
- Lubricating Oil
- User Manual



Image: The oneisall RFC-676Pro Dog Clippers, showcasing its design, charging base, and included metal guide combs.

3. Setup

3.1 Charging the Clippers

Before first use, fully charge the clippers. The LED display will indicate the battery level.

1. Connect the USB charging cable to the charging base or directly to the clipper's charging port.
2. Plug the USB cable into a compatible USB power adapter (not included) or a USB port.
3. Place the clippers onto the charging base or connect the cable directly to the clipper.
4. Allow the clippers to charge until the LED display shows 100%. A full charge typically takes approximately 3 hours.



Image: The two charging methods for the clippers: using the charging dock or direct USB cable connection.

3.2 Attaching Guide Combs

The metal guide combs help achieve desired hair lengths and ensure an even cut.

1. Select the appropriate metal guide comb for the desired hair length.
2. Align the comb with the clipper blade and slide it firmly into place until it clicks.
3. To remove, gently push the comb upwards and off the blade.



Image: Detachable metal guide combs in various sizes, designed for precise and even clipping.

4. Operation

4.1 Preparing Your Pet for Grooming

- Ensure your pet's coat is clean, dry, and thoroughly brushed to remove any tangles or mats. This prevents the blades from snagging and ensures a smooth cut.
- Introduce the clippers to your pet gradually, allowing them to get used to the sound and feel before starting to clip.

4.2 Using the Clippers

1. Press the power button to turn on the clippers.
2. Hold the clippers firmly and begin clipping in the direction of hair growth.
3. Use smooth, even strokes. Do not press too hard against the pet's skin.
4. Regularly check the blades for hair buildup and clean as needed to maintain cutting efficiency.



Image: Demonstrating the use of the clippers on a dog's coat.

4.3 Adjusting Blade Length

The clippers feature an adjustable blade lever for fine-tuning cutting length without a guide comb. Refer to the markings on the clipper body for specific length settings.

5. Maintenance

5.1 Cleaning the Blades

Regular cleaning extends the life of your clippers and ensures optimal performance.

1. Turn off the clippers and remove any attached guide combs.
2. Use the provided cleaning brush to remove loose hair from the blades.
3. Since the clippers are IPX7 waterproof, you can rinse the blade head under running water. Ensure the charging port cover is securely closed before rinsing.
4. Dry the blades thoroughly after rinsing.

5.2 Oiling the Blades

Lubricating the blades after each cleaning or extended use is crucial for smooth operation and preventing rust.

1. Apply 1-2 drops of the lubricating oil (included) evenly across the top and sides of the blade teeth.
2. Turn on the clippers for a few seconds to distribute the oil.
3. Wipe off any excess oil with a soft cloth.



Image: Proper application of lubricating oil to the clipper blades.

5.3 Storage

Store the clippers in a cool, dry place, away from direct sunlight and out of reach of children and pets. Ensure the safety lock is engaged before storing.

6. Troubleshooting

If you encounter issues with your oneisall RFC-676Pro Dog Clippers, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Clippers not turning on	Low battery; Safety lock engaged	Charge the clippers fully; Disengage the safety lock.
Poor cutting performance / Snagging hair	Blades are dull, dirty, or not oiled; Hair is matted or wet	Clean and oil the blades; Ensure pet's hair is clean, dry, and brushed; Consider blade replacement if dull.
Clippers getting hot	Extended continuous use; Lack of lubrication	Allow clippers to cool down; Apply lubricating oil to blades.
Unusual noise or vibration	Hair caught in blades; Loose blade assembly	Clean blades thoroughly; Ensure blades are securely attached.

7. Specifications

- **Model Number:** RFC-676Pro
- **Power Source:** Battery Powered (1 Lithium Ion battery required)
- **Charging Type:** USB Power Supply / Charging Base
- **Charging Time:** Approximately 3 hours
- **Item Weight:** 1.27 Pounds
- **Product Dimensions (LxWxH):** 7.28 x 1.69 x 2.36 inches (approximate)
- **Special Features:** Detachable blades, Low Noise, Multigroomer, Rechargeable, IPX7 Waterproof



Image: Detailed product dimensions and charging information for the clippers.

8. Warranty & Support

oneisall products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official oneisall website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact oneisall customer service. You can find contact details by visiting the oneisall Store on Amazon or their official brand website.