Wkzay DW198

Wkzay Cordless Handheld Vacuum Cleaner

Model: DW198

Introduction

Thank you for choosing the Wkzay Cordless Handheld Vacuum Cleaner, Model DW198. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.

Safety Information

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.

- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not charge the unit outdoors.
- Use only the charger specified by the manufacturer.
- Do not incinerate the appliance even if it is severely damaged. Batteries can explode in a fire.

Package Contents

Verify that all items are included in your package:

- Wkzay Cordless Handheld Vacuum Cleaner (Model DW198)
- Collapsible Brush Nozzle
- Washable HEPA Filter (2 included)
- Charging Base
- USB-C Charging Cable
- Power Adapter
- User Manual



Image: Wkzay Cordless Handheld Vacuum Cleaner with accessories including nozzles, filters, and charging cable.

Product Overview

The Wkzay DW198 is a lightweight and portable cordless handheld vacuum cleaner designed for quick and efficient cleaning tasks. It features a powerful brushless motor and dual suction modes to handle various types of debris.

Key Features:

- **Brushless Motor:** Delivers up to 16,000 Pa suction power with reduced noise and extended durability.
- **Dual Suction Modes:** Choose between 12,000 Pa (Standard) and 16,000 Pa (High-performance) for different cleaning needs.
- **Long Battery Life:** 6000 mAh battery provides up to 30 minutes of runtime in low mode and 15 minutes in high mode.
- **Quiet Operation:** Operates at less than 50 dB, suitable for noise-sensitive environments.

- **Compact & Lightweight:** Weighs only 1.2 lbs, making it easy to handle and store.
- **USB-C Rechargeable:** Fast and versatile charging with a battery indicator.
- **Washable HEPA Filter:** Easy to maintain and eco-friendly.
- **Ergonomic Handle:** Designed for comfortable use during extended cleaning sessions.



Image: Diagram illustrating the internal components and key features of the vacuum, such as the brushless motor, USB-C port, and HEPA filter location.

Setup

1. Charging the Vacuum

1. Place the vacuum cleaner onto its charging base.
2. Connect the USB-C charging cable to the charging base and the power adapter.
3. Plug the power adapter into a wall outlet.

4. The battery indicator lights on the vacuum will illuminate to show the charging status. All lights will be solid when fully charged.
5. A full charge typically takes 3.5-4 hours.



Image: The handheld vacuum placed on its charging base, connected via USB-C to a power adapter.

2. Attaching Accessories

The collapsible brush nozzle can be attached to the vacuum's suction port for versatile cleaning.

- To attach: Align the nozzle with the vacuum's suction opening and push firmly until it clicks into place.
- To use the brush: Extend the brush bristles from the nozzle tip.
- To use as a crevice tool: Retract the brush bristles into the nozzle.



Image: The 2-in-1 collapsible brush nozzle, demonstrating its use as a brush and a crevice tool.

Operating Instructions

1. Power On/Off

- To turn on: Press and hold the power button for 2 seconds. The vacuum will start in Standard Mode (12,000 Pa).
- To turn off: Press and hold the power button for 2 seconds.

2. Switching Suction Modes

- While the vacuum is on, press the power button once to switch between Standard Mode (12,000 Pa) and High-performance Mode (16,000 Pa).
- The LED indicator lights will show the current suction mode and battery level.



Image: The handheld vacuum in use, illustrating the two suction power modes: Standard (12000Pa) and High-performance (16000Pa).

3. General Cleaning Tips

- For general dust and light debris, use Standard Mode to conserve battery life.
- For stubborn dirt, pet hair, or larger particles, switch to High-performance Mode.
- Use the brush nozzle for upholstery, car interiors, and delicate surfaces.
- Use the crevice tool for tight corners, gaps, and hard-to-reach areas.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. Emptying the Dustbin

1. Ensure the vacuum is turned off.

2. Twist the dustbin counter-clockwise to detach it from the main body.
3. Carefully empty the collected debris into a trash can.
4. Reattach the dustbin by aligning it and twisting clockwise until secure.

2. Cleaning the HEPA Filter

The HEPA filter is washable and reusable. Clean it regularly to maintain suction power.

1. Remove the dustbin as described above.
2. Gently pull out the HEPA filter from the dustbin.
3. Rinse the filter under running water until clean. Do not use detergents or hot water.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Ensure it is completely dry to prevent damage to the motor.
5. Reinsert the dry HEPA filter into the dustbin and reattach the dustbin to the vacuum body.



Image: A hand rinsing the washable HEPA filter under a faucet.

Troubleshooting

If you encounter issues with your Wkzay handheld vacuum, please refer to the following common problems and solutions:

- **No Power:** Ensure the vacuum is fully charged. Check the charging cable and adapter connections.
- **Weak Suction:** Empty the dustbin. Clean or replace the HEPA filter. Check for any blockages in the nozzle or suction path.
- **Unusual Noise:** Check for any foreign objects caught in the suction path or brush nozzle. Ensure the dustbin and filter are correctly installed.
- **Short Battery Life:** Ensure the vacuum is fully charged. Battery life can vary based on suction mode used (High-performance mode consumes more power).

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Brand	Wkzay
Model Name	DW198
Special Feature	Brushless Motor
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	150 Milliliters
Wattage	120 watts
Recommended Uses	Household cleaning, apartments, dormitories, offices. Cleans dust, snacks, crumbs, hair from kitchens, bedrooms, window cracks, sofa cracks, floors, stairs, and hard-to-reach corners.
Form Factor	Handheld
Color	Black
Product Dimensions	3.6"L x 2.7"W x 11.4"H
Battery Description	Lithium-Ion
Noise Level	50 Decibels
Amperage	2 Amps
Battery Life	30 minutes (low suction mode)
Number of Items	1
Controller Type	Push Button
Control Method	Touch
Style	Modern

Connectivity Technology	USB
Number of Speeds	2
Portable	Yes
Number of Power Levels	2
Indoor/Outdoor Usage	Indoor, Outdoor
Item Weight	1.1 pounds
Batteries	2 Lithium Ion batteries required (included)
Surface Recommendation	All floors
Power Source	Battery Powered

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Wkzay website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question