Gevi SVCD0-AP0A1

Gevi Cordless Vacuum Cleaner SVCD0-AP0A1 User Manual

Model: SVCD0-AP0A1 | Brand: Gevi

1. Important Safety Instructions

Please read all instructions carefully before using your Gevi Cordless Vacuum Cleaner. Keep this manual for future reference.

- Do not use the appliance outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Prevent unintentional starting. Ensure the switch is in the OFF-position before connecting to battery pack, picking up or carrying the appliance.

2. Product Overview

The Gevi Cordless Vacuum Cleaner SVCD0-AP0A1 is designed for efficient daily cleaning across various surfaces in your home. Its lightweight design, powerful suction, and versatile attachments make it a convenient tool for maintaining a clean living space.

Key Features:

- **Long Runtime Detachable Battery:** Provides extended cleaning sessions and easy charging.
- **LED Display:** Clearly shows battery status and power mode.
- **Powerful Suction:** Effectively picks up dirt and debris from various surfaces.
- **Lightweight Design:** Weighs approximately 2.8 lbs for effortless maneuverability.
- **Multi-Floor Cleaning:** Suitable for hard floors, hardwoods, and low-pile carpets.
- **HEPA Filter:** Captures 99.97% of microscopic dust particles for cleaner air.
- **Flexible Smooth Steering:** Allows easy navigation around furniture and obstacles.
- **Versatile Cleaning:** Converts to a handheld vacuum with various attachments for different cleaning needs.
- **Charging Wall Mount:** Convenient storage and charging solution.

3. What's Included in the Package

The Gevi Cordless Vacuum Cleaner SVCD0-AP0A1 comes with the following components:

- Main Unit with HEPA Filter
- Two-Section Tube (Extension Wand)
- Floor Brush with LED Headlights
- Flat Suction Nozzle
- Dusting Brush
- Charging Wall Mount
- Power Adapter
- User Manual
- User Guide



Figure 3.1: All components included with the Gevi Cordless Vacuum Cleaner.

Video: What's Included in the Package?

Your browser does not support the video tag.

This video demonstrates all the items you will find inside the Gevi Cordless Vacuum Cleaner package.

4. Assembly

Follow these steps to assemble your Gevi Cordless Vacuum Cleaner:

1. Connect the two-section tube (extension wand) by aligning the ends and pushing until it clicks into place.
2. Attach the floor brush to the bottom end of the two-section tube. Ensure it clicks securely.
3. Connect the main unit (handheld vacuum) to the top end of the two-section tube.
4. For handheld use, detach the two-section tube and attach either the dusting brush or the flat suction nozzle directly to the main unit.



Figure 4.1: The Gevi Cordless Vacuum Cleaner can be configured for stick or handheld use with different attachments.

Video: How to Assemble Accessories?

Your browser does not support the video tag.

This video provides a visual guide on how to correctly assemble the various accessories for your vacuum cleaner.

5. Operating Instructions

Your Gevi Cordless Vacuum Cleaner is designed for ease of use and effective cleaning.

Power On/Off and Speed Control:

- Press the power button on the main unit to turn the vacuum on or off.
- The vacuum features 2 power levels (Min/Mid/Max). Press the mode button to cycle through the suction modes to suit your cleaning needs. The LED display will show the current mode and remaining battery life.

Cleaning Surfaces:

- The floor brush is suitable for hard floors, wood floors, and low-pile carpets.
- The LED headlights on the floor brush illuminate dust and debris, making cleaning in dimly lit areas more effective.
- Use the dusting brush for delicate surfaces like furniture or keyboards.
- The flat suction nozzle is ideal for narrow gaps, corners, and car interiors.



Figure 5.1: The vacuum is effective on both hard floors and low-pile carpets.



Figure 5.2: LED headlights reveal hidden dust for thorough cleaning.



Figure 5.3: The lightweight design ensures comfortable and easy handling.



Figure 5.4: Flexible steering allows easy navigation around obstacles.



Figure 5.5: The vacuum can be adapted with different nozzles for diverse cleaning tasks.

Video: Gevi Cordless Vacuum Overview

Your browser does not support the video tag.

This video provides a general overview of the Gevi Cordless Vacuum Cleaner, demonstrating its features and usage.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Cleaning the Dust Cup:

1. Press the release button to detach the dust cup from the main unit.
2. Hold the handle and pull out the filter assembly from the dust cup.
3. Empty the collected debris into a trash bin.
4. Rinse the dust cup with water and allow it to dry completely for at least 24 hours before reassembly.



Figure 6.1: The detachable battery allows for flexible charging and replacement.

Video: How to Clean the Dust Cup?

Your browser does not support the video tag.

This video demonstrates the process of disassembling and cleaning the dust cup.

Cleaning and Maintaining the Filter Assembly:

1. After removing the filter assembly from the dust cup, rotate the HEPA filter anticlockwise to separate it from the mesh filter.
2. Rinse both the HEPA filter and the mesh filter under running water.
3. Allow both filters to completely air dry for at least 24 hours before reassembly. Ensure they are fully dry to prevent mold and maintain suction power.
4. To reinstall, align the plastic column position, reinstall the HEPA filter, and tighten it clockwise.
5. Place the entire filter assembly back into the dust cup, ensuring it is properly seated.
6. Reattach the dust cup to the main unit until it clicks securely.



Figure 6.2: Rinse the HEPA filter thoroughly for optimal performance.

Video: How to Maintain and Assemble the Filter Assembly?

Your browser does not support the video tag.

This video guides you through the maintenance and reassembly of the filter components.

Cleaning the Brush Bar:

1. Turn off the vacuum and detach the floor brush.
2. Locate the release mechanism on the side of the brush head and open it to remove the brush bar.
3. Use scissors or a utility knife to carefully cut and remove any tangled hair or debris from the brush bar.
4. Clean any remaining debris from the brush head cavity.

5. Reinsert the clean brush bar and secure the release mechanism.



Figure 6.3: Regularly remove tangled hair from the brush bar to maintain cleaning efficiency.

Video: How to Clean the Brush Bar?

Your browser does not support the video tag.

This video illustrates the steps for cleaning and maintaining the vacuum's brush bar.

7. Troubleshooting

If you encounter any issues with your Gevi Cordless Vacuum Cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure the battery is fully charged and correctly inserted into the main unit.
Low suction power	Dust cup is full, filters are clogged, or there is a blockage in the nozzle/tube.	Empty the dust cup. Clean the HEPA and mesh filters. Check for and remove any blockages.
Brush bar not rotating	Hair or debris tangled around the brush bar, or a blockage in the brush head.	Turn off the vacuum, remove the brush bar, and clear any obstructions.
Battery not charging	Power adapter not connected, or battery issue.	Ensure the power adapter is securely connected to the wall mount and a power outlet. Contact customer support if the issue persists.

8. Specifications

Feature	Specification
Brand	Gevi
Model Name	SVCD0-AP0A1

Feature	Specification
Special Feature	Bagless
Filter Type	HEPA Filter
Is Cordless?	Yes
Charging Time	5 Hours
Recommended Uses	Hard floors, hardwoods, low pile carpets, upholstery
Form Factor	Stick
Color	White
Product Dimensions	8.98"L x 9.84"W x 43"H
Battery Type	Lithium-Ion
Battery Life	Up to 45 minutes
Motor Horsepower	150 Watts
Number of Power Levels	2
Item Weight	7.89 pounds

9. Warranty and Support

Gevi is committed to providing high-quality products and excellent customer service. Your Gevi Cordless Vacuum Cleaner is covered by a manufacturer's warranty against defects in materials and workmanship.

Customer Support:

For any questions, concerns, or warranty claims, please contact Gevi customer service. We aim to respond to all inquiries within 24 hours.

- **Online Support:** Visit the official Gevi website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or the official website for the customer service email address.



Figure 9.1: Gevi's dedicated customer service team is ready to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question