Accutime SNC4386MAZ

Sonic The Hedgehog Kids Smartwatch User Manual

Brand: Accutime | **Model:** SNC4386MAZ

1. Introduction

Welcome to the world of the Sonic The Hedgehog Kids Smartwatch! This innovative device is designed to provide young fans with a fun and functional wearable experience. It combines entertainment with practical features, encouraging activity and engagement.

This manual provides essential information on how to set up, operate, maintain, and troubleshoot your new smartwatch, ensuring a smooth and enjoyable experience.

2. Product Features

The Sonic The Hedgehog Kids Smartwatch comes equipped with a variety of features to enhance your child's daily activities:

- **Bluetooth Connectivity:** Enables calling, messaging, and music playback when connected to a compatible smartphone.
- **Full Touchscreen Display:** Intuitive interface for easy navigation.
- **Customizable Watch Faces:** Choose from 6 exciting Sonic-themed watch faces.
- **Activity Tracker:** Includes a pedometer to count steps, a sleep monitor, and various workout modes to encourage physical activity.
- **Built-in Camera & Flashlight:** Capture photos and illuminate dark areas.
- **Voice Recorder:** Record notes or messages.
- **Entertainment:** Pre-loaded games for fun and skill development.
- **Essential Tools:** Alarm, stopwatch, and calendar functions.

- **Durable Design:** Water-resistant construction to withstand daily wear and tear.
- **Adjustable Wristband:** Designed to comfortably fit wrists from 5.5 inches to 8 inches.



Figure 2.1: Front view of the Sonic The Hedgehog Kids Smartwatch, highlighting its vibrant display and character-themed strap.



Figure 2.2: The smartwatch in its packaging, illustrating key features such as messaging, call log, pedometer, and Bluetooth camera control.



Figure 2.3: A selection of the six unique Sonic-themed watch faces that users can choose from to personalize their smartwatch.

3. Setup

3.1 Charging the Smartwatch

Before first use, fully charge the smartwatch. Connect the included USB charging cable to the charging port on the watch and to a standard USB power adapter (not included) or a computer USB port. The charging indicator on the screen will show the charging status. A full charge typically takes approximately 2-3 hours.

3.2 Powering On/Off

- **To Power On:** Press and hold the power button (usually located on the side of the watch) for a few seconds until the screen lights up.

- **To Power Off:** Press and hold the power button until a power-off option appears on the screen. Tap to confirm.

3.3 Initial Setup and Time/Date Setting

Upon first power-on or after a factory reset, you may be prompted to set the language, time, and date. Follow the on-screen instructions. If the time and date are not automatically synchronized via Bluetooth, you can manually adjust them through the watch's settings menu. Navigate to **Settings > Time & Date** to make adjustments.

3.4 Bluetooth Pairing

To enable calling, messaging, and other connected features, pair your smartwatch with a compatible smartphone:

1. Ensure Bluetooth is enabled on your smartphone.
2. On the smartwatch, navigate to the Bluetooth settings (usually found in the main menu or settings app).
3. Select "Search for new device" or similar option.
4. On your smartphone, search for available Bluetooth devices and select "Sonic Smartwatch" or a similar name.
5. Confirm the pairing request on both devices if prompted.

Once paired, the smartwatch can receive notifications and control certain phone functions.

4. Operating Instructions

4.1 Navigating the Interface

The smartwatch features a full touchscreen display. Swipe left, right, up, or down to navigate through menus and applications. Tap an icon to open an application or select an option. Use the side button to return to the home screen or go back in a menu.

4.2 Key Applications and Functions

- **Phone/Call Log:** After Bluetooth pairing, you can make or receive calls directly from the watch (requires phone to be nearby) and view call history.
- **Messages:** View incoming messages and notifications from your paired smartphone.
- **Camera:** Open the camera app to take photos. The flashlight function can also be accessed here or via a dedicated icon.
- **Music:** Control music playback on your paired smartphone (play, pause, skip tracks).
- **Pedometer/Activity Tracker:** Access daily step count, distance, and calorie burn. Some models may include specific workout modes.
- **Sleep Monitor:** Track sleep patterns (wear the watch during sleep for data collection).
- **Games:** Select from pre-installed games for entertainment.
- **Alarm:** Set multiple alarms for reminders.
- **Stopwatch:** Use for timing activities.
- **Voice Recorder:** Record audio memos.
- **Watch Faces:** Change the appearance of your watch face by tapping and holding the current watch face or through the settings menu.

5. Maintenance

5.1 Cleaning

To keep your smartwatch clean, gently wipe the screen and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or screen.

5.2 Water Resistance

The smartwatch is designed to be water-resistant, meaning it can withstand splashes and light rain. It is NOT suitable for swimming, showering, or submersion in water. Avoid exposing the watch to high-pressure water or steam.

5.3 Battery Care

- Charge the watch regularly, but avoid leaving it fully discharged for extended periods.
- Do not expose the watch to extreme temperatures (hot or cold), as this can affect battery life and performance.
- Use only the provided charging cable or a compatible USB charger.

6. Troubleshooting

If you encounter issues with your smartwatch, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Watch does not turn on.	Battery may be depleted. Connect to charger and allow it to charge for at least 30 minutes before attempting to power on again.
Cannot pair with smartphone via Bluetooth.	Ensure Bluetooth is enabled on both devices. Make sure the watch is in pairing mode. Try restarting both the watch and the phone. Ensure no other devices are currently connected to the watch.
Incorrect time or date.	Manually adjust time and date in the watch's settings menu (**Settings > Time & Date**). Ensure the watch is properly paired with a smartphone for automatic synchronization if available.
Short battery life.	Frequent use of certain features (e.g., camera, games, continuous Bluetooth connection) can drain the battery faster. Reduce screen brightness. Ensure background apps are closed.
Touchscreen unresponsive.	Restart the watch. Ensure the screen is clean and dry. If the issue persists, a factory reset might be necessary (note: this will erase all data).

If the problem persists after trying these solutions, please refer to the manufacturer's official support channels.

7. Specifications

Feature	Detail
Model Number	SNC4386MAZ
Brand	Accutime
Display	Full Touchscreen
Connectivity	Bluetooth
Battery Type	1 Lithium Polymer (included)
Charging	USB Rechargeable
Wrist Fit Range	5.5 inches to 8 inches
Dimensions (Package)	6.38 x 4.21 x 2.52 inches
Weight (Item)	3 ounces
Water Resistance	Splash and light rain resistant (not for submersion)

8. Warranty and Support

Specific warranty details and comprehensive customer support information are typically provided with the product packaging or available on the manufacturer's official website. Please refer to the documentation included with your purchase or visit the Accutime website for the most up-to-date warranty terms and support contacts.

For technical assistance or inquiries, it is recommended to contact Accutime customer service directly.

© 2025 Accutime. All rights reserved. Sonic The Hedgehog ™ © SEGA.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the app to add contacts for the Accutime Sonic The Hedgehog Kids Smartwatch (SNC4386MAZ), and how do I change the time?

To add contacts and synchronize the time on your Accutime Sonic The Hedgehog Kids Smartwatch (Model SNC4386MAZ), you must pair the watch with a smartphone via Bluetooth. While the manual does not name a...

Read full answer