Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JYX T22T

JYX Karaoke Machine Model T22T User Manual

Portable Bluetooth Speaker with Dual Wireless Microphones

Introduction

Thank you for purchasing the JYX Karaoke Machine Model T22T. This portable Bluetooth speaker system is designed to provide high-quality audio and an enjoyable karaoke experience for various occasions. It features Bluetooth 5.0 connectivity, support for multiple media inputs, and dual wireless microphones. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan.

Safety Information

- Do not expose the device to rain or moisture to prevent fire or electric shock.
- Do not disassemble or modify the device. Refer all servicing to qualified personnel.
- Keep the device away from heat sources, direct sunlight, and extreme temperatures.
- Use only the provided charging cable and adapter.
- Avoid placing heavy objects on the device.
- Keep out of reach of small children to prevent accidents.

Package Contents

Please check the package for the following items:

- JYX Karaoke Machine (Model T22T)
- 2 x Wireless Microphones
- USB Charging Cable
- User Manual



Image: Contents of the JYX Karaoke Machine T22T package, showing the main unit, two wireless microphones, and charging cable.

Product Overview

Familiarize yourself with the main components and controls of your JYX Karaoke Machine.



Image: The JYX Karaoke Machine T22T with its two wireless microphones, showcasing the speaker's front panel with LED lights and a phone holder slot.

Control Panel and Ports



Image: Close-up of the control panel, showing buttons for LED, Mode, Echo, volume knob, and ports for DC 5V (charging), Mic Port/Type-C Input, USB Port/TF Card, and AUX Port.

- **LED Button:** Toggles and changes LED light modes.
- **MODE Button:** Switches between Bluetooth, USB, TF Card, and AUX modes.
- **ECHO Button:** Adjusts the echo effect for the microphones.
- **VOL +/- Knob:** Adjusts the main speaker volume.
- **PREV/NEXT Buttons:** Skips to previous/next track (in media playback modes).
- **Play/Pause Button:** Plays or pauses audio.
- **DC 5V Input:** For charging the speaker.
- **Mic Port / Type-C Input:** For wired microphone connection or additional input.
- **USB Port / TF Card Slot:** For playing audio from USB drives or TF cards.
- **AUX Port:** For connecting external audio devices via a 3.5mm audio cable.

Setup

1. Charging the Speaker

Before first use, fully charge the karaoke machine. Connect the provided USB charging cable to the DC 5V input port on the speaker and the other end to a compatible USB power adapter (not included) or a computer USB port. The charging indicator will show the charging status. A full charge provides 6-8 hours of music playback and up to 10 hours under normal use.



Image: Illustration of the JYX Karaoke Machine T22T's long-lasting rechargeable battery, showing 5200mAh capacity and 4-6 hours of operation.

2. Microphone Setup

The wireless microphones are pre-paired with the speaker. Simply insert 2x AA batteries (not included) into each microphone and power them on. They should automatically connect to the speaker.



Image: A group of friends enjoying karaoke with the JYX T22T machine and its dual wireless microphones, highlighting the wireless range and clear sound.

Operating Instructions

1. Power On/Off

Press and hold the power button on the speaker to turn it on or off. A voice prompt will indicate the status.

2. Bluetooth Connection

1. Turn on the JYX Karaoke Machine. It will automatically enter Bluetooth pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or other device.
3. Search for "JYX-T22T" in the list of available devices and select it to connect.
4. Once connected, you will hear a confirmation tone. You can now play audio from your device through the speaker.

3. USB/TF Card Playback

Insert a USB flash drive or TF (Micro SD) card containing MP3 audio files into the respective port. The speaker will automatically switch to USB/TF mode and begin playing music. Use the PREV/NEXT buttons to navigate tracks.

4. AUX-in Connection

Connect an external audio device (e.g., guitar, TV, tablet) to the AUX port using a 3.5mm audio cable. Press the MODE button until "AUX" mode is selected. Audio from the connected device will now play through the speaker.



Image: Visual representation of the multiple connection options for the JYX T22T, including Bluetooth for wireless connection, AUX-in for various devices, and SD Card/USB for playing songs freely.

5. TWS (True Wireless Stereo) Mode

To achieve a powerful stereo sound experience, you can connect two JYX T22T karaoke machines together:

1. Ensure both JYX T22T speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers, press and hold the "TWS" button (or a combination of buttons if not explicitly labeled, refer to the control panel image for the RPT button which might double as TWS). The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. A confirmation tone will indicate successful pairing.
4. Once paired, connect your Bluetooth device to one of the speakers. Audio will now play in stereo through both units.



Image: Two JYX T22T karaoke machines wirelessly connected in TWS mode, demonstrating how they create a surround sound experience for a group of people.

6. Microphone Usage

- **Microphone Volume:** Adjust the microphone volume directly on the microphone itself or via the main volume knob on the speaker.
- **Echo Effect:** Press the ECHO button on the speaker to cycle through different echo levels or turn the echo off.

7. LED Light Modes

Press the LED button on the speaker to cycle through the six vibrant disco light modes. The lights synchronize with the rhythm of the music, enhancing the party atmosphere.



Image: The JYX T22T karaoke machine showcasing its colorful disco lights, with an array of 12 different light mode indicators below it.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the speaker and microphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the device regularly, even if not in frequent use. Avoid fully discharging the battery for long periods.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Battery is low or dead.	Charge the speaker fully.
No sound from speaker	Volume is too low; incorrect mode selected; device not connected.	Increase volume; press MODE button to select correct input; ensure Bluetooth/AUX/USB/TF connection is stable.
Microphones not working	Microphone batteries are dead; microphones not powered on; out of range.	Replace microphone batteries; ensure microphones are switched on; move microphones closer to the speaker.
Bluetooth connection unstable	Device too far from speaker; interference.	Move device closer to speaker (within 10 meters); avoid obstacles; turn off other Bluetooth devices.
TWS pairing failed	Speakers already connected to another device; TWS mode not activated correctly.	Disconnect both speakers from any Bluetooth devices; ensure only one speaker initiates TWS pairing.

Specifications

Feature	Detail
Model Number	T22T
Dimensions	33 x 15 x 15 cm
Weight	2.51 Kilograms
Connectivity	Bluetooth 5.0, USB, TF Card, AUX-in
Speaker Size	6.5-inch speaker
Battery Capacity	3.7V/5200mAh
Playtime	6-8 hours (music), up to 10 hours (normal use)
Microphones	2 x Wireless Microphones
LED Lights	6 Disco Light Modes



Image: An exploded view of the JYX T22T speaker's internal components, highlighting the 3-inch woofer and 3-inch tweeter for powerful stereo sound.

Warranty and Support

The JYX Karaoke Machine Model T22T comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For technical support, warranty claims, or any questions regarding your product, please contact JYX customer service through the retailer's platform or visit the official JYX brand store online. Please have your purchase receipt and product model number (T22T) ready when contacting support.

You can visit the JYX store at: JYX Official Store

© 2024 JYX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5GQWS2T

More documents and user manuals: **https://manuals.plus/**