Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEEWER TS05

NEEWER TS05 Tripod for Cell Phone & Camera Instruction Manual

Model: TS05 | Brand: NEEWER

Introduction

The NEEWER TS05 Tripod is a versatile, all-metal support system designed for both cell phones and cameras. It features a compact, extendable design, a 360° swivel ball head with 90° tilt, a universal phone holder, and a convenient Bluetooth remote shutter release. This manual provides detailed instructions for setting up, operating, and maintaining your TS05 tripod to ensure optimal performance.

Product Overview & What's in the Box

Your NEEWER TS05 Tripod package includes the following components:

- 1 x TS05 Travel Tripod
- 1 x Universal Phone Holder
- 1 x Bluetooth Remote Shutter Release



Image: The NEEWER TS05 Tripod, showcasing its compact design with the phone holder and Bluetooth remote.

Setup

1. **Unfold the Tripod Legs:** Loosen the knob on the tripod base. Push down on the tripod legs to fully extend them into a stable triangle structure. Tighten the knob to secure the legs.
2. **Extend the Pole:** Adjust the height of the tripod by extending the 5-section telescopic poles. Secure each section by twisting the locking ring clockwise.
3. **Attach Phone Holder or Camera:** The tripod features a 1/4" screw mount. If using a phone, install the universal phone holder onto the 1/4" screw. If using a camera, directly mount your camera onto the 1/4" screw.
4. **Insert Phone:** If using the phone holder, gently expand the holder and insert your smartphone. Ensure it is securely gripped.



Image: A visual guide demonstrating the six steps for setting up the tripod, from loosening the knob to inserting a phone.

Your browser does not support the video tag.

Video: An official NEEWER video demonstrating the setup and basic use of the phone tripod.

Operating Instructions

Adjusting Height and Stability

The tripod features 5-section telescopic poles. To adjust the height, twist the locking ring counter-clockwise to loosen, extend or retract the pole to your desired height, then twist clockwise to lock. The triangle mid-spread lever ensures quick setup and stability, complemented by non-slip rubber feet.



Image: Illustration of the tripod's 5-section retractable design, showing different height adjustments from 15.8 inches to 65.2 inches.

Adjusting Shooting Angle (Ball Head)

The metal ball head offers 360° panoramic rotation and 90° vertical tilt. Loosen the locking knob on the side to adjust your device to any desired angle. Tighten the knob to secure it. This allows for quick switching between portrait and landscape modes.



Image: A detailed view of the U-shaped groove design, demonstrating the 360° swivel and 135° tilt capabilities for flexible shooting angles.

Using the Universal Phone Holder

The adjustable phone holder accommodates smartphones from 2.1" to 3.4" (5.4cm to 8.5cm) wide. It features a hand-tightening knob for seamless vertical and horizontal shooting. A cold shoe mount is integrated for attaching accessories like LED fill lights or microphones.



Image: Close-up of the universal phone holder, highlighting its cold shoe interface, adjustable width, and 1/4" screw hole.

Bluetooth Shutter Release

The included Bluetooth remote allows you to wirelessly control your device's camera shutter from up to 33ft (10m) away in unobstructed areas. This is ideal for group photos, selfies, and video recording.

1. Turn on the Bluetooth remote.
2. Enable Bluetooth on your smartphone.
3. Search for "NEEWER-Shutter" in your device's Bluetooth settings and pair.
4. Open your camera app and press the button on the remote to capture photos or start/stop video recording.



Image: A visual representation of the wireless shutter release in action, showing a smartphone connected via Bluetooth to the remote.

Your browser does not support the video tag.

Video: An official NEEWER video demonstrating the use of the phone tripod with its remote shutter.

Maintenance

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a dry, cool place away from direct sunlight and extreme temperatures. Ensure it is fully retracted and the legs are folded for compact storage.
- **Lubrication:** No special lubrication is required for the telescopic poles or ball head.

Troubleshooting

- **Tripod Instability:** Ensure the tripod legs are fully spread and the locking knob is tightened. Place the tripod on a flat, stable surface.
- **Phone Not Fitting in Holder:** The phone holder is designed for a snug fit. If your phone has a thick case, you may need to remove it for proper seating. The holder supports phones 2.1"~3.4" (5.4~8.5cm) wide.
- **Bluetooth Remote Not Connecting:**
  a. Ensure the remote is powered on.
  b. Check that Bluetooth is enabled on your smartphone.
  c. Forget the device in your phone's Bluetooth settings and attempt to re-pair.
  d. Ensure the remote's battery is not depleted.
- **Difficulty Extending/Retracting Poles:** Ensure the locking rings are fully loosened before attempting to adjust the pole height. Avoid forcing the poles.

Specifications

Model Name	TS05
Brand	NEEWER
Material	Aluminum, Metal, Rubber
Item Weight	566 Grams (20 oz)
Weight Limit	1.5 kg (3.3 lbs)
Maximum Height	160 cm (62.9 inches)
Minimum Height	37.5 cm (14.7 inches)
Folded Size	40 mm diameter (1.6 inches)
Number of Leg Sections	5
Tripod Head Type	Ball Head
Special Features	Lightweight, Compact, Adjustable, Rotatable
Compatible Devices	Camera, Smartphone

Warranty & Support

This NEEWER TS05 Tripod comes with a**1 Year Manufacturer Warranty**. For any product inquiries, technical support,

or warranty claims, please contact NEEWER customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5HG32J6

More documents and user manuals: **https://manuals.plus/**