dsorupa 78a8bc84-4eee-4527-8111-0acce8d40098

dsorupa Cordless Vacuum Cleaner Instruction Manual

Model: 78a8bc84-4eee-4527-8111-0acce8d40098

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Retain this manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible materials, hot ashes, or large, sharp objects.
- Ensure the filter is properly installed before use.
- Use only the charger provided by the manufacturer to recharge the battery.
- Do not immerse the vacuum cleaner or charger in water or other liquids.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

2. Package Contents

Verify that all components are present in the package:

- Cordless Vacuum Cleaner Main Unit
- Instructions Manual
- 2-in-1 Upholstery Brush
- Long Crevice Nozzle
- Hair Cleaning Tool
- Wall Mount Plate
- Replaceable HEPA filter (additional)



Image 2.1: Main unit and all included accessories.

3. Product Overview

The dsorupa Cordless Vacuum Cleaner features a powerful 550W motor, providing up to 45,000Pa suction for effective cleaning. It includes an advanced 8x2500mAh battery for extended runtime and a smart LED touch screen for intuitive control.

Key Features:

- **Powerful Suction:** 550W motor delivers up to 45,000Pa suction for deep cleaning.
- **Extended Runtime:** 8x2500mAh battery provides up to 55 minutes of cleaning on a single charge.

- **Smart LED Touch Screen:** Displays battery level, dust cup fullness, fault alarms, and allows suction power adjustment.
- **Anti-Winding V-shaped Brush:** Designed to reduce hair tangles, with 6 LED lights for improved visibility.
- **7-Layer Filtration System:** Captures 99.99% of dust and dirt, releasing clean air.
- **1.5L Dust Cup:** Large capacity with one-key emptying for convenience.



Image 3.1: Overview of key product features.



Image 3.2: Smart LED Touch Screen displaying battery and suction modes.



Image 3.3: Internal view of the 7-layer high-efficiency filtration system.

4. Setup and Assembly

Follow these steps to assemble your dsorupa Cordless Vacuum Cleaner:

1. **Attach the Extension Tube:** Insert the metal extension tube into the main unit until it clicks securely.
2. **Connect the Floor Brush:** Attach the V-shaped floor brush to the other end of the extension tube, ensuring it clicks into place.
3. **Install Wall Mount (Optional):** Choose a suitable location for the wall mount. Secure it to the wall using the provided screws. The vacuum can be stored and charged on this mount.
4. **Initial Charge:** Before first use, fully charge the battery. Connect the charger to the main unit or directly to the removable battery. The LED screen will indicate charging status.



Image 4.1: Wall mount installation and accessory storage.



Image 4.2: Vacuum cleaner charging while stored on the wall mount.

5. Operating Instructions

Operating your dsorupa Cordless Vacuum Cleaner is straightforward:

1. **Power On/Off:** Press the power button on the handle to turn the vacuum on or off.
2. **Adjust Suction Power:** Use the touch screen controls (MIN, MID, MAX) to select the desired suction level. The LED display will show the current mode and battery percentage.
3. **Using Attachments:** Detach the extension tube and floor brush to use the main unit with the 2-in-1 upholstery brush or long crevice nozzle for cleaning furniture, corners, or car interiors.
4. **Floor Cleaning:** The V-shaped floor brush is suitable for various floor types, including hardwood, tile, and carpet. The integrated LED lights illuminate dark areas.



Image 5.1: Demonstrating the vacuum's suction power on various debris.



Image 5.2: The V-shaped brush head with LED lights effectively cleaning floors.



Image 5.3: Using the vacuum in handheld mode for targeted cleaning.



Image 5.4: Utilizing the crevice tool for narrow spaces.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Emptying the Dust Cup

Empty the dust cup when the 'dust cup full' indicator appears on the LED screen or when debris reaches the MAX line.

1. Ensure the vacuum is turned off.
2. Press the one-key release button on the dust cup to open the bottom flap and empty contents into a trash bin.
3. Close the dust cup flap securely.



Image 6.1: One-click emptying of the dust cup.

6.2 Cleaning the Filters

The 7-layer filtration system includes a HEPA filter. Clean filters regularly to maintain suction power.

1. Twist and remove the dust cup from the main unit.
2. Remove the internal filter components (HEPA filter, metal filter).
3. Tap off loose dust. Rinse the filters under cold running water. Do not use detergent.

4. Allow filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.

6.3 Cleaning the Brush Roll

Periodically check the V-shaped brush roll for tangled hair or debris.

1. Turn off the vacuum and detach the floor brush.
2. Locate the brush roll release mechanism (usually a latch or screw) and remove the brush roll.
3. Use the provided hair cleaning tool or scissors to cut and remove any tangled hair or fibers.
4. Reinsert the brush roll and secure it in place.

7. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following table:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is depleted; Battery not properly installed; Power button malfunction.	Charge the battery; Reinstall battery securely; Contact customer support.
Low suction power	Dust cup full; Filters clogged; Blockage in nozzle/tube; Brush roll tangled.	Empty dust cup; Clean/replace filters; Remove blockage; Clean brush roll.
Brush roll not spinning	Brush roll tangled; Obstruction in brush head; Brush head not properly attached.	Clean brush roll; Remove obstruction; Reattach brush head securely.
Short battery runtime	Battery not fully charged; Using MAX suction mode continuously; Battery degradation.	Ensure full charge; Use lower suction modes when possible; Contact customer support for battery replacement.

8. Specifications

Feature	Specification
Brand	dsorupa
Model Number	78a8bc84-4eee-4527-8111-0acce8d40098
Wattage	550W
Maximum Suction	45,000Pa
Battery Type	8 x 2500mAh Lithium Ion

Feature	Specification
Maximum Runtime	Up to 55 minutes (on minimum suction)
Dust Cup Capacity	1.5 Liters
Filter Type	7-layer system with HEPA Filter
Noise Level	68 dB
Product Dimensions	13"L x 7"W x 48"H
Item Weight	8 pounds
Control Method	Touchpad Control

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or the official dsorupa website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I contact the manufacturer for support with a defective dsorupa Cordless Vacuum Cleaner?

To contact the manufacturer regarding a defective dsorupa Cordless Vacuum Cleaner, please follow these steps:Check the Packaging: The manufacturer, dsorupa, typically provides specific customer support email addresses or phone numbers on the product packaging...

Read full answer

What does the E3 error code on the display of the dsorupa Cordless Vacuum Cleaner mean, and why will the battery pack not charge?

While the provided manual for the dsorupa Cordless Vacuum Cleaner mentions that the LED touch screen displays "fault alarms," it does not explicitly define the "E3" code in the troubleshooting table. However, based on...

Read full answer