Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC901V-FMRG

ALLIMITY RC901V FMRG Voice Replacement Remote Control User Manual

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ALLIMITY RC901V FMRG Voice Replacement Remote Control. Please read this guide thoroughly to ensure proper use and to maximize the functionality of your remote control with compatible TCL Smart TVs.

Product Overview







Figure 1: Front view of the remote control, showing all buttons including the number pad, navigation, volume, channel, and dedicated app buttons.





Figure 2: Back view of the remote control, illustrating the battery compartment designed for two AAA batteries.



20.5 cm / 8.07 in



Figure 3: Front and side profile of the remote control, indicating its approximate dimensions of 20.5 cm (8.07 in) in length and 4 cm (1.57 in) in width.

Specifications

Product Dimensions	6 x 2 x 0.6 inches (15.24 x 5.08 x 1.52 cm)
Item Weight	2 ounces (56.7 grams)
Model Number	RC901V-FMRG
Batteries Required	2 AAA batteries (not included)
Special Feature	Voice Search
Color	Black
Compatible Devices	Television

Compatibility

This replacement remote control is compatible with various TCL Smart TV models, including but not limited to:

- **Remote Models:** RC901V FMR1, RC901V FAR1, RC901V FMR7
- **TCL C725 Series:** 50C725, 55C725, 65C725, 75C725
- **TCL C727 Series:** 55C727, 65C727, 75C727
- **TCL C735 Series:** 98C735
- **TCL C825 Series:** 55C825, 65C825, 75C825, 85C825
- **TCL P725 Series:** 43P725, 50P725, 55P725, 65P725, 75P725, 85P725

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover, ensuring it clicks securely into place.

2. Pairing Instructions (for Voice Functionality)

This remote control features voice functionality, which requires pairing with your TCL Smart TV. The pairing process may vary slightly depending on your specific TV model. Generally, follow these steps:

1. Ensure your TV is powered on.
2. Point the remote control towards your TV.
3. On your TV, navigate to **Settings** > **Remotes & Accessories** (or similar menu path).
4. Select **Add Accessory** or **Pair Remote**.

5. Follow the on-screen prompts. You may be instructed to press and hold specific buttons on the remote (e.g., the 'OK' button and 'Home' button simultaneously) until a pairing indicator appears on the TV screen.
6. Once paired, a confirmation message will appear on your TV.

Note: If you encounter issues, refer to your TCL TV's user manual for specific pairing instructions.

Operating Instructions

1. Button Functions

The remote control features a standard layout for easy navigation and control:

- **Power Button ( ):** Turns the TV on or off.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Number Pad (0-9):** Directly input channel numbers.
- **LIST Button:** Accesses a list of channels or recent inputs.
- **Settings/Gear Button (⚙):** Opens the TV's settings menu.
- **Home Button ( ):** Returns to the TV's home screen or smart TV interface.
- **Navigation Buttons (Up, Down, Left, Right):** Move cursor or selection.
- **OK Button:** Confirms selection or opens menu items.
- **Back Button (←):** Returns to the previous screen or menu.
- **Input/Source Button ( ):** Selects input sources (HDMI, AV, etc.).
- **Volume Up/Down (V+/V-):** Adjusts the TV volume.
- **Channel Up/Down (P+/P-):** Changes TV channels.
- **Google Assistant/Voice Button ( ):** Activates voice control (requires pairing).
- **Dedicated App Buttons (Netflix, YouTube, T-Channel, Prime Video):** Provide quick access to these streaming applications.

2. Voice Control

After successful pairing, you can use the voice control feature:

1. Press and hold the **Google Assistant/Voice Button** ( ) on the remote control.
2. Speak your command clearly into the microphone located on the remote. Examples include:
    - "Open Netflix"
    - "Search for action movies"
    - "Switch to HDMI 1"
    - "What's the weather like?"
3. Release the button when you have finished speaking. The TV will process your command.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote is not responding to TV commands.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. Remote not paired (for voice/Bluetooth functions).	Check and replace batteries. Ensure clear line of sight to TV's IR receiver. Re-pair the remote control with the TV (see Pairing Instructions).
Voice control is not working.	Remote not paired for voice functionality. TV's internet connection is unstable (if voice commands require online processing).	Ensure the remote is correctly paired for voice control. Check your TV's internet connection. Speak clearly and hold the voice button while speaking.
Buttons are sticky or unresponsive.	Dirt or debris under the buttons.	Clean the remote control with a soft, dry cloth. Avoid using liquids.

Package Contents

The package for the ALLIMITY RC901V FMRG Voice Replacement Remote Control typically includes:

- 1 x ALLIMITY RC901V FMRG Voice Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5M1B6RS

More documents and user manuals: **https://manuals.plus/**