Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic F10 Pro

Proscenic F10 Pro Wet Dry Vacuum Cleaner Instruction Manual

Model: F10 Pro

Brand: Proscenic

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for household use only. Do not use outdoors or on commercial surfaces.
- Do not immerse the appliance in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only Proscenic recommended cleaning solutions.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Always turn off the appliance before making any adjustments, changing accessories, or storing.
- Store the appliance indoors in a cool, dry place.

2. Product Overview and Components

The Proscenic F10 Pro is a 3-in-1 wet dry vacuum cleaner designed for efficient cleaning of hard floors. It vacuums, mops, and washes simultaneously.

Included Components:

- Main unit (including floor brush, roller brush, HEPA filter)
- Handle
- Charging Base
- Power Adapter
- Cleaning Brush
- Instruction Manual
- After-sales Card



Figure 2.1: Proscenic F10 Pro Wet Dry Vacuum Cleaner and accessories.

3. Setup and Initial Use

3.1 Assembly

1. Insert the handle into the main unit until it clicks securely into place.
2. Place the assembled unit onto the charging base.

3.2 Charging

1. Connect the power adapter to the charging base and plug it into a wall outlet.
2. Ensure the unit is properly seated on the charging base. The LED display will indicate charging status.
3. Allow approximately 5 hours for a full charge before first use.

3.3 Filling the Clean Water Tank

1. Press the tank release button and remove the clean water tank.

2. Open the tank cap and fill with clean tap water. For enhanced cleaning, add a small amount of Proscenic cleaning solution (follow solution instructions for dilution).
3. Close the cap securely and reinsert the tank into the main unit until it clicks.

4. Operating the Appliance

4.1 Power On/Off

Press the power button on the handle to turn the appliance on or off.

4.2 Cleaning Modes

The F10 Pro offers three cleaning modes, selectable via the mode button on the handle:

- **Smart Mode:** For general daily cleaning. The appliance automatically adjusts suction and water flow based on floor dirt detection.
- **Max Mode:** Provides maximum suction and water flow for heavy-duty stains and deeply embedded dirt.
- **Suction Mode:** Designed for absorbing liquids without dispensing water, ideal for spills.



Figure 4.1: The F10 Pro performing 3-in-1 vacuum, mop, and wash functions on a hard floor.

4.3 LED Display and Voice Guidance

The integrated LED display provides real-time information on battery life, current cleaning mode, and maintenance alerts. Voice prompts guide you through various operations and alerts, such as tank status or self-cleaning initiation.



Figure 4.2: User-friendly LED display showing operational status.

4.4 Self-Propelled Movement

The F10 Pro features a self-propulsion system that assists in forward movement, reducing effort during cleaning. The flexible floor brush enhances maneuverability around obstacles.



Figure 4.3: The self-propelled system makes cleaning effortless.

4.5 Edge Cleaning

The design of the floor brush allows for effective cleaning close to edges and baseboards, minimizing uncleaned areas.



Figure 4.4: Edge-to-edge cleaning capability.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your F10 Pro.

5.1 Automated Self-Cleaning

After each use, place the appliance on the charging base and press the self-cleaning button. The appliance will

automatically wash the roller brush and internal tubing with clean water, helping to prevent odors and maintain hygiene.



Figure 5.1: Automated self-cleaning cycle on the charging base.

5.2 Emptying and Cleaning the Dirty Water Tank

Empty the dirty water tank after each use. The tank features a solid-liquid separator for easy disposal of solid debris.

1. Press the dirty water tank release button and remove the tank.
2. Open the tank lid and dispose of dirty water and debris.

3. Rinse the tank and the solid-liquid separator thoroughly with clean water.
4. Ensure all parts are dry before reassembling and reinserting the tank.

5.3 Cleaning the Roller Brush

While the self-cleaning function helps, occasional manual cleaning of the roller brush may be necessary.

1. Turn off the appliance and remove the dirty water tank.
2. Open the roller brush cover and remove the roller brush.
3. Use the provided cleaning brush to remove any hair or debris tangled around the roller.
4. Rinse the roller brush under running water. Allow it to air dry completely before reinstallation.

5.4 HEPA Filter Maintenance

The HEPA filter should be cleaned regularly and replaced periodically to maintain suction performance.

1. Locate and remove the HEPA filter (typically found within the dirty water tank assembly).
2. Tap the filter gently to dislodge dust and debris. You may rinse it under running water if heavily soiled, but ensure it is completely dry before reinstallation.
3. Replace the HEPA filter every 3-6 months, depending on usage.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not power on	Low battery; Not charged	Charge the appliance fully. Ensure the power adapter is connected correctly.
No water dispensed / Low water flow	Clean water tank empty; Tank not installed correctly; Nozzle blocked	Refill the clean water tank. Reinstall the tank securely. Check and clean the water dispensing nozzle.
Poor suction / Leaves streaks	Dirty water tank full; Roller brush tangled/dirty; HEPA filter clogged	Empty and clean the dirty water tank. Clean the roller brush. Clean or replace the HEPA filter.
Self-cleaning function not working	Dirty water tank not installed correctly; Appliance not on charging base; Low battery	Ensure the dirty water tank is securely in place. Confirm the appliance is correctly seated on the charging base. Ensure sufficient battery charge.
Unpleasant odor	Dirty water tank not cleaned; Roller brush not cleaned/dried properly	Empty and thoroughly clean the dirty water tank after each use. Clean and allow the roller brush to air dry completely. Run the self-cleaning cycle.
Voice prompts are too loud/soft	Volume settings	Refer to the appliance's controls for adjusting voice prompt volume.

7. Specifications

Feature	Specification
Model Name	US-F10 Pro
Brand	Proscenic
Special Features	Automated Self-Cleaning, Headlight, Lightweight, Vacuum and Mop Combo, Wet/Dry
Filter Type	HEPA Filter
Cordless	Yes
Clean Water Tank Capacity	650 Milliliters
Dirty Water Tank Capacity	500 Milliliters (approximate, inferred from runtime description)
Wattage	125 watts
Charging Time	5 Hours
Battery Type	Lithium-Ion (6x2,600 mAh battery pack)
Battery Life (Runtime)	Up to 30 minutes
Noise Level	79 dB
Product Dimensions	43"L x 10"W x 8"H
Item Weight	9 pounds
Control Method	Push Button, Voice



Figure 7.1: Runtime and tank capacities of the F10 Pro.

8. Warranty and Support

For warranty information, please refer to the 'After-sales Card' included in your product packaging. If you encounter any issues or require technical assistance, please contact Proscenic customer support through the official website or the contact information provided in your documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my Proscenic F10 Pro display a 'fill clean water' error even though I have already filled the tank?

If your Proscenic F10 Pro continues to prompt you to add clean water after you have already filled the tank, please check the following troubleshooting steps based on the manual: Check Tank Installation: Ensure...

Read full answer

Open the live page

https://manuals.plus/asin/B0D5MFYDFW

More documents and user manuals: **https://manuals.plus/**